



Count on it.


Operator's Manual

Auger Head and Universal Swivel Auger Head

Compact Tool Carrier

Model No. 22805—Serial No. 402000000 and Up

Model No. 22806—Serial No. 402000000 and Up



G004513



This product complies with all relevant European directives. For details, please see the Declaration of Incorporation (DOI) at the back of this publication.

⚠ WARNING

CALIFORNIA
Proposition 65 Warning

This product contains a chemical or chemicals known to the State of California to cause cancer, birth defects, or reproductive harm.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Important: With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.




Figure 1

g244284

1. Model and serial number location

Introduction

The machine is a hydraulically powered auger attachment for compact tool carriers. It is designed to dig vertical holes in the earth for the installation of posts, plants, and other construction and landscaping needs. It is not intended to drill holes in pavement, concrete, or ice.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

You may contact Toro directly at www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. [Figure 1](#) identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol ([Figure 2](#)), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

g000502

1. Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	3
General Safety	3
Slope Safety	4
Auger Safety	4
Maintenance and Storage Safety	4
Safety and Instructional Decals	5
Product Overview	5
Specifications	5
Operation	6
Installing and Removing the Attachment	6
Installing an Auger	6
Digging a Hole	8
Removing an Auger	8
Transport Position	9
Maintenance	10
Recommended Maintenance Schedule(s)	10
Greasing the Cradle Arm Pivot Points	10
Changing the Planetary Gear Case Oil	10
Storage	11
Troubleshooting	12

Safety

⚠ DANGER

There may be buried utility lines in the work area. Digging into them may cause a shock or an explosion.

Have the property or work area marked for buried lines and do not dig in marked areas. Contact your local marking service or utility company to have the property marked (for example, in the US, call 811 or in Australia, call 1100 for the nationwide marking service).

General Safety

Always follow all safety instructions to avoid serious injury or death.

- Always carry the attachment close to the ground; refer to [Transport Position \(page 9\)](#).
- Have the property or work area marked for buried lines and other objects, and do not dig in marked areas.
- Read and understand the content of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Never allow children or untrained people to operate the machine.
- Keep your hands and feet away from the moving components and attachments.
- Do not operate the machine without the guards and other safety protective devices in place and working on the machine.
- Keep bystanders and pets a safe distance away from the machine.
- Stop the machine, shut off the engine, and remove the key before servicing, fueling, or unclogging the machine.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

You can find additional safety information where needed throughout this *Operator's Manual*.

Slope Safety

- **Operate the machine up and down slopes with the heavy end of the machine uphill.** Weight distribution changes with attachments. This attachment makes the front of machine the heavy end.
- **Keep the attachment in the lowered position when on slopes.** Raising the attachment on a slope affects the stability of the machine.
- Slopes are a major factor related to loss of control and tip-over accidents, which can result in severe injury or death. Operating the machine on any slope or uneven terrain requires extra caution.
- Establish your own procedures and rules for operating on slopes. These procedures must include surveying the site to determine which slopes are safe for machine operation. Always use common sense and good judgment when performing this survey.
- Slow down and use extra care on hillsides. Ground conditions can affect the stability of the machine.
- Avoid starting or stopping on a slope. If the machine loses traction, proceed slowly, straight down the slope.
- Avoid turning on slopes. If you must turn, turn slowly and keep the heavy end of the machine uphill.
- Keep all movements on slopes slow and gradual. Do not make sudden changes in speed or direction.
- If you feel uneasy operating the machine on a slope, do not do it.
- Watch for holes, ruts, or bumps, as uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Use caution when operating on wet surfaces. Reduced traction could cause sliding.
- Do not operate the machine near drop-offs, ditches, embankments, or bodies of water. The machine could suddenly roll over if a wheel or track goes over the edge or the edge caves in. Maintain a safe distance between the machine and any hazard.
- Do not remove or add attachments on a slope.
- Do not park the machine on a hillside or slope.

Auger Safety

- For wheeled machines, use the counterweight on the traction unit when using the auger head with a 30 to 76 cm (12 to 30 inch) auger installed.
- For wheeled machines, do not use the counterweight when using the auger head without an auger or with an auger smaller than 30 cm (12 inches).
- Keep your hands, feet, and any other part of your body or clothing away from moving auger or other parts.


Maintenance and Storage Safety

- Check fasteners at frequent intervals for proper tightness to ensure that the equipment is in safe operating condition.
- Refer to the *Operator's Manual* for important details if you store the attachment for an extended period of time
- Maintain or replace safety and instruction labels, as necessary.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



105-0326

decal105-0326

1. Warning—read the *Operator's Manual*.
2. Entanglement hazard, auger—keep bystanders a safe distance away from the auger.
3. Explosion and/or electric shock hazard—do not dig in areas with buried gas or power lines.

Product Overview




Figure 3

g004514

1. Hose guide
2. Mounting plate
3. Motor
4. Cradle arm
5. Drive head
6. Drive shaft

Specifications

Note: Specifications and design are subject to change without notice.

Model 22805	
Width	62 cm (24 inches)
Length	40 cm (16 inches)
Height	59 cm (23 inches)
Weight	83 kg (182 lb)

Model 22806	
Width	62 cm (24 inches)
Length	42 cm (17 inches)
Height	59 cm (23 inches)
Weight	89 kg (196 lb)

Operation

Installing and Removing the Attachment

Refer to the *Operator's Manual* for the traction unit for the installation and removal procedure.

Important: Before installing the attachment, position the machine on a level surface, ensure that the mount plates are free of any dirt or debris, and ensure that the pins rotate freely. If the pins do not rotate freely, grease them.

Note: Always use the traction unit to lift and move the attachment. To move an auger without the drive head, sling a strap over each end of the auger and hoist it to the desired location.

⚠ WARNING

If you do not fully seat the quick-attach pins through the attachment mount plate, the attachment could fall off the machine, crushing you or bystanders.

Ensure that the quick-attach pins are fully seated in the attachment mount plate.

⚠ WARNING

Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury; otherwise, gangrene may result.

- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks; never use your hands.

⚠ CAUTION

Hydraulic couplers, hydraulic lines/valves, and hydraulic fluid may be hot. If you contact hot components, you may be burned.

- Wear gloves when operating the hydraulic couplers.
- Allow the machine to cool before touching hydraulic components.
- Do not touch hydraulic fluid spills.

Installing an Auger

⚠ WARNING

The auger head swings freely in the cradle arms. Your hands or fingers could get pinched and severely injured or amputated if they are caught between the cradle arms and the swinging drive head.

Keep your hands and fingers away from the cradle arms.

1. Park the machine on a level surface, lower the loader arms, and engage the parking brake (if applicable).
2. If you are installing an auger on the Model 22806 drive head, shut off the engine and remove the key. Position the drive head vertically, slide a bolt (1/2 x 2-1/2 inches) into the holes in the front cradle arms, and secure it lightly with a flange nut (1/2 inch) as shown in [Figure 4](#).




Figure 4

1. Drive head (front view)
2. Bolt
3. Front cradle arm

3. Start the engine and raise the loader arms so that the drive head clears the ground.
4. Shut off the engine and remove the key.

- Manually rotate the auger drive head up, until you can slide a bolt (1/2 x 2-1/2 inches) into the hole in the cradle arm, securing the drive head. Lightly secure the bolt with a nut (1/2 inch) as shown in [Figure 5](#).




Figure 5

- Drive head
- Cradle arm
- Bolt and flange nut

- If using an extension with the auger, insert the end of the extension into the end of the auger and secure the auger to the extension with a bolt (7/8 x 4-1/2 inch) and nut (7/8 inch) as shown in [Figure 6](#).




Figure 6

- Extension
- Auger
- Bolt (7/8 x 4-1/2 inch)
- Nut (7/8 inch)

- Start the engine.
- Maneuver the drive shaft into the end of the auger shaft or extension (if applicable) as shown in [Figure 7](#).




Figure 7

- Drive head
- Auger shaft

- Shut off the engine and remove the key.
- Secure the auger to the drive head with a bolt (7/8 x 4-1/2 inch) and nut (7/8 inch) as shown in [Figure 8](#).




Figure 8

- Bolt (7/8 x 4-1/2 inches)
- Nut (7/8 inch)
- Bolt(s) and nut(s)

- Remove the bolts and nuts from the cradle arms installed in steps 2 (if applicable) and 5.
- Start the engine.
- Raise the auger free of the ground ([Figure 9](#)).




Figure 9

- When the auger is vertical, tilt the attachment plate rearward until the drive head contacts the attachment plate to stabilize the auger and keep it from swinging freely ([Figure 9](#)).

Digging a Hole

Important: Before digging, ensure that the ground is free of any trash or debris.

1. Lower the auger to the soil at the site of the proposed hole.
2. Move the throttle lever to the FAST position.
3. If your traction unit has a speed-selector lever, move it to the SLOW position.
4. If your traction unit has a flow-divider control, move it to the 10 o'clock position.
5. Pull the auxiliary hydraulics lever to the operator grip or reference bar to begin digging.
6. Lower the auger slowly as the soil is loosened. As you dig deeper, move the traction unit backward or forward as required to keep the auger vertical (Figure 10).




Figure 10

7. When the auger becomes full of soil, disengage the auger drive and lift the auger from the hole. Engage the auger drive to spin off the soil, then resume digging.

Important: Switching the auxiliary hydraulics lever rapidly from forward to reverse will help to shake off the soil.

⚠ DANGER

If you are using Model 22806, excessive downward force may cause the bit to wobble uncontrollably, which could tip the traction unit. You or bystanders could be pinned or seriously injured.

Do not use excessive downward pressure on the bit. Allow the bit to pull itself into the soil.

Removing an Auger

1. Disengage the auxiliary hydraulics.
2. Raise the loader arms so the auger comes out of the hole.
Note: If you have a 24-inch extension installed between the drive head and the auger, it may be necessary to raise the auger as high as possible and then move the traction unit backward to pull the auger the rest of the way out of the hole.
3. Drive the machine to the storage location for the auger.
4. While lowering the arms, drive slowly backwards until the auger is horizontal.
5. Shut off the engine and remove the key.
6. Remove the bolt and nut securing the drive head to the auger or extension.
7. Start the engine and back the traction unit away from the auger.
8. If you used an extension, remove the bolt and nut securing it and pull it off the auger.

Transport Position

- When transporting any size auger over short distances or an auger larger than 51 cm (20 inch) diameter over longer distances, do the following:
 1. Raise the auger so that it clears the ground and is vertical (Figure 9).




Figure 11

2. Tilt the attachment plate rearward until the drive head contacts the attachment plate to stabilize the auger and keep it from swinging freely.

- When transporting an auger smaller than 51 cm (20 inch) diameter over long distances or slopes, do the following:
 1. While lowering the arms, drive slowly backwards until the auger is horizontal, then engage the parking brake (if applicable).
 2. Shut off the engine and remove the key.
 3. Manually rotate the auger drive head up, until you can slide a bolt (1/2 x 2-1/2 inches) into the hole in the cradle arm, securing the drive head. Lightly secure the bolt with a nut (1/2 inch) as shown in Figure 5.
 4. As you transport the auger, keep it as close to the ground as possible, no more than 15 cm (6 inches) above the lowest position.




Figure 12

1. No more than 15 cm (6 inches) above the lowest position

Maintenance

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 50 hours	<ul style="list-style-type: none"> Change the planetary gearcase oil.
Before each use or daily	<ul style="list-style-type: none"> Grease the cradle arm pivot points. (Grease all fittings immediately after every washing.) Check the auger teeth and replace them if they are damaged or worn.
Every 1,000 hours	<ul style="list-style-type: none"> Change the planetary gearcase oil.
Before storage	<ul style="list-style-type: none"> Check the auger teeth and replace them if they are damaged or worn. Paint chipped surfaces.

⚠ CAUTION

If you leave the key in the switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Remove the key from the switch before you perform any maintenance.

Greasing the Cradle Arm Pivot Points

Service Interval: Before each use or daily (Grease all fittings immediately after every washing.)

Grease Type: General-purpose grease

1. Park the machine on a level surface, engage the parking brake (if applicable), and lower the loader arms.
2. Shut off the engine and remove the key.
3. Clean the grease fittings with a rag.
4. Connect a grease gun to each fitting.
5. Pump grease into the fittings until grease begins to ooze out of the bearings.
6. Wipe up any excess grease.




Figure 13

1. Planetary gear case
2. Bolts
3. Motor

Changing the Planetary Gear Case Oil

Service Interval: After the first 50 hours

Every 1,000 hours

Type: Mild, extreme pressure lubricant, rated API-GL-5, number 80 or 90

Capacity: 0.4 L (13.6 fl oz)

1. Support the drive head over an oil pan (Figure 13).

2. Remove the 4 bolts securing the motor and remove the motor, allowing all the oil to drain into the pan.
3. When the oil is completely drained, turn the drive head so that the opening is facing the up.
4. Add oil to the gearcase.
5. Replace the motor and secure it with the four bolts removed previously. Torque the bolts to 142 N·m (105 ft-lb).

Storage

1. Before long term storage, wash the attachment with mild detergent and water to remove dirt and grime.
2. Check and tighten all bolts, nuts, and screws. Repair or replace any damaged or worn part.
3. Ensure that all hydraulic couplers are connected together to prevent contamination of the hydraulic system.
4. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
5. Store the attachment in a clean, dry garage or storage area. Cover it to protect it and keep it clean.

Troubleshooting

Problem	Possible Cause	Corrective Action
The drive head does not operate.	<ol style="list-style-type: none"><li data-bbox="586 218 1029 275">1. Hydraulic coupler not completely connected.<li data-bbox="586 285 1029 342">2. A hydraulic coupler needs to be replaced.<li data-bbox="586 352 1029 409">3. There is an obstruction in a hydraulic hose.<li data-bbox="586 420 1029 434">4. A hydraulic hose is kinked.<li data-bbox="586 445 1029 472">5. The gearbox is contaminated.	<ol style="list-style-type: none"><li data-bbox="1062 218 1508 245">1. Check and tighten all couplers.<li data-bbox="1062 285 1508 342">2. Check the couplers and replace any that are worn or damaged.<li data-bbox="1062 352 1508 380">3. Find and remove the obstruction.<li data-bbox="1062 411 1508 438">4. Replace the kinked hose.<li data-bbox="1062 445 1508 497">5. Refer to your Authorized Service Dealer.

Notes:

Notes:

Declaration of Incorporation

The Toro Company, 8111 Lyndale Avenue South, Bloomington, MN, USA declares that the following unit(s) conform(s) to the directives listed, when installed in accordance with the accompanying instructions onto certain Toro models as indicated on the relevant Declarations of Conformity.

Model No.	Serial No.	Product Description	Invoice Description	General Description	Directive
22805	402000000 and Up	Auger Head	AUGER POWER HEAD ATTACHMENT CE	Auger	2006/42/EC
22806	402000000 and Up	Universal Swivel Auger Head	SWIVEL AUGER POWER HEAD ATTACHMENT CE	Auger	2006/42/EC

Relevant technical documentation has been compiled as required per Part B of Annex VII of 2006/42/EC.

We will undertake to transmit, in response to requests by national authorities, relevant information on this partly completed machinery. The method of transmission shall be electronic transmittal.

This machinery shall not be put into service until incorporated into approved Toro models as indicated on the associated Declaration of Conformity and in accordance with all instructions, whereby it can be declared in conformity with all relevant Directives.

Certified:



Joe Hager
Sr. Engineering Manager
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
February 6, 2018

Authorized Representative:

Marcel Dutrieux
Manager European Product Integrity
Toro Europe NV
Nijverheidsstraat 5
2260 Oevel
Belgium

Tel. +32 16 386 659

European Privacy Notice

The Information Toro Collects

Toro Warranty Company (Toro) respects your privacy. In order to process your warranty claim and contact you in the event of a product recall, we ask you to share certain personal information with us, either directly or through your local Toro company or dealer.

The Toro warranty system is hosted on servers located within the United States where privacy law may not provide the same protection as applies in your country.

BY SHARING YOUR PERSONAL INFORMATION WITH US, YOU ARE CONSENTING TO THE PROCESSING OF YOUR PERSONAL INFORMATION AS DESCRIBED IN THIS PRIVACY NOTICE.

The Way Toro Uses Information

Toro may use your personal information to process warranty claims, to contact you in the event of a product recall and for any other purpose which we tell you about. Toro may share your information with Toro's affiliates, dealers or other business partners in connection with any of these activities. We will not sell your personal information to any other company. We reserve the right to disclose personal information in order to comply with applicable laws and with requests by the appropriate authorities, to operate our systems properly or for our own protection or that of other users.

Retention of your Personal Information

We will keep your personal information as long as we need it for the purposes for which it was originally collected or for other legitimate purposes (such as regulatory compliance), or as required by applicable law.

Toro's Commitment to Security of Your Personal Information

We take reasonable precautions in order to protect the security of your personal information. We also take steps to maintain the accuracy and current status of personal information.

Access and Correction of your Personal Information

If you would like to review or correct your personal information, please contact us by email at legal@toro.com.

Australian Consumer Law

Australian customers will find details relating to the Australian Consumer Law either inside the box or at your local Toro Dealer.