



36in Sprayer SprayMaster

Model No. 34246—Serial No. 40000000 and Up

Setup Instructions

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Description	Qty.	Use
10W-50 engine oil service classification SJ or higher	as required.	Service the engine.
15W-50 hydraulic fluid API rating CI-4/CF	as required.	Service the hydraulic oil.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	
Engine Owner Manual	1	
Digital Display User's Manual	1	

Checking Tire Pressure

1. Check the tire pressure in the drive and caster tires. Proper inflation for all tires is 110 to 138 kPa (16 to 20 psi).
2. Adjust if necessary.

Servicing the Battery

Important: The machine is shipped with a sealed AGM lead acid battery.

⚠ DANGER

Charging or jump starting the battery may produce explosive gases. Battery gases can explode, causing serious injury.

- Keep sparks, flames, or cigarettes away from the battery.
- Ventilate when charging or using the battery in an enclosed space.
- Ensure that the venting path of the battery is always open once the battery is filled with acid.
- Always shield eyes and face from the battery.



▲ DANGER

Battery electrolyte contains sulfuric acid, which is poisonous and can cause severe burns. Swallowing electrolyte can be fatal or can cause severe burns if it touches skin.

- **Wear safety glasses to shield eyes, and rubber gloves to protect skin and clothing when handling electrolyte.**
- **Do not swallow electrolyte.**
- **In the event of an accident, flush with water and call a doctor immediately.**

1. Check the voltage of the battery with a digital voltmeter or with the message display. If the voltage is less than 12.4V, the battery may need to be charged.

Important: In order to prevent damage to the battery, use an automatic 12V smart charger that is approved for use with AGM batteries with an output of 3.5A or less. The recommended battery charger is Part No. 135-7024. Ensure that the negative battery cable is disconnected before charging and that the charger is set to the correct mode for 12V AGM batteries.

2. Connect the negative battery cable.

Note: If the positive cable is also disconnected, connect the **positive (red) cable** to the positive battery terminal **first**, then the negative (black) cable to the negative battery terminal. Slip the insulator boot over the positive terminal.

Note: If time does not permit charging the battery, or if charging equipment is not available, connect the negative battery cable and run the vehicle continuously for 20 to 30 minutes to sufficiently charge the battery.

Servicing the Engine

The engine is shipped with oil; check the oil level and if necessary fill to the appropriate level; refer to the engine owner's manual for an appropriate API rating and viscosity.

Servicing the Hydraulic Oil

The machine is shipped with hydraulic oil in the transmission and expansion tank.

1. Run the machine for approximately 15 minutes to allow any extra air to purge out of the hydraulic system.
2. With the machine cold, check the hydraulic-reservoir fluid level. If necessary, add hydraulic fluid until the fluid reaches halfway up the reservoir sight window.
3. Replace the hydraulic-reservoir cap and tighten until snug. **Do not overtighten.**

Filling Out the Product Registration

Fill out the online warranty registration form.