



Residential Products

# Garden Tractor GT Series

## Service Manual



# ABOUT THIS MANUAL

---

This service manual was written expressly for Toro service technicians. The Toro company has made every effort to make the information in this manual complete and correct.

Basic shop safety knowledge and mechanical/electrical skills are assumed. The Table of Contents lists the systems and the related topics covered in this manual.

For service information on the Hydro-Gear hydrostatic transaxle, please refer to the Hydro-Gear 310-3000 Transaxle service manual (form no. 492-0682). For electrical service, please refer to the Riding Products Demystification Guide, 2006-2007 (form no. 492-9173), or the Electrical Troubleshooting DVD (form no. 492-9193).

Units covered in this manual are: GT2000 Series Lawn & Garden Tractors

The manual may also be specified for use on later model products.

The hydraulic power system is precision machinery. Maintain strict cleanliness control during all stages of service and repair. Cover or cap all hose ends and fittings whenever they are exposed. Even a small amount of dirt or other contamination can severely damage the system.

We are hopeful that you will find this manual a valuable addition to your service shop. If you have any questions or comments regarding this manual, please contact us at the following address:

The Toro Company  
Residential and Landscape Contractor Technical Services  
8111 Lyndale Avenue South  
Bloomington, MN 55420

The Toro Company reserves the right to change product specifications or this manual without notice.

**THIS PAGE INTENTIONALLY LEFT BLANK.**

# TABLE OF CONTENTS

## SAFETY INFORMATION

General Information.....	1-1
Think Safety First.....	1-1

## SPECIFICATIONS

Torque Specifications .....	2-1
Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series).....	2-2
Standard Torque for Dry, Zinc and Steel Fasteners (Metric Series).....	2-3
Other Torque Specifications .....	2-4
Equivalents and Conversions.....	2-5
U.S. to Metric Conversions.....	2-6
Product Specifications.....	2-7

## CHASSIS

Front Pivot Axle Replacement .....	3-1
Front Pivot Axle Removal.....	3-1
Front Pivot Axle Installation.....	3-8
Axle Assembly Replacement.....	3-15
Axle Assembly Removal .....	3-15
Axle Assembly Installation .....	3-19
Steering Wheel Replacement.....	3-23
Steering Wheel Removal .....	3-23
Steering Wheel Installation .....	3-24
Steering Shaft Replacement.....	3-25
Steering Shaft Removal .....	3-25
Steering Shaft Installation .....	3-27
Electric PTO Clutch Replacement.....	3-29
Electric PTO Clutch Removal.....	3-29
Electric PTO Clutch Installation.....	3-30
Fuel Tank Replacement.....	3-32
Fuel Tank Removal .....	3-32
Fuel Tank Installation .....	3-33
Hood Replacement.....	3-34
Hood Removal .....	3-34
Hood Installation .....	3-34
Fender Replacement.....	3-35
Fender Removal .....	3-35
Fender Installation .....	3-41
Tower Replacement.....	3-46
Tower Removal .....	3-46
Tower Installation .....	3-55
Throttle Cable Replacement.....	3-65
Throttle Cable Removal .....	3-65
Throttle Cable Installation .....	3-70
Choke Cable Replacement.....	3-74
Choke Cable Removal .....	3-74
Choke Cable Installation .....	3-77
Deck Lift Link Replacement.....	3-81
Deck Lift Link Removal .....	3-81
Deck Lift Link Installation .....	3-83
Deck Lift Cable Replacement.....	3-85
Deck Lift Cable Removal .....	3-85
Deck Lift Cable Installation .....	3-89

# TABLE OF CONTENTS

---

## CHASSIS cont.

Deck Lift Handle & Shaft Assembly Replacement.....	3-93
Deck Lift Handle & Shaft Assembly Removal .....	3-93
Deck Lift Handle & Shaft Assembly Installation .....	3-97
Front Wheel Toe-In Measurement & Adjustment.....	3-101

## ENGINE

Engine Replacement .....	4-1
Engine Removal.....	4-1
Engine Installation.....	4-6
Throttle & Choke Cable Adjustment .....	4-10

## GEAR DRIVE SYSTEM

Transmission Drive Belt Replacement .....	5-1
Transmission Drive Belt Removal .....	5-1
Transmission Drive Belt Installation .....	5-3
Variable Speed Drive Belt Replacement .....	5-5
Variable Speed Drive Belt Removal .....	5-5
Variable Speed Drive Belt Installation .....	5-7
CVT Transmission Replacement.....	5-10
CVT Transmission Removal.....	5-10
CVT Transmission Installation.....	5-16
CVT Transmission Service .....	5-22
CVT Transmission Housing Teardown .....	5-22
Differential Axle Assembly Service.....	5-28
Drive Shaft Assembly Service.....	5-29
Right Hand Output Shaft Assembly Service .....	5-34
CVT Transmission Housing Rebuild .....	5-38
Variable Speed Pulley Service .....	5-44
Brake Puck Replacement.....	5-47
Brake Puck Removal .....	5-47
Brake Puck Installation .....	5-49
Brake Adjustment .....	5-52
Autodrive Pedal Adjustment .....	5-53

## HYDROSTATIC DRIVE SYSTEM

Transmission Drive Belt Replacement .....	6-1
Transmission Drive Belt Removal .....	6-1
Transmission Drive Belt Installation .....	6-3
Hydrostatic Transmission Replacement .....	6-6
Hydrostatic Transmission Removal.....	6-6
Hydrostatic Transmission Installation.....	6-13
Purging the System .....	6-20
Fluid Change .....	6-21
Neutral Adjustment .....	6-22
Brake Puck Replacement.....	6-24
Brake Puck Removal .....	6-24
Brake Puck Installation .....	6-27
Parking Brake Adjustment .....	6-30

# TABLE OF CONTENTS

## MOWER DECK

50" Mower Deck Belt Replacement .....	7-1
50" Mower Deck Belt Removal .....	7-1
50" Mower Deck Belt Installation .....	7-2
50" Mower Deck Fixed Idler Replacement .....	7-4
50" Mower Deck Fixed Idler Removal.....	7-4
50" Mower Deck Fixed Idler Installation.....	7-5
50" Mower Deck Removal .....	7-6
50" Mower Deck Installation .....	7-8
50" Mower Deck Spindle Replacement .....	7-10
50" Mower Deck Spindle Removal.....	7-10
50" Mower Deck Spindle Installation.....	7-12
50" Mower Deck Spindle Service .....	7-13
50" Mower Deck Spring Loaded Idler Replacement.....	7-17
50" Mower Deck Spring Loaded Idler Removal .....	7-17
50" Mower Deck Spring Loaded Idler Installation .....	7-20
54" Mower Deck Belt Replacement .....	7-23
54" Mower Deck Belt Removal .....	7-23
54" Mower Deck Belt Installation .....	7-25
54" Mower Deck Fixed Idler Replacement .....	7-26
54" Mower Deck Fixed Idler Removal.....	7-26
54" Mower Deck Fixed Idler Installation.....	7-28
54" Mower Deck Removal .....	7-29
54" Mower Deck Installation .....	7-31
54" Mower Deck Roller Replacement.....	7-34
54" Mower Deck Roller Removal .....	7-34
54" Mower Deck Roller Installation .....	7-36
54" Mower Deck Roller Adjustment.....	7-38
54" Mower Deck Spindle Replacement .....	7-38
54" Mower Deck Spindle Removal.....	7-38
54" Mower Deck Spindle Installation.....	7-40
54" Mower Deck Spindle Service .....	7-41
54" Mower Deck Spring Loaded Idler Replacement.....	7-45
54" Mower Deck Spring Loaded Idler Removal .....	7-45
54" Mower Deck Spring Loaded Idler Installation .....	7-47
Mower Deck Pulley Replacement (50" & 54" Mower Decks).....	7-49
Mower Deck Pulley Removal .....	7-49
Mower Deck Pulley Installation .....	7-50

## Electrical

Electrical System .....	8-1
GT2100, GT2200, GT2300 Wiring Diagram.....	8-2
GT2100, GT2200, GT2300 Wiring Diagram cont. ....	8-3

# **TABLE OF CONTENTS**

---

**THIS PAGE INTENTIONALLY LEFT BLANK.**

## General Information



This symbol means WARNING or PERSONAL SAFETY INSTRUCTION - read the instruction because it has to do with your safety. Failure to comply with the instruction may result in personal injury or even death.

This manual is intended as a service and repair manual only. The safety instructions provided herein are for troubleshooting, service, and repair of the GT2000 Series Lawn & Garden Tractors.

The GT2000 Series tractor operator's manual contains safety information and operating tips for safe operating practices. Operator's manuals are available online at [www.toro.com](http://www.toro.com) or:

**The Toro Company  
Publications Department  
8111 Lyndale Avenue South  
Bloomington, MN 55420**

## Think Safety First

### Avoid unexpected starting of engine...

Always turn off the engine and disconnect the spark plug wire(s) before cleaning, adjusting, or repair.

### Avoid lacerations and amputations...

Stay clear of all moving parts whenever the engine is running. Treat all normally moving parts as if they were moving whenever the engine is running or has the potential to start.

### Avoid burns...

Do not touch the engine, muffler, or other components which may increase in temperature during operation, while the unit is running or shortly after it has been running.

### Avoid fires and explosions...

Avoid spilling fuel and never smoke while working with any type of fuel or lubricant. Wipe up any spilled fuel or oil immediately. Never remove the fuel cap or add fuel when the engine is running. Always use approved, labeled containers for storing or transporting fuel and lubricants.

### Avoid asphyxiation...

Never operate an engine in a confined area without proper ventilation.

### Avoid injury from batteries...

Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes, and clothing. Battery gases can explode. Keep cigarettes, sparks, and flames away from the battery.

### Avoid injury due to inferior parts...

Use only original equipment parts to ensure that important safety criteria are met.

### Avoid injury to bystanders...

Always clear the area of bystanders before starting or testing powered equipment.

### Avoid injury due to projectiles...

Always clear the area of sticks, rocks, or any other debris that could be picked up and thrown by the powered equipment.

### Avoid modifications...

Never alter or modify any part unless it is a factory approved procedure.

### Avoid unsafe operation...

Always test the safety interlock system after making adjustments or repairs on the machine. Refer to the Electrical section in this manual for more information.



# SAFETY INFORMATION

---

1

## Hydraulics Safety

- Inspect all hydraulic line connectors and fittings. Make sure all hydraulic hoses and lines are in good condition before applying pressure to the system.
- Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Hydraulic fluid escaping under pressure can penetrate the skin and cause injury. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor or gangrene may occur.
- Before disconnecting or performing any work on the hydraulic system, lower the loader arm/attachment to the ground and stop the engine so all pressure is relieved.
- Be sure you understand a service procedure before working on the machine.

## Torque Specifications


Recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in the service manual.

These torque specifications for the installation and tightening of fasteners shall apply to all fasteners which do not have a specific requirement identified in the service manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature, hardness of the surface underneath of the fastener's head, or similar condition which affects the installation.


As noted in the following tables, torque values should be **reduced by 25% for lubricated fasteners** to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

### Fastener Identification



Inch Series Bolts and Screws	
(A) Grade 1 (B) Grade 5	(C) Grade 8



Metric Bolts and Screws	
(A) Class 8.8	(B) Class 10.9

# SPECIFICATIONS

## Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series)

Thread Size	Grade 1, 5, & 8 with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 5 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 8 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)	
		In-lb	In-lb	N-cm	In-lb	N-cm	In-lb
# 6 - 32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	170 ± 20	23 ± 2	260 ± 20
# 6 - 40 UNF				17 ± 2	190 ± 20	25 ± 2	280 ± 20
# 8 - 32 UNC	13 ± 2	25 ± 5	282 ± 30	29 ± 3	330 ± 30	41 ± 4	460 ± 45
# 8 - 36 UNF				31 ± 3	350 ± 30	43 ± 4	31 ± 3
# 10 - 24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 4	475 ± 45	60 ± 6	674 ± 70
#10 - 32 UNF				48 ± 4	540 ± 45	68 ± 6	765 ± 70
1/4 - 20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1125 ± 100	140 ± 15	1580 ± 170
1/4 - 28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 10	1300 ± 100	160 ± 15	1800 ± 170
5/16 - 18 UNC	115 ± 15	105 ± 17	1186 ± 169	200 ± 25	2250 ± 280	300 ± 30	3390 ± 340
5/16 - 24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2540 ± 280	325 ± 30	3670 ± 340
	<b>ft-lb</b>	<b>ft-lb</b>	<b>N-m</b>	<b>ft-lb</b>	<b>N-m</b>	<b>ft-lb</b>	<b>N-m</b>
3/8 - 16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 4	58 ± 5
3/8 - 24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 3	47 ± 4	50 ± 4	68 ± 5
7/16 - 14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	68 ± 9
7/16 - 20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 5	75 ± 7	77 ± 7	104 ± 9
1/2 - 13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 10	142 ± 14
1/2 - 20 UNF	32 ± 3	53 ± 7	72 ± 9	85 ± 8	115 ± 11	120 ± 10	163 ± 14
5/8 - 11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 20	285 ± 27
5/8 - 18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 15	230 ± 20	240 ± 20	325 ± 27
3/4 - 10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 25	359 ± 34	374 ± 35	508 ± 47
3/4 - 16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 25	407 ± 34	420 ± 35	569 ± 47
7/8 - 9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8 - 14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 45	644 ± 61	660 ± 60	895 ± 81

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

**Note:** Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

**Note:** The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

# SPECIFICATIONS

2

## Standard Torque for Dry, Zinc and Steel Fasteners (Metric Series)

Thread Size	Class 8.8 Bolts, Screws, and Studs with Regular Height Nuts (Class 8 or Strong Nuts)		Class 10.9 Bolts, Screws, and Studs with Regular Height Nuts (Class 10 or Strong Nuts)	
<b>M5 X 0.8</b>	57 ± 5 in-lb	640 ± 60 N-cm	78 ± 7 in-lb	885 ± 80 N-cm
<b>M6 X 1.0</b>	96 ± 9 in-lb	1018 ± 100 N-cm	133 ± 13 in-lb	1500 ± 150 N-cm
<b>M8 X 1.25</b>	19 ± 2 ft-lb	26 ± 3 N-m	27 ± 2 ft-lb	36 ± 3 N-m
<b>M10 X 1.5</b>	38 ± 4 ft-lb	52 ± 5 N-m	53 ± 5 ft-lb	72 ± 7 N-m
<b>M12 X 1.75</b>	66 ± 7 ft-lb	90 ± 10 N-m	92 ± 9 ft-lb	125 ± 12 N-m
<b>M16 X 2.0</b>	166 ± 15 ft-lb	225 ± 20 N-m	229 ± 22 ft-lb	310 ± 30 N-m
<b>M20 X 2.5</b>	325 ± 33 ft-lb	440 ± 45 N-m	450 ± 37 ft-lb	610 ± 50 N-m

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

**Note:** The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

**Note:** Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

# SPECIFICATIONS

## Other Torque Specifications

### SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 - 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 - 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
3/8 - 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb
1/2 - 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb

### Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 - 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N-m
1/2 - 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m

\*\* For steel wheels and non-lubricated fasteners.

### Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23, or Type F	
Thread Size	Baseline Torque*
No. 6 - 32 UNC	20 ± 5 in-lb
No. 8 - 32 UNC	30 ± 5 in-lb
No.10 - 24 UNC	38 ± 7 in-lb
1/4 - 20 UNC	85 ± 15 in-lb
5/16 - 18 UNC	110 ± 20 in-lb
3/8 - 16 UNC	200 ± 100 in-lb

### Thread Cutting Screws (Zinc Plated Steel)

Thread Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

\* Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

### Conversion Factors

$$\begin{aligned} \text{in-lb} \times 11.2985 &= \text{N-cm} \\ \text{ft-lb} \times 1.3558 &= \text{N-m} \end{aligned}$$

$$\begin{aligned} \text{N-cm} \times 0.08851 &= \text{in-lb} \\ \text{N-cm} \times 0.73776 &= \text{ft-lb} \end{aligned}$$

# SPECIFICATIONS

2

## Equivalents and Conversions

### Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm
1/64	0.015625	0.397	33/64	0.515625	13.097
1/32	0.03125	0.794	16/32	0.53125	13.484
3/64	0.046875	1.191	35/64	0.546875	13.891
1/16	0.0625	1.588	9/16	0.5625	14.288
5/64	0.078125	1.984	37/64	0.578125	14.684
3/32	0.9375	2.381	19/32	0.59375	15.081
1/8	0.1250	3.175	5/8	0.6250	15.875
9/64	0.140625	3.572	41/64	0.640625	16.272
5/32	0.15625	3.969	21/32	0.65625	16.669
11/64	0.171875	4.366	43/64	0.671875	17.066
3/16	0.1875	4.762	11/16	0.6875	17.462
13/64	0.203125	5.159	45/64	0.703125	17.859
7/32	0.21875	5.556	23/32	0.71875	18.256
15/64	0.234375	5.953	47/64	0.734375	18.653
1/4	0.2500	6.350	3/4	0.7500	19.050
17/64	0.265625	6.747	49/64	0.765625	19.447
9/32	0.28125	7.144	25/32	0.78125	19.844
19/64	0.296875	7.541	51/64	0.796875	20.241
5/16	0.3125	7.541	13/16	0.8125	20.638
21/64	0.328125	8.334	53/64	0.828125	21.034
11/32	0.34375	8.731	27/32	0.84375	21.431
23/64	0.359375	9.128	55/64	0.859375	21.828
3/8	0.3750	9.525	7/8	0.8750	22.225
25/64	0.390625	9.922	57/64	0.890625	22.622
13/32	0.40625	10.319	29/32	0.90625	23.019
27/64	0.421875	10.716	59/64	0.921875	23.416
7/16	0.4375	11.112	15/16	0.9375	23.812
29/64	0.453125	11.509	61/64	0.953125	24.209
15/32	0.46875	11.906	31/32	0.96875	24.606
31/64	0.484375	12.303	63/64	0.984375	25.003
1/2	0.5000	12.700	1	1.000	25.400
1 mm = 0.03937 in.			0.001 in. = 0.0254 mm		

# SPECIFICATIONS

## U.S. to Metric Conversions

	To Convert	Into	Multiply By
<b>Linear Measurement</b>	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
<b>Area</b>	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
<b>Volume</b>	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
<b>Weight</b>	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces	Grams	28.3495
<b>Pressure</b>	Pounds/Sq. In.	Kilopascal	6.895
<b>Work</b>	Foot-pounds	Newton-Meters	1.356
	Foot-pounds	Kilogram-Meters	0.1383
	Inch-pounds	Kilogram-Centimeters	1.152144
<b>Liquid Volume</b>	Quarts	Liters	0.9463
	Gallons	Liters	3.785
<b>Liquid Flows</b>	Gallons/Minute	Liters/Minute	3.785
<b>Temperature</b>	Fahrenheit	Celsius	1. Subtract 32° 2. Multiply by 5/9

# SPECIFICATIONS

## Product Specifications

Name	GT2100	GT2200	GT2300
Engine	23HP Twin Cylinder Kohler Courage	25HP Twin Cylinder Kohler Courage	26HP Twin Cylinder Kohler Courage
High RPM Setting	3375		
Low RPM Setting	1200 ± 75		
Construction	12 Gauge Steel Frame		
Fuel Capacity	3.0 gallons (11.4 liters)		
Wheel Base	46.0" (116.8cm)		
Overall Length	68.0" (172.7cm)		
Overall Width	54.0" (137.2cm)	54.0" (137.2cm)	60.0" (152.4cm)
Overall Height	43.0" (109.2cm)		
Weight (approx.)	575 lbs. (261kg)	575 lbs. (261kg)	675 lbs. (306kg)
Traction System	CVT 2-Speed Transaxle	Hydro-Gear 3000 Series Transaxle	Hydro-Gear 3000 Series Transaxle
Forward Ground Speed	0 – 5.2 mph (8.2 km/h)		
Reverse Ground Speed	0 – 2.3 mph (3.7 km/h)		
Front Tires	16 x 7.5 x 8		
Rear Tires	23 x 10.5 x 12		
Tire Pressure (Front/Rear)	14 psi/10 psi (97kPa/68kPa)		
Turning Radius	21" (53.3cm)		
Electrical System	Voltage: 12 volt negative ground Battery: 245CCA (sealed) Alternator: 15 amp regulated Fuse: 20 amp		
Mower Deck	50" (127cm) Three Blade 12 Gauge Steel (2.7mm)	50" (127cm) Three Blade 12 Gauge Steel (2.7mm)	54" (138cm) Three Blade 12 Gauge Steel (2.7mm)
Height-of-Cut	1.5" to 4" (3.8 to 10cm)		

2



# SPECIFICATIONS

---

**2**

**THIS PAGE INTENTIONALLY LEFT BLANK.**

## Front Pivot Axle Replacement

### Front Pivot Axle Removal

1. Disconnect the negative and then the positive battery cable.
2. Remove the mower deck. Refer to:
  - "50" Mower Deck Removal" on page 7-6
  - "54" Mower Deck Removal" on page 7-29
3. Remove the 2 hairpin cotters and clevis pins securing the deck hanger bracket to the frame (Fig. 001).



Fig 001

PICT-7204a

4. Remove the deck hanger bracket and rod assembly from the frame (Fig. 002).



Fig 002

PICT-7206

5. Raise the hood (Fig. 003).



Fig 003

PICT-7207

# CHASSIS

6. Unplug the headlights from the wire harness (Fig. 004).



Fig 004

PICT-7210

7. Remove the hood from the frame (Fig. 005).



Fig 005

PICT-7212

8. Apply the parking brake.
9. Lift and secure the front end of the machine so the front axle can be accessed.
10. Remove the hubcaps from both front wheels (Fig. 006).



Fig 006

PICT-7214

11. Remove and discard the cotter pin from the 2 axles (Fig. 007).



Fig 007

PICT-7216a

12. Remove the washers from the 2 axles (Fig. 008).



Fig 008

PICT-7217a

**Note:** There is an inner and an outer bushing included with the wheel assembly:

Inner bushing (Fig. 010):



Fig 010

PICT-7219a

13. Remove the wheels from the axles (Fig. 009).



Fig 009

PICT-7218

Outer bushing (Fig. 011):



Fig 011

PICT-7220a

# CHASSIS

14. Remove the nut securing the ball joint to the axle assembly (Fig. 012).



Fig 012

PICT-7222

16. Remove the cap from the axle assembly (Fig. 014).



Fig 014

PICT-7226

3

15. Remove the ball joint from the axle assembly (Fig. 013).



Fig 013

PICT-7225

17. Remove the push nut from the axle assembly (Fig. 015).



Fig 015

PICT-7228

18. Remove the axle assembly from the front pivot axle (Fig. 016).



Fig 016

PICT-7230

19. Repeat steps 13 - 18 to remove the axle assembly from the opposite side of the pivot axle.

20. Remove the harness clip from the frame (Fig. 017).



Fig 017

PICT-7236

21. Support the front pivot axle with jackstands.

22. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 018).




Fig 018

PICT-7245

23. Remove the bumper (Fig. 019).



Fig 019

PICT-7249

# CHASSIS

24. Remove the 4 screws securing the left and right side bumper brackets to the muffler bracket (2 on the left and 2 on the right) (Fig. 020).



Fig 020

PICT-7250

26. Remove the 4 bolts (2 on the right, 2 on the left) securing the left and right pivot supports to the frame (Fig. 022).




Fig 022

PICT-7243

3

25. Slide the muffler and heat shield assembly off the manifold pipes (Fig. 021).



Fig 021

PICT-7252

27. Remove the nuts from the bolts securing the pivot bar and pivot support brackets to the frame (Fig. 023).




Fig 023

PICT-7258

28. Unthread and remove one of the bolts and pivot supports from the pivot axle and frame (Fig. 024).



Fig 024

PICT-7262

30. Remove the pivot bar bracket from the frame (Fig. 026).



Fig 026

PICT-7265

29. Unthread and remove the other bolt and pivot support from the pivot axle and frame (Fig. 025).



Fig 025

PICT-7264

31. Remove the front pivot axle (Fig. 027).



Fig 027

PICT-7266



# CHASSIS

## Front Pivot Axle Installation

1. Position and support the front pivot axle to the frame.

**Note:** The grease fittings should face forward (Fig. 028).



Fig 028

PICT-7266

2. Position the pivot bar bracket onto the frame (Fig. 029).



Fig 029

PICT-7265

3. Position the pivot support to the frame and loosely install a bolt through the pivot support, pivot bracket and pivot axle (Fig. 030).



Fig 030

PICT-7268

4. Position the other pivot support bracket to the frame and loosely install the other bolt through the pivot support, pivot bracket and pivot axle (Fig. 031).



Fig 031

PICT-7270

5. Loosely install a nut onto each of the bolts securing the pivot support bracket and pivot bar bracket to the frame (Fig. 032).




Fig 032

PICT-7258

7. Tighten the 2 nuts and bolts securing the pivot support bracket and axle pivot bar to the frame (Fig. 034).




Fig 034

PICT-7271

6. Install 4 bolts securing the left and right pivot supports to the frame (2 on the right, 2 on the left) (Fig. 033).




Fig 033

PICT-7243

8. Slide the muffler and heat shield assembly onto the manifold pipes and position it to the frame (Fig. 035).



Fig 035

PICT-7273

# CHASSIS

9. Install 4 screws securing the left and right side pivot support brackets to the muffler/heat shield assembly (2 on the left and 2 on the right) (Fig. 036).



Fig 036

PICT-7250

11. Install 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 038).




Fig 038

PICT-7245

10. Position the bumper (Fig. 037).



Fig 037

PICT-7249

12. Install the harness clip into the frame (Fig. 039).



Fig 039

PICT-7236

13. Slide the axle assemblies into the front pivot axle (Fig. 040).



Fig 040

PICT-7230

15. Install a nut onto each ball joint securing the ball joints to the axle assembly (Fig. 042).



Fig 042

PICT-7276

14. Position the ball joints into the axle assembly (Fig. 041).



Fig 041

PICT-7225

16. Slide the wheel assemblies onto the axles (Fig. 043).



Fig 043

PICT-7277

# CHASSIS

**Note:** There is an inner and an outer bushing included with the wheel assembly:

Inner bushing (Fig. 044):



Fig 044

PICT-7219a

Outer bushing (Fig. 045):



Fig 045

PICT-7220a

17. Install a washer onto each axle (Fig. 046).



Fig 046

PICT-7217a

18. Install a new cotter pin into each axle to secure the wheel (Fig. 047).



Fig 047

PICT-7280a

19. Install a hubcap onto the 2 wheel assemblies (Fig. 048).



Fig 048

PICT-7214

22. Position the hood onto the hood support brackets (Fig. 050).



Fig 050

PICT-7212

20. Lower the front end of the machine to the ground.

21. Install push nut caps onto each of the axle assemblies (Fig. 049).



Fig 049

PICT-7282

23. Plug the headlights into the wire harness (Fig. 051).



Fig 051

PICT-7210

# CHASSIS

24. Lower the hood (Fig. 052).



Fig 052

PICT-7207

25. Apply grease to the axle pivot bar grease fittings and to the bushings on the inside of the wheel assembly (Fig. 053 and Fig. 054).



Fig 053

PICT-7286



Fig 054

PICT-7288a

26. Position the deck hanger bracket and rod assembly to the frame (Fig. 055).



Fig 055

PICT-7206

27. Install 2 clevis pins and hairpins to secure the deck hanger bracket to the frame (Fig. 056).



Fig 056

PICT-7204

28. Install the mower deck. Refer to:
- “50” Mower Deck Installation” on page 7-8
  - “54” Mower Deck Installation” on page 7-31
29. Connect the negative and the positive battery cable.

## Axle Assembly Replacement

**Note:** The following procedure is the same for right side and left side axle assembly replacement.

**Note:** The following procedures were done with the mower deck removed. It is not required that the mower deck be removed.

## Axle Assembly Removal

1. Disconnect the negative and then the positive battery cable.
2. Raise the hood (Fig. 057).



Fig 057

PICT-7207



# CHASSIS

3. Unplug the headlights from the wire harness (Fig. 058).



Fig 058

PICT-7210

4. Remove the hood from the frame (Fig. 059).



Fig 059

PICT-7212

5. Apply the parking brake.
6. Lift and secure the front end of the machine so the front axle can be accessed.
7. Remove the hubcap from the front wheel (Fig. 060).



Fig 060

PICT-7214

8. Remove and discard the cotter pin from the axle (Fig. 061).



Fig 061

PICT-7216a

9. Remove the washer from the axle (Fig. 062).



Fig 062

PICT-7217a

**Note:** There is an inner and an outer bushing included with the wheel assembly:

Inner bushing (Fig. 064):



Fig 064

PICT-7219a

10. Remove the wheel assembly from the axle (Fig. 063).



Fig 063

PICT-7218

Outer bushing (Fig. 065):



Fig 065

PICT-7220a

# CHASSIS

11. Remove the nut securing the ball joint to the axle assembly (Fig. 066).



Fig 066

PICT-7222

13. Remove the cap from the axle assembly (Fig. 068).



Fig 068

PICT-7226

3

12. Remove the ball joint from the axle assembly (Fig. 067).



Fig 067

PICT-7225

14. Remove the push nut from the axle assembly (Fig. 069).



Fig 069

PICT-7228

15. Remove the axle assembly from the front pivot axle (Fig. 070).



Fig 070

PICT-7230

2. Position the ball joint into the axle assembly (Fig. 072).



Fig 072

PICT-7225

## Axle Assembly Installation

1. Slide the axle assembly into the front pivot axle (Fig. 071).



Fig 071

PICT-7230

3. Install a nut onto the ball joint securing it to the axle assembly (Fig. 073).



Fig 073

PICT-7276

# CHASSIS

4. Slide the wheel assembly onto the axle (Fig. 074).



Fig 074

PICT-7277

Outer bushing (Fig. 076):



Fig 076

PICT-7220

**Note:** There is an inner and an outer bushing included with the wheel assembly:

Inner bushing (Fig. 075):



Fig 075

PICT-7219a

5. Install a washer onto the axle (Fig. 077).



Fig 077

PICT-7217a

6. Install a new cotter pin into the axle to secure the wheel (Fig. 078).



Fig 078

PICT-7280a

7. Install a hubcap onto the wheel assembly (Fig. 079).



Fig 079

PICT-7214

8. Lower the front end of the machine to the ground.
9. Install a push nut cap onto the axle assembly (Fig. 080).



Fig 080

PICT-7282

10. Position the hood onto the hood support brackets (Fig. 081).



Fig 081

PICT-7212

# CHASSIS

11. Plug the headlights into the wire harness (Fig. 082).



Fig 082

PICT-7210

13. Apply grease to the axle pivot bar grease fittings and to the bushings on the inside of the wheel assembly (Fig. 084 and Fig. 085).



Fig 084

PICT-7286

12. Lower the hood (Fig. 083).



Fig 083

PICT-7207



Fig 085

PICT-7288a

## Steering Wheel Replacement

### Steering Wheel Removal

1. Remove the steering wheel cover (Fig. 086).



Fig 086

PICT-7290

2. Remove the screw securing the steering wheel to the steering shaft (Fig. 087).



Fig 087

PICT-7323a

3. Remove the washer from the steering wheel (Fig. 088).



Fig 088

PICT-7292

4. Remove the steering wheel from the steering shaft (Fig. 089).



Fig 089

PICT-7295a



# CHASSIS

## Steering Wheel Installation

1. Slide the steering wheel onto the steering shaft (Fig. 090).



Fig 090

PICT-7295a

3. Install a screw to secure the steering wheel to the steering shaft (Fig. 092).



Fig 092

PICT-7323a

2. Place a washer into the steering wheel (Fig. 091).



Fig 091

PICT-7296

4. Install the steering wheel cover (Fig. 093).



Fig 093

PICT-7290

## Steering Shaft Replacement

### Steering Shaft Removal

1. Remove the steering wheel. Refer to “Steering Wheel Removal” on page 3-23.
2. Raise the hood (Fig. 094).



Fig 094

PICT-7298

3. Remove the mower deck. Refer to:
  - “50” Mower Deck Removal” on page 7-6
  - “54” Mower Deck Removal” on page 7-29

4. Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Slide the fuel line back onto the fuel filter and position the hose clamp to secure. Replace the fuel cap onto the fuel tank (Fig. 095).



Fig 095

PICT-7300

5. Loosen the 2 screws securing the fuel tank support rods to the dash supports. Lay the support rods to the side (Fig. 096).



Fig 096

PICT-7303

# CHASSIS

6. Lift the fuel tank out of the tower (Fig. 097).



Fig 097

PICT-7304a

9. Remove the pinion from the steering shaft (Fig. 099).



Fig 099

PICT-7308

7. Raise and support the machine to access the steering gear assembly.
8. Secure the steering gear in place with a punch and remove the nut from the end of the steering shaft (Fig. 098).



Fig 098

PICT-7306

10. Push up on the steering shaft and remove the washer from the end of the steering shaft (Fig. 100).



Fig 100

PICT-7319

11. Lower the machine.
12. Pull the steering shaft up and out of the hex flange bearing. Angle the steering shaft between the pedal levelers and lower it out of the tower (Fig. 101).



Fig 101

PICT-7310

## Steering Shaft Installation

1. Install the hex flange bushing into the steering support bracket ensuring the hex is seated in the bracket (Fig. 103).



Fig 103

PICT-7315

13. Remove the hex flange bushing from the steering shaft support bracket (Fig. 102).

**Note: Inspect the hex flange bushing and replace it if worn or damaged.**



Fig 102

PICT-7312

2. Slide the steering shaft up into the tower from below. Insert the lower end of the steering shaft into the hex flange bushing (Fig. 104).



Fig 104

PICT-7310

# CHASSIS

3. Raise the machine to access the steering gear assembly.
4. Push up on the steering shaft to install a washer onto the steering shaft (Fig. 105).

**Note:** The washer is installed above the steering gear.



Fig 105

PICT-7319

5. Slide the pinion onto the steering shaft (Fig. 106).



Fig 106

PICT-7308

6. Loosely install a nut onto the steering shaft. Secure the steering gear in place with a punch and tighten the nut (Fig. 107).



Fig 107

PICT-7306

7. Grease the pinion gear with #2 general purpose grease (Fig. 108).



Fig 108

PICT-7321

8. Lower the machine.
9. Position the fuel tank into the tower (Fig. 109).



Fig 109

PICT-7304a

10. Position the 2 fuel tank support rods and install a screw securing each support rod to the dash supports (Fig. 110).



Fig 110

PICT-7303

11. Install the steering wheel. Refer to "Steering Wheel Installation" on page 3-24.

## Electric PTO Clutch Replacement

### Electric PTO Clutch Removal

1. Remove the mower deck. Refer to:
  - "50" Mower Deck Removal" on page 7-6
  - "54" Mower Deck Removal" on page 7-29
2. Unplug the clutch from the wire harness (Fig. 111).



Fig 111

PICT-7329

3. Raise the machine so the electric PTO clutch can be accessed.
4. Route the clutch connector out through the slot in the frame.

# CHASSIS

5. Remove the bolt and lock washer securing the clutch to the crankshaft (Fig. 112).



Fig 112

PICT-7331

6. Remove the clutch and spacer(s) from the crankshaft (Fig. 113).



Fig 113

PICT-7335a

## Electric PTO Clutch Installation

1. Apply anti-seize compound to the crankshaft (Fig. 114).



Fig 114

PICT-7343

2. Position the spacer(s) on the top side of the clutch (Fig. 115).



Fig 115

PICT-7345a

3. Align the clutch keyway with the key on the crankshaft and slide the clutch and spacer assembly onto the crankshaft (Fig. 116).



Fig 116

PICT-7335a

4. Install a bolt and lock washer securing the clutch to the crankshaft. Torque the bolt to 37.5 to 50 ft-lbs. (50.84 to 67.79 Nm) (Fig. 117).




Fig 117

PICT-7346

5. Route the clutch connector through the slot in the frame.
6. Lower the machine.
7. Plug the clutch into the wire harness (Fig. 118).



Fig 118

PICT-7329

8. Install the mower deck. Refer to:
  - "50" Mower Deck Installation" on page 7-8
  - "54" Mower Deck Installation" on page 7-31



# CHASSIS

## Fuel Tank Replacement

### Fuel Tank Removal

1. Raise the hood (Fig. 119).



Fig 119

PICT-7298

2. Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Replace the fuel cap onto the fuel tank (Fig. 120).



Fig 120

PICT-7300

3. Loosen the 2 screws securing the fuel tank support rods to the dash supports. Lay the support rods to the side (Fig. 121).



Fig 121

PICT-7303

4. Lift the fuel tank out of the tower (Fig. 122).



Fig 122

PICT-7304a

## Fuel Tank Installation

1. Position the fuel tank into the tower (Fig. 123).



Fig 123

PICT-7304a

2. Position the 2 fuel tank support rods and install a screw securing each support rod to the dash supports (Fig. 124).



Fig 124

PICT-7303

3. Slide the fuel line back onto the fuel filter and position the hose clamp to secure (Fig. 125).



Fig 125

PICT-7300

4. Lower the hood (Fig. 126).



Fig 126

PICT-7207

# CHASSIS

## Hood Replacement

### Hood Removal

1. Raise the hood (Fig. 127).



Fig 127

PICT-7207

2. Unplug the headlights from the wire harness (Fig. 128).



Fig 128

PICT-7210

3. Remove the hood from the frame (Fig. 129).



Fig 129

PICT-7212

### Hood Installation

1. Position the hood onto the hood support brackets (Fig. 130).



Fig 130

PICT-7212

2. Plug the headlights into the wire harness (Fig. 131).



Fig 131

PICT-7210

3. Lower the hood (Fig. 132).



Fig 132

PICT-7207

## Fender Replacement

### Fender Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 133).



Fig 133

PICT-7349

3. Disconnect the battery cable from the positive battery terminal (Fig. 134).



Fig 134

PICT-7351a

# CHASSIS

4. Remove the battery hold down rod (Fig. 135).



Fig 135

PICT-7352

6. Remove the battery tray (Fig. 137).



Fig 137

PICT-7354

5. Remove the battery from the battery tray (Fig. 136).



Fig 136

PICT-7353

7. Unplug the 2 seat switch wires (Fig. 138).



Fig 138

PICT-7357

3

- Loosen the bolt and nut securing the left seat mount bracket to the seat bracket (Fig. 139).



Fig 139

PICT-7358

- Remove the 4 bolts securing the seat mount brackets to the fender (Fig. 141).



Fig 141

PICT-7363

- Using a spring tool (Toro part no. 92-5771), release the extension spring from the seat mount bracket (Fig. 140).



Fig 140

PICT-7359

- Remove the seat (Fig. 142).



Fig 142

PICT-7364

# CHASSIS

12. Remove the height-of-cut grip from the height-of-cut lever (Fig. 143).



Fig 143 PICT-7391

14. Remove the carriage bolt, washer and nut securing the fender to the frame (Fig. 145).



Fig 145 PICT-7369

13. Pry up the front portion of the left hand foot pad (Fig. 144).



Fig 144 PICT-7367

15. Pry up the front portion of the right hand foot pad (Fig. 146).



Fig 146 PICT-7372

3

16. Remove the carriage bolt, washer and nut securing the fender to the frame (Fig. 147).



Fig 147

PICT-7373

17. Locate the 2 screws under the danger decal on the fender. Cut the decal to expose the screw heads (Fig. 148).



Fig 148

PICT-7375

18. Remove the 2 screws (Fig. 149).



Fig 149

PICT-7376

19. Remove the fasteners securing the brake pedal lever to the brake control assembly (Fig. 150):

**Note: The foot pad has been removed for photo purposes.**




Fig 150

PICT-7378

- A. TORX screw and washer
- B. Hex head bolt and lock washer



# CHASSIS

20. Remove the brake pedal (Fig. 151).



Fig 151

PICT-7379

22. Remove the speed control pedal (Fig. 153).



Fig 153

PICT-7383

21. Remove the 2 bolts securing the speed control lever to the speed control assembly (Fig. 152).



Fig 152

PICT-7381

23. Remove the fender (Fig. 154).



Fig 154

PICT-7386

3

## Fender Installation

1. Position the fender onto the frame (Fig. 155).



Fig 155

PICT-7386

2. Position the speed control pedal to the speed control assembly (Fig. 156).



Fig 156

PICT-7383

3. Install 2 bolts securing the speed control lever to the speed control assembly (Fig. 157).



Fig 157

PICT-7381

4. Position the brake pedal to the brake control assembly (Fig. 158).



Fig 158

PICT-7379

# CHASSIS

5. Install fasteners securing the brake pedal to the brake control assembly (Fig. 159):

**Note:** The foot pad has been removed for photo purposes.




Fig 159

PICT-7378

- A. TORX screw and washer
- B. Hex head bolt and lock washer

6. Install 2 screws located under the danger decal on the frame (Fig. 160).



Fig 160

PICT-7376

7. Apply a replacement danger decal (Fig. 161).



Fig 161

PICT-7991

8. Lift the right hand foot pad and install the carriage bolt, washer and nut securing the right fender to the frame (Fig. 162).



Fig 162

PICT-7373

9. Lift the left foot pad and install a carriage bolt, washer and nut securing the fender to the frame (Fig. 163).



Fig 163

PICT-7369

10. Slide the height-of-cut grip onto the height-of-cut lever (Fig. 164).



Fig 164

PICT-7391

11. Position the seat assembly onto the fender (Fig. 165).



Fig 165

PICT-7392

12. Install 3 of the 4 bolts securing the seat mount brackets to the fender as shown (Fig. 166).




Fig 166

PICT-7396

# CHASSIS

13. Install the 4th bolt and external lock washer securing the seat mount brackets to the fender (Fig. 167).



Fig 167

PICT-7397

15. Tighten the bolt and nut securing the left seat mount bracket to the seat bracket (Fig. 169).



Fig 169

PICT-7358

14. Using a spring removal tool (Toro part no. 92-5771), install an extension spring onto the seat mount bracket (Fig. 168).



Fig 168

PICT-7359

16. Plug the 2 seat switch wires into the seat switch (Fig. 170).



Fig 170

PICT-7357

17. Position the battery tray into the fender (Fig. 171).



Fig 171

PICT-7354

19. Install the battery hold down rod (Fig. 173).



Fig 173

PICT-7352

18. Place the battery into the battery tray (Fig. 172).



Fig 172

PICT-7353

20. Connect the red battery cable to the positive battery terminal (Fig. 174).



Fig 174

PICT-7351a

# CHASSIS

21. Connect the black battery cable to the negative battery terminal (Fig. 175).



Fig 175

PICT-7349

22. Lower the seat.
23. Operate the tractor to ensure all controls and the seat switch operate properly.

## Tower Replacement

### Tower Removal

1. Remove the fender. Refer to “Fender Removal” on page 3-35.
2. Remove the steering wheel. Refer to “Steering Wheel Removal” on page 3-23.
3. Remove the hood. Refer to “Hood Removal” on page 3-34.
4. Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Replace the fuel cap onto the fuel tank (Fig. 176).



Fig 176

PICT-7300

5. Loosen the 2 screws securing the fuel tank support rods to the dash supports. Lay the support rods to the side (Fig. 177).



Fig 177

PICT-7303

7. Unplug the hour meter from the wire harness (Fig. 179).




Fig 179

PICT-7398

6. Lift the fuel tank out of the tower (Fig. 178).



Fig 178

PICT-7304a

8. Unplug the electric PTO switch plug (Fig. 180).



Fig 180

PICT-7400



# CHASSIS

9. Unplug the wire harness from the ignition module (Fig. 181).



Fig 181

PICT-7401

11. Remove the fuse holder from the tower support by depressing the tabs (Fig. 183).



Fig 183

PICT-7405

10. Unplug the wire harness from the ignition switch (Fig. 182).



Fig 182

PICT-7404

12. Remove the throttle decal from the tower (Fig. 184).



Fig 184

PICT-7407

3

13. Remove the bolt and nut securing the control knob to the throttle assembly (Fig. 185).



Fig 185

PICT-7408

15. Remove the 2 screws securing the throttle assembly to the tower (Fig. 187).



Fig 187

PICT-7410

14. Remove the control knob (Fig. 186).



Fig 186

PICT-7409

16. Pull the throttle assembly out from the rear of the tower (Fig. 188).



Fig 188

PICT-7412

# CHASSIS

17. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 189).




Fig 189

PICT-7245

19. Remove the 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right) (Fig. 191).



Fig 191

PICT-7423

18. Remove the bumper (Fig. 190).



Fig 190

PICT-7417

20. Slide the muffler and heat shield assembly off the manifold pipes (Fig. 192).



Fig 192

PICT-7425

21. Position the throttle in the slow position and fully push the choke in (Fig. 193).



Fig 193

PICT-7426

23. Remove the choke cable from the cable clamp and remove the z-bend from the engine control lever (Fig. 195).



Fig 195

PICT-7433

22. Loosen the TORX screw securing the cable clamp to the engine bracket (Fig. 194).



Fig 194

PICT-7430

24. Remove the nut securing the choke to the tower (Fig. 196).



Fig 196

PICT-7434

# CHASSIS

25. Remove the choke assembly from the tower (Fig. 197).



Fig 197 PICT-7436a

27. Remove the cruise control rod and park brake rod from the levers (Fig. 199).



Fig 199 PICT-7439

26. Remove the hairpins from the cruise control rod and the park brake linkage (Fig. 198).



Fig 198 PICT-7438

28. Remove the 2 screws and washers securing the top of the tower to the top of the support brackets (Fig. 200).



Fig 200 PICT-7446a

3

29. Remove the 2 bolts and 4 screws securing the bottom of the tower to the frame (3 on the left side, 3 on the right side) (Fig. 201).




Fig 201

PICT-7449

31. Remove the 2 screws securing the left tower support to the frame (Fig. 203).



Fig 203

PICT-7470

30. Lift the tower off the frame (Fig. 202).



Fig 202

PICT-7453

32. Remove the left tower support from the frame (Fig. 204).



Fig 204

PICT-7473

# CHASSIS

33. Repeat steps 31 and 32 to remove the right tower support.
34. Remove the hour meter from the tower by squeezing the tabs (Fig. 205).



Fig 205 PICT-7466

35. Remove the ignition switch module from the tower by depressing the 4 tabs (Fig. 206).



Fig 206 PICT-7457

36. Remove the clip from back side of the PTO switch (Fig. 207).



Fig 207 PICT-7458

37. Remove the PTO switch from the tower (Fig. 208).



Fig 208 PICT-7459

38. Remove the screw securing the bent lever rod to the tower (Fig. 209).



Fig 209

PICT-7460

39. Remove the bent lever rod, cruise control lever and parking brake lever from the tower (Fig. 210).



Fig 210

PICT-7461

## Tower Installation

1. Position the bent lever rod, cruise control lever and parking brake lever assembly into the tower (Fig. 211).



Fig 211

PICT-7461

Note the orientation of the levers when installed in the tower (Fig. 212).



Fig 212

PICT-7462



# CHASSIS

2. Install the screw securing the bent lever rod to the tower (Fig. 213).



Fig 213

PICT-7460

- Note the orientation of the PTO switch when installed in the tower (Fig. 215).



Fig 215

PICT-7475

3. Insert the PTO switch into the tower (Fig. 214).



Fig 214

PICT-7459

4. Install the clip onto the back side of the PTO switch (Fig. 216).



Fig 216

PICT-7458

5. Insert the ignition switch module into the tower (Fig. 217).



Fig 217

PICT-7457

7. Position the left tower support onto the frame (Fig. 219).



Fig 219

PICT-7473

6. Install the hour meter into the tower (Fig. 218).




Fig 218

PICT-7466

8. Install 2 screws securing the left tower support to the frame (Fig. 220).



Fig 220

PICT-7470

# CHASSIS

9. Repeat steps 7 and 8 to install the right tower support.

10. Position the tower onto the frame (Fig. 221).



Fig 221

PICT-7453

12. Install 2 screws and washers securing the top of the tower to the top of the support brackets (Fig. 223).



Fig 223

PICT-7446a

11. Install 2 bolts and 4 screws securing the bottom of the tower to the frame (3 on the left side, 3 on the right side) (Fig. 222).




Fig 222

PICT-7449

13. Insert the cruise control rod and park brake rod into the levers (Fig. 224).



Fig 224

PICT-7476

14. Install a hairpin into the cruise control rod and the park brake rod securing them to the levers (Fig. 225).



Fig 225

PICT-7438

16. Route the choke cable around the left side of the engine placing the cable into the R-clamp (Fig. 227) and through the cable tie (Fig. 228).



Fig 227

PICT-7478

15. Insert the choke assembly through the tower (Fig. 226).



Fig 226

PICT-7477



Fig 228

PICT-7479

# CHASSIS

17. Install a nut securing the choke handle to the tower (Fig. 229).



Fig 229

PICT-7481

19. Place the choke cable into the cable clamp (Fig. 231).



Fig 231

PICT-7489

18. Insert the choke cable z-bend into the choke lever on the front of the engine (Fig. 230).



Fig 230

PICT-7488

20. Insert the throttle assembly from the rear of the tower (Fig. 232).



Fig 232

PICT-7412

3

21. Install 2 screws securing the throttle assembly to the tower (Fig. 233).



Fig 233

PICT-7410

23. Install a bolt and nut securing the control knob to the throttle assembly (Fig. 235).



Fig 235

PICT-7491

22. Push the knob onto the throttle control lever (Fig. 234).



Fig 234

PICT-7490

24. Apply a throttle decal onto the tower (Fig. 236).



Fig 236

PICT-7407

# CHASSIS

25. Install the fuse holder into the right hand tower support (Fig. 237).



Fig 237

PICT-7493

27. Plug the wire harness into the ignition module (Fig. 239).



Fig 239

PICT-7401

26. Plug the wire harness into the ignition switch (Fig. 238).



Fig 238

PICT-7404

28. Plug the wire harness into the electric PTO switch (Fig. 240).



Fig 240

PICT-7495

3

29. Plug the wire harness into the hour meter (Fig. 241).




Fig 241

PICT-7398

31. Position the 2 fuel tank support rods and install a screw securing each support rod to the dash supports (Fig. 243).



Fig 243

PICT-7303

30. Position the fuel tank into the tower (Fig. 242).



Fig 242

PICT-7304a

32. Slide the fuel line back onto the fuel filter and position the hose clamp to secure (Fig. 244).



Fig 244

PICT-7300



# CHASSIS

33. Install the steering wheel. Refer to "Steering Wheel Installation" on page 3-24.
34. Install the fender. Refer to "Fender Installation" on page 3-41.
35. Adjust the throttle and choke cables. Refer to "Throttle and Choke Cable Adjustment" on page 4-10.
36. Slide the muffler and heat shield assembly onto the manifold pipes (Fig. 245).

3



Fig 245

PICT-7425

37. Install 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right (Fig. 246).



Fig 246

PICT-7423

38. Position the bumper to the frame (Fig. 247).



Fig 247

PICT-7417

39. Install 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 248).




Fig 248

PICT-7245

40. Install the hood. Refer to "Hood Installation" on page 3-34.
41. Operate the tractor to ensure all controls and the seat switch operate properly.

## Throttle Cable Replacement

### Throttle Cable Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 249).



Fig 249

PICT-7349

# CHASSIS

3. Remove the hood. Refer to "Hood Removal" on page 3-34.
4. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 250).




Fig 250

PICT-7245

6. Remove the 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right) (Fig. 252).



Fig 252

PICT-7423

5. Remove the bumper (Fig. 251).



Fig 251

PICT-7417

7. Slide the muffler and heat shield assembly off the manifold pipes (Fig. 253).



Fig 253

PICT-7425

- Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Replace the fuel cap onto the fuel tank (Fig. 254).



Fig 254

PICT-7300

- Loosen the 2 screws securing the fuel tank support rods to the dash supports. Lay the support rods to the side (Fig. 255).



Fig 255

PICT-7303

- Lift the fuel tank out of the tower (Fig. 256).



Fig 256

PICT-7304a

- Remove the throttle decal from the tower (Fig. 257).



Fig 257

PICT-7407

# CHASSIS

12. Remove the bolt and nut securing the control knob to the throttle assembly (Fig. 258).



Fig 258

PICT-7491

14. Remove the 2 screws securing the throttle assembly to the tower (Fig. 260).



Fig 260

PICT-7410

13. Remove the control knob (Fig. 259).



Fig 259

PICT-7490

15. Pull the throttle assembly out from the rear of the tower (Fig. 261).



Fig 261

PICT-7412

16. Loosen the cable clamp TORX screw securing the throttle and choke cables to the engine bracket (Fig. 262).



Fig 262

PICT-7430

18. Remove the throttle cable assembly from the cable tie and R-clamp located on the left side of the engine (Fig. 264 and Fig. 265).



Fig 264

PICT-7479

17. Remove the throttle cable from the clamp and the z-bend from the engine throttle bracket (Fig. 263).




Fig 263

PICT-7426



Fig 265

PICT-7478

# CHASSIS

## Throttle Cable Installation

1. Slide the throttle cable assembly through the cable tie located on the left front corner of the engine. Place the cable into the R-clamp located on the left rear side of the engine (Fig. 266 and Fig. 267).



Fig 266

PICT-7479

2. Install the throttle cable z-bend into engine throttle bracket and insert it into the cable clamp (Fig. 268).




Fig 268

PICT-7426

3. Insert the throttle assembly into the tower (Fig. 269).



Fig 267

PICT-7478



Fig 269

PICT-7412

4. Install 2 screws to secure the throttle assembly to the tower (Fig. 270).



Fig 270

PICT-7410

6. Install a bolt and nut to secure the control knob to the throttle assembly (Fig. 272).



Fig 272

PICT-7491

5. Slide the control knob onto the throttle assembly lever (Fig. 271).



Fig 271

PICT-7490

7. Install a throttle decal onto the tower (Fig. 273).



Fig 273

PICT-7407



# CHASSIS

8. Position the fuel tank into the tower (Fig. 274).



Fig 274

PICT-7304a

10. Slide the fuel line back onto the fuel filter and position the hose clamp to secure (Fig. 276).



Fig 276

PICT-7300

9. Position the 2 fuel tank support rods and install a screw securing each support rod to the dash supports (Fig. 275).



Fig 275

PICT-7303

11. Adjust the throttle and choke cables. Refer to "Throttle and Choke Cable Adjustment" on page 4-10.

12. Slide the muffler and heat shield assembly onto the manifold pipes and into position (Fig. 277).



Fig 277

PICT-7425

13. Install 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right) (Fig. 278).



Fig 278

PICT-7423

15. Install 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 280).




Fig 280

PICT-7245

14. Position the bumper to the frame (Fig. 279).



Fig 279

PICT-7417

16. Install the hood. Refer to "Hood Installation" on page 3-34.

17. Connect the battery cable to the negative battery terminal (Fig. 281).



Fig 281

PICT-7349

18. Lower the seat.

19. Operate the tractor to ensure all controls operate properly.

# CHASSIS

## Choke Cable Replacement

### Choke Cable Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 282).



Fig 282

PICT-7349

3. Remove the hood. Refer to "Hood Removal" on page 3-34.
4. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 283).




Fig 283

PICT-7245

5. Remove the bumper (Fig. 284).



Fig 284

PICT-7417

6. Remove the 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right (Fig. 285).




Fig 285

PICT-7423

8. Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Replace the fuel cap onto the fuel tank (Fig. 287).



Fig 287

PICT-7300

7. Slide the muffler and heat shield assembly off the manifold pipes (Fig. 286).



Fig 286

PICT-7425

9. Loosen the 2 screws securing the fuel tank support rods to the dash supports. Lay the support rods to the side (Fig. 288).



Fig 288

PICT-7303

# CHASSIS

10. Lift the fuel tank out of the tower (Fig. 289).



Fig 289

PICT-7304a

12. Remove the choke cable from the cable clamp and remove the z-bend from the engine control lever (Fig. 291).



Fig 291

PICT-7433

11. Loosen the cable clamp TORX screw securing the throttle and choke cables to the engine bracket (Fig. 290).



Fig 290

PICT-7430

13. Remove the nut securing the choke control to the tower (Fig. 292).



Fig 292

PICT-7434

14. Remove the choke cable assembly from the machine by pulling it out through the tower (Fig. 293).



Fig 293

PICT-7436a

2. Route the choke cable around the left side of the engine placing the cable into the R-clamp (Fig. 295) and through the cable tie (Fig. 296).



Fig 295

PICT-7478

## Choke Cable Installation

1. Insert the choke cable assembly through the tower (Fig. 294).



Fig 294

PICT-7477



Fig 296

PICT-7479

# CHASSIS

3. Install a nut securing the choke cable control to the tower (Fig. 297).



Fig 297

PICT-7481

5. Place the choke cable into the cable clamp (Fig. 299).



Fig 299

PICT-7489

4. Insert the choke cable z-bend into the choke lever on the front of the engine (Fig. 298).




Fig 298

PICT-7488

6. Adjust the throttle and choke cables. Refer to "Throttle and Choke Cable Adjustment" on page 4-10.

7. Position the fuel tank into the tower (Fig. 300).



Fig 300

PICT-7304a

8. Position the 2 fuel tank support rods and install a screw securing each support rod to the dash supports (Fig. 301).



Fig 301

PICT-7303

9. Slide the fuel line back onto the fuel filter and position the hose clamp to secure (Fig. 302).



Fig 302

PICT-7300

10. Slide the muffler and heat shield assembly onto the manifold pipes and into position (Fig. 303).



Fig 303

PICT-7425

11. Install 4 screws securing the left and right side muffler brackets to the frame (2 on the left and 2 on the right) (Fig. 304).




Fig 304

PICT-7423



# CHASSIS

12. Position the bumper to the frame (Fig. 305).



Fig 305

PICT-7417

13. Install 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 306).




Fig 306

PICT-7245

14. Install the hood. Refer to "Hood Installation" on page 3-34.

15. Connect the battery cable to the negative battery terminal (Fig. 307).



Fig 307

PICT-7349

16. Lower the seat.

17. Operate the tractor to ensure all controls operate properly.

## Deck Lift Link Replacement

The following procedures were done on the right side of the tractor. The procedure is the same for the left side unless noted. The rear wheel assembly has been removed for photo purposes.

## Deck Lift Link Removal

1. Remove mower deck. Refer to:
  - "50" Mower Deck Removal" on page 7-6
  - "54" Mower Deck Removal" on page 7-29
2. Place the deck lift handle in the lowest height-of cut position.
3. Lift the seat to access the battery compartment.
4. Disconnect the black battery cable from the negative battery terminal (Fig. 308).



Fig 308

PICT-7349

5. Disconnect the red battery cable from the positive battery terminal (Fig. 309).



Fig 309

PICT-7351a

6. Remove the battery hold down rod (Fig. 310).



Fig 310

PICT-7352

# CHASSIS

7. Remove the battery from the battery tray (Fig. 311).



Fig 311

PICT-7353

9. Remove the cotter pin securing the lift cable to the lift link (Fig. 313).




Fig 313

PICT-7752

8. Remove the battery tray (Fig. 312).



Fig 312

PICT-7354

10. Remove the shoulder bolt and nut securing the front end of the lift link to the frame (Fig. 314).



Fig 314

PICT-7758

3

11. Remove the lift link from the machine (Fig. 315).



Fig 315

PICT-7808

2. Install a shoulder bolt and nut to secure the front end of the lift link to the frame (Fig. 317).



Fig 317

PICT-7758

## Deck Lift Link Installation

1. Position the lift link to the frame (Fig. 316).



Fig 316

PICT-7808

3. Insert the lower end of the lift cable into the lift link and install a cotter pin securing the lift cable to the lift link (Fig. 318).

Right side lift cable: The lift cable must be positioned on the outside of the brake rod.




Fig 318

PICT-7752

A. Lift cable

B. Brake Rod

# CHASSIS

Left side lift cable: The lift cable must be positioned between the transmission drive belt and the frame (Fig. 319).




Fig 319 PICT-7794

- A. Lift cable      B. Transmission drive belt

4. Position the battery tray into the fender (Fig. 320).



Fig 320 PICT-7354

5. Place the battery into the battery tray (Fig. 321).



Fig 321 PICT-7353

6. Install the battery hold down rod (Fig. 322).



Fig 322 PICT-7352

7. Connect the red battery cable to the positive battery terminal (Fig. 323).



Fig 323

PICT-7351a

8. Connect the black battery cable to the negative battery terminal (Fig. 324).



Fig 324

PICT-7349

9. Lower the seat.
10. Install the mower deck. Refer to:
  - "50" Mower Deck Installation" on page 7-8
  - "54" Mower Deck Installation" on page 7-31
11. Operate the tractor to ensure all controls operate properly.

## Deck Lift Cable Replacement

The following procedures were performed on the right side lift cable. The procedure is the same for the left side lift cable unless noted. The wheel assembly has been removed for photo purposes.

### Deck Lift Cable Removal

1. Remove the mower deck. Refer to:
  - "50" Mower Deck Removal" on page 7-6
  - "54" Mower Deck Removal" on page 7-29
2. Place the deck lift handle in the highest height-of-cut position.
3. Lift the seat to access the battery compartment.
4. Disconnect the black battery cable from the negative battery terminal (Fig. 325).



Fig 325

PICT-7349

# CHASSIS

5. Disconnect the red battery cable from the positive battery terminal (Fig. 326).



Fig 326

PICT-7351a

6. Remove the battery hold down rod (Fig. 327).



Fig 327

PICT-7352

7. Remove the battery from the battery tray (Fig. 328).




Fig 328

PICT-7353

8. Remove the battery tray (Fig. 329).



Fig 329

PICT-7354

3

- Using a spring tool (Toro part no. 92-5771), unhook the deck lift spring from the machine (Fig. 330).



Fig 330

PICT-7768

- Remove the hairpin cotter securing the upper end of the lift cable to the frame (Fig. 331).



Fig 331

PICT-7766

- Place the deck lift handle in the lowest height-of-cut position.
- Remove the e-clip from the end of the lift shaft assembly (Fig. 332).



Fig 332

PICT-7771

- Slide the lift shaft over as far as possible and remove the upper end of the cable from the lift shaft assembly (Fig. 333).



Fig 333

PICT-7775



# CHASSIS

14. Remove the cotter pin securing the lift cable to the lift link. Remove the end of cable from the lift link (Fig. 334).



Fig 334

PICT-7752

16. Remove the roller pulley and shoulder bolt (Fig. 336).



Fig 336

PICT-7764

15. Remove the nut from the shoulder bolt that secures the roller pulley and lift cable to the frame (Fig. 335).



Fig 335

PICT-7760

17. Remove the lift cable from the machine (Fig. 337).




Fig 337

PICT-7776

3

## Deck Lift Cable Installation

1. Place the deck lift handle in the lowest height-of cut position.
2. Position the lift cable into the machine (Fig. 338).



Fig 338

PICT-7776

3. With the e-clip removed, slide the lift shaft over as far as possible and install the upper end of the cable into the lift shaft assembly (Fig. 339).



Fig 339

PICT-7777

4. Install the e-clip onto the end of the lift shaft assembly (Fig. 340).




Fig 340

PICT-7784

5. Place the deck lift handle in the highest height-of cut position.
6. Install a hairpin cotter securing the upper end of the lift cable to the lift shaft assembly (Fig. 341).



Fig 341

PICT-7766

# CHASSIS

7. Hook the deck lift spring onto the frame (Fig. 342).



Fig 342

PICT-7768

8. Place the deck lift handle in the lowest height-of cut position.
9. Insert the lower end of the lift cable through the hole in the frame located in front of the roller pulley bracket (Fig. 343).



Fig 343

PICT-7790

10. Insert the shoulder bolt into the roller pulley. Place the lift cable into the groove of the roller pulley. Insert the shoulder bolt/roller assembly into the pulley bracket located on the frame (Fig. 344).

**Note:** Make sure the cable stays inside the guides on the frame.



Fig 344

PICT-7792

11. Install a nut onto the shoulder bolt to secure the roller pulley and lift cable to the frame (Fig. 345).



Fig 345

PICT-7760

12. Insert the lower end of the lift cable into the lift link and install a cotter pin securing the lift cable to the lift link (Fig. 346).

Right side lift cable: The lift cable must be positioned on the outside of the brake rod.




Fig 346

PICT-7752

- A. Lift cable                      B. Brake Rod

Left side lift cable: The lift cable must be positioned between the transmission drive belt and the frame (Fig. 347).




Fig 347

PICT-7794

- A. Lift cable                      B. Transmission drive belt

13. Position the battery tray in the fender (Fig. 348).



Fig 348

PICT-7354

14. Place the battery into the battery tray (Fig. 349).



Fig 349

PICT-7353

# CHASSIS

15. Install the battery hold down rod (Fig. 350).



Fig 350

PICT-7352

17. Connect the black battery cable to the negative battery terminal (Fig. 352).



Fig 352

PICT-7349

16. Connect the red battery cable to the positive battery terminal (Fig. 351).



Fig 351

PICT-7351a

18. Lower the seat.

19. Install the mower deck. Refer to:

- 50" Mower Deck Installation on page 7-8
- 54" Mower Deck Installation on page 7-31

20. Operate the tractor to ensure all controls operate properly.

## Deck Lift Handle & Shaft Assembly Replacement

### Deck Lift Handle & Shaft Assembly Removal

1. Remove the mower deck. Refer to:
  - “50” Mower Deck Removal” on page 7-6
  - “54” Mower Deck Removal” on page 7-29
2. Place the deck lift handle in the highest height-of-cut position.
3. Remove the handle grip from the deck lift handle (Fig. 353).



Fig 353

PICT-7391

4. Lift the seat to access the battery compartment.
5. Disconnect the black battery cable from the negative battery terminal (Fig. 354).



Fig 354

PICT-7349

6. Disconnect the red battery cable from the positive battery terminal (Fig. 355).



Fig 355

PICT-7351a

# CHASSIS

7. Remove the battery hold down rod (Fig. 356).



Fig 356

PICT-7352

9. Remove the battery tray (Fig. 358).



Fig 358

PICT-7354

8. Remove the battery from the battery tray (Fig. 357).



Fig 357

PICT-7353

10. Remove the hairpin cotter securing the upper end of the lift cable to the lift shaft assembly (Fig. 359).



Fig 359

PICT-7766

11. Using a spring tool (Toro part no. 92-5771), remove the deck lift spring from the machine (Fig. 360).



Fig 360

PICT-7768

12. Place the deck lift handle in the lowest height-of-cut position.
13. Remove the e-clip from the end of the lift shaft assembly (Fig. 361).



Fig 361

PICT-7771

14. Slide the lift shaft over as far as possible and remove the upper end of the cable from the lift shaft assembly (Fig. 362).



Fig 362

PICT-7775

15. Remove the bushing from the end of the lift shaft assembly (Fig. 363).



Fig 363

PICT-7799



# CHASSIS

16. Repeat steps 11 thru 15 on the opposite side of the machine.

17. Slide the ends of the deck lift shaft out of the sides of the frame. Move the wire harness from above the deck lift shaft assembly. Slide the assembly back to the left and remove the lift handle from the slot in the fender. Remove the assembly through the right side of the machine (Fig. 364 and Fig. 365).

3



Fig 364

PICT-7800

18. Remove the torsion spring from the handle and shaft assembly (Fig. 366).




Fig 366

PICT-7805a

A. Torsion spring  
B. Handle

C. Shaft assembly

19. Remove the handle from the shaft assembly (Fig. 367).



Fig 365

PICT-7802



Fig 367

PICT-7807a

## Deck Lift Handle & Shaft Assembly Installation

1. Install the handle into the shaft assembly (Fig. 368).



Fig 368

PICT-7807a

2. Install the torsion spring securing the handle to the shaft assembly (Fig. 369).




Fig 369

PICT-7805a

- A. Torsion spring  
B. Handle

- C. Shaft assembly

3. Insert the deck lift shaft and handle assembly in to the frame from under the right side of the fender. Insert the handle into the slot in the fender. Position the wire harness on top of the shaft assembly. Insert the ends of the shaft into the sides of the frame (Fig. 370 and Fig. 371).



Fig 370

PICT-7802



Fig 371

PICT-7800

# CHASSIS

4. Install a bushing over the end of the lift shaft (Fig. 372).




Fig 372

PICT-7816

6. Install an e-clip onto the end of the lift shaft assembly (Fig. 374).




Fig 374

PICT-7771

5. Slide the lift shaft over as far as possible and insert the upper end of the cable assembly into the hole on the side of the lift shaft assembly (Fig. 373).



Fig 373

PICT-7775

7. Repeat steps 4 thru 6 on the opposite side of the machine.
8. Place the deck lift handle in the highest height-of-cut position.
9. Install the deck lift spring from the lift shaft assembly to the rear frame (Fig. 375).



Fig 375

PICT-7768

10. Install a hair pin to secure the upper end of both lift cables to the lift shaft assembly (Fig. 376).



Fig 376

PICT-7766

12. Place the battery into the battery tray (Fig. 378).



Fig 378

PICT-7353

11. Position the battery tray (Fig. 377).



Fig 377

PICT-7354

13. Install the battery hold down rod (Fig. 379).



Fig 379

PICT-7352

# CHASSIS

14. Connect the red battery cable to the positive battery terminal (Fig. 380).



Fig 380

PICT-7351a

16. Lower the seat.

17. Install the handle grip onto the deck lift handle (Fig. 382).



Fig 382

PICT-7796a

15. Connect the black battery cable to the negative battery terminal (Fig. 381).



Fig 381

PICT-7349

18. Place the deck lift handle in the highest height-of-cut position.

19. Install the mower deck. Refer to:
- "50" Mower Deck Installation" on page 7-8
  - "54" Mower Deck Installation" on page 7-31

20. Operate the tractor to ensure all controls operate properly.

## Front Wheel Toe-In Measurement & Adjustment

If there is uneven tire wear, lawn scuffing, or hard steering, toe-in may need to be adjusted. The front toe-in measurement should be  $1/16''$  to  $5/16''$  (1.58 to 7.93mm). This should be checked every 100 hours or once a year, whichever occurs first.

1. Place the steering wheel in position for straight ahead travel.
2. In front of the axle, measure the distance horizontally from the inside of the left rim to the inside of the right rim (Fig. 383). Note the distance.



Fig 383

PICT-7819

3. Behind the axle, measure the distance horizontally from the inside of the left rim to the inside of the right rim (Fig. 384). Note the distance.



Fig 384

PICT-7821

4. The measurement taken in front of the axle should be between  $1/16''$  and  $5/16''$  (0.16cm and 0.79cm) less than the measurement taken behind the axle.

# CHASSIS

---

Adjust if necessary:

5. Loosen the jam nut found on the drag link at the rear of the ball joint (Fig. 385).




Fig 385

fig. 12 3354-975

6. Remove the hex nut on the top of ball joint (Fig. 385).
7. Thread the ball joint toward the jam nut to shorten the drag link. Thread the ball joint away from the jam nut to lengthen the drag link (Fig. 385).
8. Replace hex nut and lock washer and retighten the jam nut after proper adjustment is achieved.

## Engine Replacement

### Engine Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 386).



Fig 386

PICT-7349

3. Disconnect the battery cable from the positive battery terminal (Fig. 387).



Fig 387

PICT-7351a

4. Remove the electric PTO clutch. Refer to "Electric PTO Clutch Removal" on page 3-29.
5. Release tension from the idler spring and slide the engine pulley off the crank shaft. Remove the transmission drive belt from the engine pulley and remove the pulley from the machine (Fig. 388).



Fig 388

PICT-7497

6. Remove the 4 engine mounting bolts (Fig. 389).




Fig 389

PICT-7620



# ENGINE

7. Lower the machine to the ground.
8. Remove the hood. Refer to "Hood Removal" on page 3-34.
9. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 390).



Fig 390

PICT-7245

11. Remove the 4 screws securing the left and right side bumper brackets to the frame (2 on the left and 2 on the right) (Fig. 392).



Fig 392

PICT-7423

10. Remove the bumper (Fig. 391).



Fig 391

PICT-7417

12. Slide the muffler and heat shield assembly off the manifold pipes and remove it from the machine (Fig. 393).



Fig 393

PICT-7425

13. Mark either the throttle or choke cable and corresponding engine bracket to more easily identify them upon installation (the choke is marked with tape in the photo below) (Fig. 394).




Fig 394

PICT-7591

- A. Choke (outside linkage plate)
- B. Throttle (inside linkage plate)

14. Loosen the cable clamp securing the throttle and choke cable to the engine bracket (Fig. 395).



Fig 395

PICT-7596

15. Unhook the throttle and choke cable z-bends from the engine brackets (Fig. 396).



Fig 396

PICT-7597

4

16. Slide the throttle and choke cables out of the cable tie and the r-clamp located on the left side of the engine (Fig. 397).



Fig 397

PICT-7601

# ENGINE

17. Remove the fuel cap. Slide the hose clamp down the fuel line. Remove the fuel line from the fuel filter and drain the fuel into a suitable container. Slide the fuel line back onto the fuel filter and position the hose clamp to secure. Replace the fuel cap onto the fuel tank (Fig. 398).



Fig 398

PICT-7300

18. Slide the other hose clamp down the fuel line and slide the fuel line off the fuel filter (Fig. 399).



Fig 399

PICT-7603a

19. Disconnect the wire harness from the engine (Fig. 400).



Fig 400

PICT-7605

20. Remove the nut securing the positive wire to the starter assembly. Remove the positive wire from the starter assembly (Fig. 401).



Fig 401

PICT-7610

21. Loosen the oil dipstick. Remove the oil drain cap and install the drain hose onto the oil drain fitting. Twist the oil drain fitting counter-clockwise and pull to drain the oil from the engine (Fig. 402).



Fig 402

PICT-7612

25. Attach chains/straps and a hoist to the lift points on the engine. Raise and remove the engine from the frame (Fig. 403).



Fig 403

PICT-7613

22. Loosen the engine oil dipstick.
23. After the oil has drained, turn the oil drain fitting clockwise to close. Tighten the oil dipstick.
24. Remove the drain hose and reinstall the oil drain cap.

26. If the engine is being serviced, refer to the engine manufacturer's service manual.
27. If a new engine is being installed:
  - Transfer the marking on the throttle/choke bracket to the bracket on the new engine.
  - Install a cable tie on the new engine to route the throttle/choke cables through.
  - Transfer the R-clamp that the throttle/choke cables get routed through to the new engine.

# ENGINE

## Engine Installation

1. Attach chains/straps and a hoist to the lift points on the engine. Lower the engine into place on the frame (Fig. 404).

**Note:** Take care to ensure the throttle and choke cables are not caught between the engine and the frame.



Fig 404

PICT-7613

2. Slide the positive wire onto the starter post. Install a nut securing the positive wire to the starter assembly (Fig. 405).



Fig 405

PICT-7610

3. Plug the wire harness into the engine harness (Fig. 406).



Fig 406

PICT-7605

4. Slide the fuel line onto the fuel filter and position the clamp to secure (Fig. 407).



Fig 407

PICT-7603

- Slide the throttle and choke cables through cable tie and position them into the r-clamp located on the left side of the engine (Fig. 408).



Fig 408

PICT-7614

- Place the throttle and choke cables into the cable clamp. Tighten screw only enough to hold the cables in place (Fig. 410).



Fig 410

PICT-7596

- Hook the throttle and choke cable z-bends into the engine brackets (Fig. 409).

Note the marked cable and the marked bracket.



Fig 409

PICT-7617

- Remove the cable markers.

- Raise the machine.

- Align the engine mounting holes with the holes in the frame. Install the 4 engine mounting bolts and torque to  $16 \pm 2$  ft-lbs. ( $21.7 \pm 2.7$  Nm) (Fig. 411).




Fig 411

PICT-7620

4

# ENGINE

11. Apply anti-seize compound to the crankshaft. Slide the engine pulley onto crankshaft and install the transmission drive belt around engine pulley (Fig. 412).



Fig 412

PICT-7497

14. Connect the battery cable to the negative battery terminal (Fig. 414).



Fig 414

PICT-7349

12. Install the Electric PTO clutch. Refer to Electric PTO Clutch Installation on page 3-30.
13. Connect the battery cable to the positive battery terminal (Fig. 413).



Fig 413

PICT-7351a

15. Lower the seat.
16. Adjust the throttle and choke cables. Refer to: "Throttle & Choke Cable Adjustment" on page 4-10.
17. Slide the muffler and heat shield assembly onto the manifold pipes and into position (Fig. 415).



Fig 415

PICT-7425

18. Install 4 screws securing the left and right side bumper brackets to the frame (2 on the left and 2 on the right) (Fig. 416).



Fig 416

PICT-7423

20. Install 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 418).



Fig 418

PICT-7245

19. Position the bumper to the frame (Fig. 417).



Fig 417

PICT-7417

21. Install the hood Refer to "Hood Installation" on page 3-34.
22. Operate the tractor to ensure all controls operate properly.



# ENGINE

## Throttle & Choke Cable Adjustment

The hood, front bumper and muffler assembly must be removed to make this adjustment. To remove them, follow steps 1 – 5. If they have already been removed, begin at step 6.

1. Remove the hood. Refer to “Hood Removal” on page 3-34.
2. Remove the 2 screws securing the bumper to the frame (1 bolt on the left and 1 on the right) (Fig. 419).



Fig 419

PICT-7245

3. Remove the bumper (Fig. 420).



Fig 420

PICT-7417

4. Remove the 4 screws securing the left and right side bumper brackets to the frame (2 on the left and 2 on the right) (Fig. 421).



Fig 421

PICT-7423

5. Slide the muffler and heat shield assembly off the manifold pipes and remove it from the machine (Fig. 422).



Fig 422

PICT-7425

7. Position the choke control so it is fully pushed in and the throttle control so it is in the fast position (Fig. 423 and Fig. 424).



Fig 423

PICT-7993

Adjustment:

6. The cable clamp securing the throttle and choke cables must be loose.



Fig 424

PICT-7992

# ENGINE

---

8. Push the engine throttle bracket over to the full throttle position (Fig. 425).



Fig 425

PICT-7995

9. Tighten the cable clamp TORX screw to secure the throttle and choke cables in position (Fig. 426).



Fig 426

PICT-7998

10. Move both the throttle control and the choke control in through the full range of motion to ensure the cables are properly adjusted.

## Transmission Drive Belt Replacement

### Transmission Drive Belt Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 427).



Fig 427

PICT-7349

3. Disconnect the battery cable from the positive battery terminal (Fig. 428).



Fig 428

PICT-7351a

4. Remove the battery hold down rod (Fig. 429).



Fig 429

PICT-7352

5. Remove the battery from the battery tray (Fig. 430).



Fig 430

PICT-7353

# GEAR DRIVE SYSTEM

6. Remove the battery tray (Fig. 431).



Fig 431

PICT-7354

8. Remove the transmission belt from the machine (Fig. 433).



Fig 433

PICT-7628

7. Move the flat idler pulley in the direction of the arrow to remove the transmission drive belt from the transmission pulley and variable speed pulley (Fig. 432).




Fig 432

PICT-7627a

A. Direction to move flat idler pulley

B. Transmission belt

5

# GEAR DRIVE SYSTEM

## Transmission Drive Belt Installation

1. Route the transmission drive belt around the pulleys (Fig. 434).




Fig 434 belt routing iso

- A. Variable speed pulley
- B. Transmission pulley
- C. Idler pulley
- D. Transmission drive belt
- E. Idler spring

2. Position the battery tray (Fig. 435).



Fig 435 PICT-7354

3. Place the battery into the battery tray (Fig. 436).



Fig 436 PICT-7353

# GEAR DRIVE SYSTEM

4. Install the battery hold down rod (Fig. 437).



Fig 437

PICT-7352

6. Connect the black battery cable to the negative battery terminal (Fig. 439).



Fig 439

PICT-7349

5. Connect the red battery cable to the positive battery terminal (Fig. 438).



Fig 438

PICT-7351a

7. Lower the seat.

5

# GEAR DRIVE SYSTEM

## Variable Speed Drive Belt Replacement

### Variable Speed Drive Belt Removal

1. Remove the transmission drive belt. Refer to "Transmission Drive Belt Removal" on page 5-1.
2. Remove the shift knob (Fig. 440).



Fig 440

PICT-7632

3. Remove the 4 screws securing the shift cover to the frame (Fig. 441).



Fig 441

PICT-7635

4. Remove the shift cover plate from the frame and lay it to the side (Fig. 442).



Fig 442

PICT-7636

5. Remove the Electric PTO clutch. Refer to "Electric PTO Clutch Removal" on page 3-29.
6. Slide the engine pulley off the crankshaft and remove the transmission drive belt from the engine pulley (Fig. 443).



Fig 443

PICT-7497



# GEAR DRIVE SYSTEM

7. Remove the 4 bolts securing the variable speed pulley assembly to the transmission (Fig. 444).




Fig 444

PICT-7640a

9. Route the belt forward and remove it from around the shift rod (Fig. 446).



Fig 446

PICT-7644

8. Tilt the variable speed pulley forward and remove the belt from it (Fig. 445).



Fig 445

PICT-7642

10. Pull the belt downward (Fig. 447).



Fig 447

PICT-7648

5

# GEAR DRIVE SYSTEM

11. Remove the belt from around the two flat idler pulleys (Fig. 448).



Fig 448

PICT-7649

12. Remove the transmission drive belt from around the crankshaft and remove it from above the steering support bracket (Fig. 449).



Fig 449

PICT-7498

## Variable Speed Drive Belt Installation

1. Route the transmission drive belt through the steering support bracket and frame. Install the transmission drive belt around the crankshaft (Fig. 450).

**Note:** The belt routes between the steering shaft and left side of the frame.



Fig 450

PICT-7622

2. Route the belt between the two idler pulleys on the center double idler bracket (Fig. 451).



Fig 451

PICT-7649

# GEAR DRIVE SYSTEM

3. Route the belt up toward the top of the transmission (Fig. 452).



Fig 452

PICT-7648

5. Tilt the variable speed pulley forward and route the belt around it into the lower pulley groove (Fig. 454).



Fig 454

PICT-7642

4. Route the belt so that it is positioned around the shift rod (Fig. 453).



Fig 453

PICT-7644

6. Install 4 bolts securing the variable speed pulley assembly to the transmission (Fig. 455).




Fig 455

PICT-7640a

5

# GEAR DRIVE SYSTEM

7. Apply anti-seize compound to the crankshaft. Slide the engine pulley onto the crankshaft and route the transmission drive belt around the engine pulley (Fig. 456).



Fig 456

PICT-7497

8. Install the Electric PTO clutch. Refer to "Electric PTO Clutch Installation" on page 3-30.
9. Slide the shift cover plate into the frame (Fig. 457).



Fig 457

PICT-7636

10. Install 4 screws securing the shift cover to the frame (Fig. 458).



Fig 458

PICT-7635

11. Slide the shift knob onto the shift lever (Fig. 459).



Fig 459

PICT-7632

12. Install the transmission drive belt. Refer to "Transmission Drive Belt Installation" on page X-XX.

# GEAR DRIVE SYSTEM

## CVT Transmission Replacement

### CVT Transmission Removal

1. Remove the mower deck. Refer to “50 inch Mower Deck Removal” on page 7-6.
2. Remove the transmission drive belt. Refer to “Transmission Drive Belt Removal” on page 5-1.
3. Remove the shift knob (Fig. 460).



Fig 460

PICT-7632

4. Remove the 4 screws securing the shift cover to the frame (Fig. 461).



Fig 461

PICT-7635

5. Remove the shift cover plate and lay it to the side (Fig. 462).



Fig 462

PICT-7636

5

# GEAR DRIVE SYSTEM

6. Remove the nut securing the shift rod assembly to the transmission (Fig. 463).



Fig 463

PICT-7710a

8. Remove the shift rod assembly from the machine (Fig. 465).



Fig 465

PICT-7708a

7. Remove the spring washer from the shift rod assembly (Fig. 464).



Fig 464

PICT-7709a

9. Remove the washer from the shift rod assembly (Fig. 466).



Fig 466

PICT-7705a

# GEAR DRIVE SYSTEM

10. Loosen the 8 bolts securing the rear wheels to the wheel hub assemblies (4 on the left and 4 on the right) (Fig. 467).



Fig 467

PICT-7502a

13. Raise the machine.

14. Remove the 4 bolts securing the variable speed pulley assembly to the transmission (Fig. 469).




Fig 469

PICT-8525

11. Raise and support the rear of the machine.
12. Remove the 8 lug nuts and remove the 2 wheel assemblies from the wheel hubs (Fig. 468).



Fig 468

PICT-7503a

15. Tilt the variable speed pulley forward and remove the belt from it (Fig. 470).



Fig 470

PICT-7642

5

# GEAR DRIVE SYSTEM

16. Pull the belt downward (Fig. 471).



Fig 471

PICT-8530

18. Remove the cotter pin securing the front end of the brake control rod to the brake linkage (Fig. 473).




Fig 473

PICT-7659

17. Remove the belt from the two flat idler pulleys (Fig. 472).



Fig 472

PICT-7649

19. Remove the brake control rod from the linkage (Fig. 474).



Fig 474

PICT-7660



# GEAR DRIVE SYSTEM

20. Unhook the spring from the rear end of the brake control rod (Fig. 475).



Fig 475

PICT-7662

22. Remove the bolt, nut and self tapping screw securing the front of the transmission to the transmission bracket (Fig. 477).




Fig 477

PICT-7668

21. Remove the brake control rod (Fig. 476).



Fig 476

PICT-7666

A. Bolt and nut

B. Self tapping screw

5

# GEAR DRIVE SYSTEM

23. Support the transmission.
24. Remove the 4 bolts and nuts securing the sides of the transmission to the frame (2 bolts and 2 nuts on each side) (Fig. 478).




Fig 478

PICT-7670

25. Carefully lower the transmission from the machine (Fig. 479).

**Note:** Variable speed pulley will be unsecured.



Fig 479

PICT-7677

26. Remove the variable speed pulley from the transmission (Fig. 480).



Fig 480

PICT-7676

27. Remove the bolt and washer securing the wheel hub assembly to the transmission axle shaft. Remove the wheel hub from the axle shaft (Fig. 481).



Fig 481

PICT-7679a

5

# GEAR DRIVE SYSTEM

28. Repeat step 28 to remove the opposite wheel hub assembly.
29. Remove the nut securing the transmission pulley to the transmission (Fig. 482).



Fig 482

PICT-7682

## CVT Transmission Installation

1. Position the transmission pulley onto the transmission (Fig. 484).



Fig 484

PICT-7684

5

30. Remove the transmission pulley (Fig. 483).



Fig 483

PICT-7684

2. Install the nut securing the transmission pulley to the transmission (Fig. 485).



Fig 485

PICT-7682

# GEAR DRIVE SYSTEM

- Slide the wheel hub onto the axle shaft. Install a bolt and washer to secure the wheel hub assembly to the transmission axle shaft (Fig. 486).



Fig 486

PICT-7679a

- Carefully raise and support the transmission in the machine (Fig. 488).



Fig 488

PICT-7677

- Repeat step 2 to install the opposite wheel hub assembly.
- Position the variable speed pulley onto the transmission (Fig. 487).



Fig 487

PICT-7696

- Install 4 bolts and nuts securing the sides of the transmission to the frame (2 bolts and 2 nuts on each side) (Fig. 489).




Fig 489

PICT-7669

5

# GEAR DRIVE SYSTEM

8. Install a bolt, nut and a self tapping screw to secure the front of the transmission to the transmission bracket (Fig. 490).




Fig 490

PICT-7667

- A. Bolt and nut                      B. Self tapping screw

9. Insert the brake control rod through the hole in the transmission bracket (Fig. 491).



Fig 491

PICT-7666

10. Hook the brake control spring to the rear end of the brake control rod (Fig. 492).



Fig 492

PICT-7662

11. Insert the front end of the brake control rod into the brake linkage (Fig. 493).



Fig 493

PICT-7698

5

# GEAR DRIVE SYSTEM

12. Install a cotter pin securing the front end of the brake control rod to the brake linkage (Fig. 494).




Fig 494

PICT-7659

14. Lower the machine.

15. Tighten the 8 lug nuts securing the rear wheels to the wheel hub assemblies (Fig. 496).



Fig 496

PICT-7502a

13. Install the 2 rear wheel assemblies onto the wheel hubs. Install 8 lug nuts to secure (Fig. 495).



Fig 495

PICT-7503a

16. Route the transmission drive belt between the two flat idler pulleys on the center double idler bracket (Fig. 497).



Fig 497

PICT-7702

5

# GEAR DRIVE SYSTEM

17. Route the belt up in front of the transmission toward the top of the transmission (Fig. 498).



Fig 498

PICT-7648

19. Install 4 bolts securing the variable speed pulley assembly to the transmission (Fig. 500).




Fig 500

PICT-7640

18. Tilt the variable speed pulley forward and route the drive belt around it into the lower pulley groove (Fig. 499).



Fig 499

PICT-7642

20. Lower the machine.

21. Slide a flat washer (with an oblong center hole) onto the transmission shift lever (Fig. 501).



Fig 501

PICT-7705a

5

# GEAR DRIVE SYSTEM

22. Slide the shift rod assembly onto the transmission shift lever. Ensure the rod is in between the variable speed drive belt (Fig. 502).



Fig 502

PICT-7708a

24. Install a nut securing the shift rod assembly to the transmission shift lever (Fig. 504).



Fig 504

PICT-7710a

23. Slide a spring washer (center of the washer up, OD of the washer down) onto the shift rod assembly (Fig. 503).



Fig 503

PICT-7709a

25. Position the shift cover plate into the fender (Fig. 505).



Fig 505

PICT-7636



# GEAR DRIVE SYSTEM

26. Install 4 screws securing the shift cover to the frame (Fig. 506).



Fig 506

PICT-7712

27. Slide the shift knob onto the shift rod (Fig. 507).



Fig 507

PICT-7632

28. Install the transmission drive belt. Refer to "Transmission Drive Belt Installation" on page 5-3.
29. Install the mower deck. Refer to "50" Mower Deck Installation" on page 7-8.
30. Operate the tractor to ensure all controls operate properly.

## CVT Transmission Service

### CVT Transmission Housing Teardown

**Note:** Transaxle shown does not have grease, for photo clarity. Clean and inspect all parts after disassembly. Apply a small amount of grease to all moving parts and needle bearings prior to reassembly.

1. Remove the 23 bolts securing the housing halves together (Fig. 508).



Fig 508

PICT-8272a

2. Remove the upper housing from the lower housing assembly (Fig. 509).




Fig 509

PICT-8274a

# GEAR DRIVE SYSTEM

3. Remove the 2 bolts securing the brake assembly to the transmission housing (Fig. 510).




Fig 510

PICT-8277a

5. Remove the brake disc from the transmission shaft (Fig. 512).



Fig 512

PICT-8280a

4. Remove the brake assembly from the transmission (Fig. 511).

**Note:** Some transmissions have 2 washers (1 on each bolt) between the brake assembly and transmission housing.



Fig 511

PICT-8278a

6. Remove the puck from the transmission housing (Fig. 513).



Fig 513

PICT-8281

5

# GEAR DRIVE SYSTEM

7. Remove the shift fork assembly from the transmission housing (Fig. 514).



Fig 514

PICT-8283

9. Remove the differential axle assembly from the housing (Fig. 516).




Fig 516

PICT-8285

8. Remove the drive shaft and right hand output shaft assemblies from the housing (Fig. 515).



Fig 515

PICT-8284

10. Remove the e-ring from the input shaft (Fig. 517).



Fig 517

PICT-8286

5

# GEAR DRIVE SYSTEM

11. Remove the washers from the input shaft (Fig. 518).



Fig 518

PICT-8288

13. Remove the washer from the input shaft (Fig. 520).



Fig 520

PICT-8290a

12. Remove the input shaft assembly from the housing (Fig. 519).



Fig 519

PICT-8289

14. Remove the snap ring that secures the bevel gear to the input shaft (Fig. 521).



Fig 521

PICT-8293a

5

# GEAR DRIVE SYSTEM

15. Remove the bevel gear from the input shaft (Fig. 522).



Fig 522

PICT-8295a

17. Remove the lockout plate from the housing (Fig. 524).



Fig 524

PICT-8298

16. Remove the 2 screws securing the lockout plate from the housing (Fig. 523).




Fig 523

PICT-8296

18. Turn the housing over and remove the 3 screws that secure the shift cover to the housing (Fig. 525).



Fig 525

PICT-8299

5

# GEAR DRIVE SYSTEM

19. Remove the shift cover from the housing (Fig. 526).



Fig 526

PICT-8301a

21. Remove the shifter insert from the housing (Fig. 528).



Fig 528

PICT-8305a

20. Remove the shift lever assembly from the housing (Fig. 527).



Fig 527

PICT-8304a

22. If the bearings are being replaced, drive out the upper and lower needle bearings from the housing for the input shaft through the hole (Fig. 529).



Fig 529

PICT-8306

5

# GEAR DRIVE SYSTEM

## Differential Axle Assembly Service

**Note:** Differential is serviced as an assembly.

23. Remove the bolt and washer securing the wheel hub assembly to the transmission axle shaft. Remove the wheel hub from the axle shaft (Fig. 530).

**Note:** Discard the bolt. It is a patch bolt and must be replaced upon installation.



Fig 530

PICT-8314a

24. Slide the 2 bearings off the axle (Fig. 531).



Fig 531

PICT-8315a

25. Repeat steps 23 and 24 to remove the opposite bearings and wheel hub assembly.

26. Inspect the 4 bearings. Replace if worn or damaged (Fig. 532).



Fig 532

PICT-8318a

27. Slide 2 bearings onto the axle shaft (Fig. 533).



Fig 533

PICT-8315a

5

# GEAR DRIVE SYSTEM

28. Slide the wheel hub onto the axle shaft. Install a patch bolt (new) and washer securing the wheel hub assembly to the transmission axle shaft (Fig. 534).



Fig 534

PICT-8314a

29. Repeat steps 27 and 28 to install the opposite bearings and wheel hub assembly.

## Drive Shaft Assembly Service

30. Remove the flange bearing and flat washer from the drive shaft (Fig. 535).



Fig 535

PICT-8321

31. Remove the 9 tooth sprocket from the drive shaft (Fig. 536).



Fig 536

PICT-8322a



# GEAR DRIVE SYSTEM

32. Remove the collar assembly from the drive shaft (Fig. 537).



Fig 537

PICT-8323a

34. Remove the 20 tooth spur gear from the drive shaft (Fig. 539).



Fig 539

PICT-8326a

33. Remove the 41 tooth spur gear from the drive shaft (Fig. 538).



Fig 538

PICT-8324a

35. Remove the hi-lo collar assembly from the drive shaft (Fig. 540).



Fig 540

PICT-8327a

5

# GEAR DRIVE SYSTEM

36. Remove the flange bearing and flat washer from the opposite end of the drive shaft (Fig. 541).



Fig 541

PICT-8329a

38. Remove the 10 tooth spur gear from the drive shaft (Fig. 543).



Fig 543

PICT-8333a

37. Remove the snap ring from the drive shaft (Fig. 542).



Fig 542

PICT-8331a

39. Inspect the drive shaft, flange bearings, washers, sprocket, spur gears, snap ring and collars. Replace if worn or damaged (Fig. 544):




Fig 544

PICT-8334a

- |                       |                       |
|-----------------------|-----------------------|
| A. Flange bearing (2) | F. 10 tooth spur gear |
| B. Flat washer (2)    | G. Collar assembly    |
| C. Drive shaft        | H. 20 tooth spur gear |
| D. 9 tooth sprocket   | I. 41 tooth spur gear |
| E. Hi-Lo Collar       |                       |

# GEAR DRIVE SYSTEM

40. Slide a 10 tooth spur gear onto the drive shaft (Fig. 545).



Fig 545

PICT-8333a

42. Slide a washer and flange bearing onto the end of the drive shaft (Fig. 547).



Fig 547

PICT-8329

41. Install a snap ring onto the drive shaft securing the 10 tooth spur gear (Fig. 546).



Fig 546

PICT-8331a

43. Slide a hi-lo collar assembly onto the drive shaft (Fig. 548).



Fig 548

PICT-8327a

5

# GEAR DRIVE SYSTEM

44. Slide a 20 tooth spur gear onto drive shaft (Fig. 549).



Fig 549

PICT-8326a

46. Slide a collar assembly onto the drive shaft (Fig. 551).



Fig 551

PICT-8323

45. Slide a 41 tooth spur gear onto the drive shaft (Fig. 550).



Fig 550

PICT-8324a

47. Slide a 9 tooth sprocket onto the drive shaft (Fig. 552).



Fig 552

PICT-8322

# GEAR DRIVE SYSTEM

48. Slide a washer and flange bearing onto the drive shaft (Fig. 553).



Fig 553

PICT-8321a

50. Remove the bearing from the output shaft (Fig. 555).



Fig 555

PICT-8340a

## Right Hand Output Shaft Assembly Service

49. Remove the seal from the output shaft (Fig. 554).



Fig 554

PICT-8339a

51. Remove the 16 tooth sprocket and chain from the output shaft (Fig. 556).



Fig 556

PICT-8342a

5

# GEAR DRIVE SYSTEM

52. Remove the flanged bearing from the output shaft (Fig. 557).



Fig 557 PICT-8343a

54. Remove the 37 tooth spur gear from the output shaft (Fig. 559).



Fig 559 PICT-8346a

53. Remove the 2 washers from the output shaft (Fig. 558).



Fig 558 PICT-8344a

55. Remove the shifter cover from the output shaft (Fig. 560).



Fig 560 PICT-8347a

# GEAR DRIVE SYSTEM

56. Remove the 27 tooth spur gear from the output shaft (Fig. 561).



Fig 561

PICT-8349a

58. Slide a 27 tooth spur gear onto the output shaft (Fig. 563).



Fig 563

PICT-8349a

57. Inspect the flanged bearing, washers, shifter cover, output shaft, seal, ball bearing, spur gears and chain. Replace if worn or damaged Fig. 562):



Fig 562

PICT-8350a

59. Slide a shifter cover onto the output shaft (Fig. 564).



Fig 564

PICT-8347a

- |                    |                       |
|--------------------|-----------------------|
| A. Flanged bearing | F. Ball bearing       |
| B. Washer (2)      | G. 37 tooth spur gear |
| C. Shifter cover   | H. 27 tooth spur gear |
| D. Output shaft    | I. 16 tooth spur gear |
| E. Seal            | J. 22 link chain      |

# GEAR DRIVE SYSTEM

60. Slide a 37 tooth spur gear onto the output shaft (Fig. 565).



Fig 565

PICT-8346a

62. Slide a flanged bearing onto the output shaft (Fig. 567).



Fig 567

PICT-8343a

61. Slide 2 washers onto the output shaft (Fig. 566).



Fig 566

PICT-8344a

63. Slide a 16 tooth sprocket and chain onto the output shaft (Fig. 568).



Fig 568

PICT-8342a



# GEAR DRIVE SYSTEM

64. Slide a bearing onto the output shaft (Fig. 569).



Fig 569

PICT-8340a

66. Position the 9 tooth sprocket on the drive shaft assembly into the chain with the right hand output shaft assembly (Fig. 571).



Fig 571

PICT-8351a

65. Slide a new seal onto the output shaft (Fig. 570).



Fig 570

PICT-8339a

## CVT Transmission Housing Rebuild

67. If applicable, press 2 new input shaft needle bearings into the housing (Fig. 572).



Fig 572

PICT-8310a

5

# GEAR DRIVE SYSTEM

68. Slide the shifter insert into the housing (Fig. 573).



Fig 573

PICT-8305a

70. Turn the housing over and position the shift cover to the housing (Fig. 575).



Fig 575

PICT-8301a

69. Slide the shift lever assembly into the housing (Fig. 574).



Fig 574

PICT-8304a

71. Install 3 screws to secure the shift cover to the housing (Fig. 576).



Fig 576

PICT-8299

5

# GEAR DRIVE SYSTEM

72. Position the lockout plate to the housing (Fig. 577).



Fig 577

PICT-8298

74. Slide a bevel gear onto the input shaft (Fig. 579).



Fig 579

PICT-8295a

73. Install 2 screws to secure the lockout plate to the housing (Fig. 578).



Fig 578

PICT-8296

75. Install a snap ring to secure the bevel gear to the input shaft (Fig. 580).



Fig 580

PICT-8293a

5

# GEAR DRIVE SYSTEM

76. Slide a washer onto the input shaft (Fig. 581).



**Fig 581**

PICT-8290a

78. Slide 2 washers onto the input shaft (Fig. 583).



**Fig 583**

PICT-8288

77. Slide the input shaft assembly into the housing (Fig. 582).



**Fig 582**

PICT-8289

79. Install an e-ring onto the input shaft to secure it to the housing (Fig. 584).



**Fig 584**

PICT-8286

**5**

# GEAR DRIVE SYSTEM

80. Position the differential axle assembly into the housing (Fig. 585).




Fig 585

PICT-8285

**Note:** Make sure the tabs of all 3 flange bearings are seated in their V notches in the housing (Fig. 587 and Fig. 588).




Fig 587

PICT-8352a

81. Position the drive shaft and right hand output shaft assemblies into the housing (Fig. 586).



Fig 586

PICT-8284



Fig 588

PICT-8354a

5

# GEAR DRIVE SYSTEM

82. Place the shift fork assembly into the housing (Fig. 589).



Fig 589

PICT-8283

84. Slide the brake disc onto the transmission shaft (Fig. 591).



Fig 591

PICT-8280a

83. Replace the brake pucks and brake disc if worn or damaged. Install the puck into the transmission housing (Fig. 590).



Fig 590

PICT-8281

**Note:** Some transmissions have 2 washers (1 on each bolt) between the brake assembly and transmission housing.

85. Position the brake assembly to the transmission (Fig. 592).



Fig 592

PICT-8278a

5

# GEAR DRIVE SYSTEM

86. Install 2 bolts to secure the brake assembly to the transmission housing (Fig. 593).




Fig 593

PICT-8277a

89. Install 23 bolts in a crisscross pattern to secure the housing halves together (Fig. 595).




Fig 595

PICT-8272a

87. Pack the transmission with grease: 55 oz. of Shell Darina "O" Type Grease.

88. Position the upper housing onto the lower housing (Fig. 594).




Fig 594

PICT-8355a

## Variable Speed Pulley Service

To remove the variable speed pulley from the CVT transmission, refer to "CVT Transmission Removal" on page 5-10.

1. Remove the center bolt and washer securing the bearings to the pulley shaft (Fig. 596).



Fig 596

PICT-7685a

5

# GEAR DRIVE SYSTEM

2. Remove the bracket assembly from the variable speed pulley (Fig. 597).



Fig 597

PICT-7686a

4. Remove the bearing cup from the bracket (Fig. 599).



Fig 599

PICT-7690a

3. Remove the 3 nuts and bolts securing the bearing cup to the pulley bracket (Fig. 598).



Fig 598

PICT-7688a

5. Remove the 2 ball bearings from the bearing cup (Fig. 600).



Fig 600

PICT-7692a

5



# GEAR DRIVE SYSTEM

6. Inspect the bearings. Replace if worn or damaged.
7. Insert 2 bearings into the bearing cup (Fig. 601).



Fig 601

PICT-7693a

9. Install 3 bolts and nuts to secure the bearing cup assembly to the bracket (Fig. 603).



Fig 603

PICT-7688a

8. Position the bearing cup assembly onto the bracket (Fig. 602).



Fig 602

PICT-7695a

10. With the pulley secure in a vise, position the bracket assembly onto the pulley (Fig. 604).



Fig 604

PICT-7686a

5

# GEAR DRIVE SYSTEM

11. Install a bolt and washer securing the bracket assembly to the pulley (Fig. 605).



Fig 605

PICT-7685a

2. Raise and support the rear of the machine.
3. Remove the 4 lug nuts and remove the wheel assembly from the wheel hub (Fig. 607).



Fig 607

PICT-7503a

## Brake Puck Replacement

### Brake Puck Removal

1. Loosen the 4 lug nuts securing the rear wheel to the wheel hub assembly (Fig. 606).



Fig 606

PICT-7502a

4. Remove the 2 bolts securing the brake assembly to the transmission housing (Fig. 608).



Fig 608

PICT-7717a

5

# GEAR DRIVE SYSTEM

5. Remove the brake assembly from the transmission (Fig. 609).

**Note:** Some transmissions have 2 washers between the brake assembly and the transmission (1 for each bolt).



Fig 609

PICT-7719a

7. Remove the puck from the brake assembly (Fig. 611).



Fig 611

PICT-7721

6. Remove the brake assembly from the spring (Fig. 610).



Fig 610

PICT-7720a

8. Remove the brake disc from the transmission (Fig. 612).



Fig 612

PICT-7722

5

# GEAR DRIVE SYSTEM

9. Remove the puck from the transmission housing (Fig. 613).



Fig 613

PICT-7723a

## Brake Puck Installation

1. Install a puck into the transmission housing (Fig. 615).



Fig 615

PICT-7723a

10. Inspect the brake disc and 2 brake pucks. Replace if damaged or worn (Fig. 614).



Fig 614

PICT-7724a

2. Slide the brake disc onto the transmission shaft (Fig. 616).



Fig 616

PICT-7725

5

# GEAR DRIVE SYSTEM

3. Install the puck into the brake assembly (Fig. 617).



Fig 617

PICT-7721

5. Insert 2 bolts into the brake assembly (Fig. 619).



Fig 619

PICT-7728

4. Hook the brake assembly onto the spring (Fig. 618).



Fig 618

PICT-7727

6. If washers are present, slide a washer onto each of the bolts (Fig. 620).



Fig 620

PICT-7730

5

# GEAR DRIVE SYSTEM

7. Position the brake assembly to the transmission and install the 2 bolts to secure it (Fig. 621).



Fig 621

PICT-7717a

9. Lower the machine.

10. Tighten the 4 lug nuts to secure the rear wheel to the wheel hub assembly (Fig. 623).



Fig 623

PICT-7502a

8. Slide the wheel onto the wheel hub assembly and install 4 lug nuts (Fig. 622).



Fig 622

PICT-7503a

# GEAR DRIVE SYSTEM

## Brake Adjustment

### ! WARNING !

Never attempt to adjust the brakes while the engine is running. Always disengage PTO, move shift lever into neutral position, stop engine and remove key to prevent unintended starting.

If the tractor does not come to a complete stop when the brake pedal is completely depressed, or if the tractor's rear wheels can roll with the parking brake applied, the brake is in need of adjustment. The brake disc can be found on the right side of the transmission in the rear of the tractor. Adjust if necessary as follows:

Looking at the transmission from the right side of the tractor, locate the spring and brake disc (Fig. 624).




Fig 624

fig. 11 3354-975

- A. Brake disc
- B. Hex nut
- C. Spring
- D. Brake puck (2)

1. Loosen, but do NOT remove, the hex nut found on the right side of the brake assembly (Fig. 000 above).
2. Insert a feeler gauge set at .011" (.028mm) between the brake disc and the brake puck (Fig. 625).



Fig 625

PICT-7731

**Note:** If a feeler gauge is unavailable, a typical business card is approximately .011" (.028mm) thick.

3. Retighten the hex nut loosened earlier, leaving a .011" (.028mm) gap between the brake disc and the brake puck.

# GEAR DRIVE SYSTEM

## Autodrive Pedal Adjustment

1. Remove the mower deck. Refer to "50" Mower Deck Removal" on page 7-6.
2. The Autodrive pedal is properly adjusted when the hole found in the double idler bracket has approximately 1-3/8" (3.5cm) of travel with 10 lbs. (4.5kg) of pressure applied to the Autodrive pedal (Fig. 626 and Fig. 627).



Fig 626

PICT-7670




Fig 627

PICT-7673a

- A. Double idler bracket    B. 1-3/8" (3.5cm) travel distance

3. If adjustment is needed:
4. Locate the speed control assembly on the underside of the steering support bracket (Fig. 628).




Fig 628

PICT-7682a

5. Remove both hairpin cotters from the main pin on the speed control assembly (Fig. 629).




Fig 629

PICT-7682a

5



# GEAR DRIVE SYSTEM

6. Remove the washer from the speed control assembly (Fig. 630).



Fig 630

PICT-7683

8. Remove the lock nut from the main pin (Fig. 632).




Fig 632

PICT-7691

7. Remove the Autodrive pedal return spring (Fig. 631).



Fig 631

PICT-7684

9. Remove the main pin from the speed control assembly (Fig. 633).



Fig 633

PICT-7692

5

# GEAR DRIVE SYSTEM

- Loosen the jam nut on the idler adjustment rod.  
Turn the idler adjustment rod clockwise or counter-clockwise to obtain the 1-3/8" (3.5cm) idler bracket travel (Fig. 634).




Fig 634

PICT-7693

- A. Jam nut                      B. Idler adjustment rod

- Tighten the jam nut.

- Install the main pin through the adjustment rod, back into the lockout bracket, then through the speed control assembly. Install the jam nut onto the pin (Fig. 635).

**Note:** Ensure the main pin is oriented so the hairpin holes are positioned vertically.




Fig 635

PICT-7699

- A. Main pin                      D. Speed control assembly  
B. Adjustment rod              E. Jam nut  
C. Lockout bracket

5

- Install a washer onto the main pin (Fig. 636).



Fig 636

PICT-7683

# GEAR DRIVE SYSTEM

14. Install 2 hairpin cotters into the main pin (Fig. 637).




Fig 637

PICT-7682a

16. Install the other end of the Autodrive pedal return spring to the tab on the frame (Fig. 639).



Fig 639

PICT-7704

15. Install the Autodrive pedal return spring into the notch on the speed control bracket (Fig. 638).



Fig 638

PICT-7687a

17. Check the travel distance on the idler bracket (approximately 1-3/8" (3.5cm) of travel with 10 lbs. (4.5kg) of pressure applied to the Autodrive pedal). If additional adjustment is needed, go back to step 3 and repeat adjustment.

18. Install the mower deck. Refer to "50" Mower Deck Installation" on page 7-8.

5

# HYDROSTATIC DRIVE SYSTEM

## Transmission Drive Belt Replacement

### Transmission Drive Belt Removal

1. Lift the seat to access the battery compartment.
2. Disconnect the battery cable from the negative battery terminal (Fig. 640).



Fig 640

PICT-7349

3. Disconnect the battery cable from the positive battery terminal (Fig. 641).



Fig 641

PICT-7351a

4. Remove the battery hold down rod (Fig. 642).



Fig 642

PICT-7352

5. Remove the battery from the battery tray (Fig. 643).



Fig 643

PICT-7353

# HYDROSTATIC DRIVE SYSTEM

6. Remove the battery tray (Fig. 644).



Fig 644

PICT-7354

7. Raise the machine so the transmission drive belt can be accessed.
8. With a small pry bar, release tension from the idler spring. Remove the belt from the fixed V idler pulley and the idler pulley (Fig. 645).



Fig 645

PICT-7496

9. Remove the Electric PTO clutch. Refer to Electric PTO Clutch Removal on page 3-29.
10. Slide the engine pulley off the crankshaft and remove the transmission drive belt from the engine pulley (Fig. 646).



Fig 646

PICT-7497

11. Remove the transmission drive belt from around the crankshaft (Fig. 647).



Fig 647

PICT-7498

# HYDROSTATIC DRIVE SYSTEM

12. Route the transmission drive belt back and remove it from above the steering support bracket (Fig. 648).



Fig 648

PICT-7499

## Transmission Drive Belt Installation

1. Route the transmission drive belt around the transmission fan and pulley (Fig. 650).



Fig 650

PICT-7501

13. Remove the transmission drive belt from around the transmission pulley and fan. Remove the belt from the machine (Fig. 649).



Fig 649

PICT-7501

2. Route the transmission drive belt between the steering support bracket and frame (Fig. 651).



Fig 651

PICT-7584

# HYDROSTATIC DRIVE SYSTEM

3. Position the transmission drive belt around the crankshaft (Fig. 652).



Fig 652

PICT-7585a

5. With a small pry bar, extend the idler spring bracket. Route the right hand belt run between the fixed idler and the flat idler. Route the left hand belt run on the outside of the other fixed idler pulley (Fig. 654).



Fig 654

PICT-7496a

4. Apply anti-seize compound to crankshaft. Slide the engine pulley onto crankshaft and install the transmission drive belt around engine pulley (Fig. 653).



Fig 653

PICT-7497

Transmission drive belt routing (Fig. 655).




Fig 655

PICT-7586

- |                    |                |
|--------------------|----------------|
| A. Fixed idler (2) | C. RH belt run |
| B. Flat idler      | D. LH belt run |

6

# HYDROSTATIC DRIVE SYSTEM

6. Install the Electric PTO clutch. Refer to “Electric PTO Clutch Installation” on page 3-30.
7. Install the battery tray (Fig. 656).



Fig 656

PICT-7354

9. Install the battery hold down rod (Fig. 658).



Fig 658

PICT-7352

8. Install the battery to the battery tray (Fig. 657).



Fig 657

PICT-7353

10. Connect the battery cable to the positive battery terminal (Fig. 659).



Fig 659

PICT-7351a



# HYDROSTATIC DRIVE SYSTEM

11. Connect the battery cable to the negative battery terminal (Fig. 660).



Fig 660

PICT-7349

12. Lower the seat.

## Hydrostatic Transmission Replacement

### Hydrostatic Transmission Removal

1. Remove the transmission drive belt. Refer to "Transmission Drive Belt Removal" on page 5-1.
2. Loosen the 8 lug nuts securing the rear wheels to the wheel hub assemblies (Fig. 661).



Fig 661

PICT-7502a

# HYDROSTATIC DRIVE SYSTEM

3. Raise and support the rear of the machine.
4. Remove the 8 lug nuts and remove the 2 wheel assemblies from the wheel hubs (Fig. 662).



Fig 662

PICT-7503a

6. Remove the brake control rod from the linkage (Fig. 664).



Fig 664

PICT-7513

5. Remove the cotter pin securing the front end of the brake control rod to the brake linkage (Fig. 663).



Fig 663

PICT-7512

7. Unhook the spring from the rear end of the brake control rod (Fig. 665).



Fig 665

PICT-7518

# HYDROSTATIC DRIVE SYSTEM

8. Remove the brake control rod (Fig. 666).



Fig 666

PICT-7521

10. Remove the speed control rod trunnion from the speed control linkage (Fig. 668).



Fig 668

PICT-7523

9. Remove the hairpin cotter securing the front end of the speed control rod to the speed control linkage (Fig. 667).



Fig 667

PICT-7522

11. Remove the cotter pin from the rear end of the speed control rod (Fig. 669).



Fig 669

PICT-7527

6

# HYDROSTATIC DRIVE SYSTEM

12. Remove the spring from the speed control rod and transmission (Fig. 670).




Fig 670

PICT-7529

14. Remove the washer from the speed control rod (Fig. 672).



Fig 672

PICT-7532

13. Remove the speed control rod from the transmission linkage and remove it from the machine (Fig. 671).



Fig 671

PICT-7530

15. Unplug the harness wire from actuator bracket spring switch (Fig. 673).



Fig 673

PICT-7534

# HYDROSTATIC DRIVE SYSTEM

16. Remove the actuator bracket/spring switch (Fig. 674).



Fig 674

PICT-7546

18. Remove the hairpin cotter securing the bypass lever to the bypass bracket on the transmission (Fig. 676).



Fig 676

PICT-7556

17. Remove the screw securing the harness ground (Fig. 675).




Fig 675

PICT-7544

19. Remove the return spring from the bypass lever (Fig. 677).



Fig 677

PICT-7558

6

# HYDROSTATIC DRIVE SYSTEM

20. Remove the bypass lever from the bypass bracket on the transmission and remove the lever from the machine (Fig. 678).



Fig 678

PICT-7559a

22. Secure and support the transmission.

23. Remove the 2 bolts securing the front of the hydrostatic transmission to the frame (Fig. 680).



Fig 680

PICT-7551

21. Remove the cable tie securing the transmission vent hose to the frame (Fig. 679).



Fig 679

PICT-7561

24. Remove the 4 bolts and nuts securing the sides of the hydrostatic transmission to the frame (2 bolts on each side) (Fig. 681).



Fig 681

PICT-7554

# HYDROSTATIC DRIVE SYSTEM

25. Carefully lower the hydrostatic transmission from the machine (Fig. 682).



Fig 682

PICT-7564a

27. Remove the wheel hub assembly from the transmission axle shaft (Fig. 684).




Fig 684

PICT-7568a

26. Remove the bolt and washer securing the wheel hub assembly to the transmission axle shaft (Fig. 683).




Fig 683

PICT-7567a

28. Repeat steps 26 and 27 to remove the opposite wheel hub assembly.

6

# HYDROSTATIC DRIVE SYSTEM

## Hydrostatic Transmission Installation

1. Slide a wheel hub assembly onto each transmission axle shaft (Fig. 685).




Fig 685

PICT-7568a

3. Carefully position the hydrostatic transmission under the machine. Secure and support the transmission (Fig. 687).



Fig 687

PICT-7564a

2. Install a bolt and washer to secure each wheel hub assembly to the transmission axle shafts (Fig. 686).




Fig 686

PICT-7567a

4. Install 4 bolts and nuts securing the sides of the hydrostatic transmission to the frame (2 bolts on each side) (Fig. 688).



Fig 688

PICT-7554



# HYDROSTATIC DRIVE SYSTEM

5. Install 2 bolts securing the front of the hydrostatic transmission to the frame (Fig. 689).



Fig 689

PICT-7551

7. Insert the bypass lever into the slot on the rear of the machine. Slide the bypass lever onto the bypass bracket on the transmission (Fig. 691).



Fig 691

PICT-7559a

6. Position the transmission vent tube along the left side of the frame and install a plastic push mount tie to secure it to the frame and wire harness (Fig. 690).



Fig 690

PICT-7561

8. Slide the return spring onto the bypass bracket (Fig. 692).



Fig 692

PICT-7558

6

# HYDROSTATIC DRIVE SYSTEM

9. Install a hairpin cotter securing the bypass lever and spring to the bypass bracket on the transmission (Fig. 693).



Fig 693

PICT-7556

11. Position the actuator bracket with the spring switch to the slot in the transmission (Fig. 695).



Fig 695

PICT-7574

10. Position the ground wire to the transmission bracket and install a screw to secure it (Fig. 694).




Fig 694

PICT-7544

12. Plug the harness wire into the actuator bracket spring switch (Fig. 696).



Fig 696

PICT-7534

# HYDROSTATIC DRIVE SYSTEM

13. Slide a washer onto the rear end of the speed control rod (Fig. 697).



Fig 697

PICT-7532

15. Hook the spring onto the speed control rod (Fig. 699).



Fig 699

PICT-7529

14. Position the rear end of the speed control rod into the machine and slide the speed control rod into the transmission linkage (Fig. 698).



Fig 698

PICT-7577

16. Install a cotter pin securing the spring, actuator bracket and speed control rod to the transmission (Fig. 700).



Fig 700

PICT-7527

# HYDROSTATIC DRIVE SYSTEM

17. Insert the trunnion on the front end of the speed control rod into the speed control linkage (Fig. 701).



Fig 701

PICT-7523

19. Position the rear end of the brake control rod through the hole in the frame and up to the transmission (Fig. 703).



Fig 703

PICT-7521

18. Install a hairpin cotter securing the front end of the speed control rod to the speed control linkage (Fig. 702).



Fig 702

PICT-7522

20. Hook the spring to the rear end of the brake control rod (Fig. 704).



Fig 704

PICT-7518

# HYDROSTATIC DRIVE SYSTEM

21. Position the front end of the brake control rod into the brake control linkage (Fig. 705).




Fig 705

PICT-7580

23. Slide the wheel assembly onto the wheel hub assembly (Fig. 707).



Fig 707

PICT-7503a

22. Install a cotter pin securing the front end of the brake control rod to the brake control linkage (Fig. 706).



Fig 706

PICT-7512

24. Install 4 lug nuts securing the wheel assembly to the wheel hub assembly (Fig. 708).



Fig 708

PICT-7502a

6

# HYDROSTATIC DRIVE SYSTEM

25. Repeat steps 23 and 24 to install the second wheel assembly to the opposite wheel hub.
26. Install the transmission drive belt. Refer to “Transmission Drive Belt Installation” on page 5-3.
27. Tighten the 8 lug nuts securing the rear wheels to the wheel hub assemblies (Fig. 709).



Fig 709

PICT-7502a

28. If a new transmission was installed, purge the system, adjust the brake and adjust neutral. Refer to:
  - “Purging the System” on page 6-20
  - “Brake Adjustment” on page 5-52
  - “Neutral Adjustment” on page 6-22
29. Operate the tractor to ensure all controls operate properly.

# HYDROSTATIC DRIVE SYSTEM

## Purging the System

Due to the effect air has on efficiency in hydrostatic drive applications, it is critical that it be purged from the system.

These purge procedures should be implemented any time a hydrostatic system has been opened to facilitate maintenance or any additional oil has been added to the system.

Air creates inefficiency because its compression and expansion rate is higher than the oil in hydrostatic drive systems.

The resulting symptoms in hydrostatic systems may be:

1. Noisy operation
2. Lack of power or drive after short term operation
3. High operation temperature and excessive expansion of oil

Before starting, make sure the transaxle is at the specified oil level (Fig. 710).

**Note:** Fill unit until oil is flowing out of Port B.

The following procedures should be performed with the vehicle drive wheels off the ground, then repeated under normal operating conditions.

1. With the bypass valve open and the engine running, slowly move the directional control (foot control) in both forward and reverse directions 5 to 6 times; as air is purged from the unit, the oil level will drop.
2. With the bypass valve in the closed position and the engine running, slowly move the directional control valve (foot control) in both forward and reverse directions 5 to 6 times. After stopping the engine, check the oil level and add oil as required.

**Note:** Fill unit until oil is flowing out of Port B (Fig. 710).

3. It may be necessary to repeat Steps 1 and 2 until all the air is completely purged from the system. When the transaxle moves forward and reverse at normal speed purging is complete.




Fig 710

fig. 3 310-3000

A. Fluid fill port

B. Fluid level port - oil should flow from this port

# HYDROSTATIC DRIVE SYSTEM

## Fluid Change

The Hydro-Gear transaxle is factory filled and does not require periodic oil change. In the event of oil contamination or degradation, oil replacement may correct certain performance problems:

1. Remove the transaxle from the machine. Refer to "Hydrostatic Transmission Removal" on page 6-6.
2. Completely drain the oil from the transaxle through the top fluid fill port, Port A (Fig. 711).
3. Fill unit until oil is flowing out of Port B (Fig. 711):

Fluid Description	Volume
20W-50 engine oil	0.95 gal (116.5oz)




Fig 711

fig. 3 310-3000

- A. Fluid fill port
- B. Fluid level port - oil should flow from this port

4. Install the transaxle into the machine. Refer to "Hydrostatic Transmission Installation" on page X-XX.
5. Purge the system. Refer to "Purging the System" on page X-XX.



# HYDROSTATIC DRIVE SYSTEM

## Neutral Adjustment

Before making a neutral adjustment, the transmission must be warmed up for at least 10 minutes.

1. Loosen the 4 lug nuts securing the right rear wheel to the wheel hub assembly (Fig. 712).



Fig 712

PICT-7502a

2. Raise and support the rear of the machine.
3. Remove the 4 lug nuts and remove the wheel assembly from the wheel hub (Fig. 713).



Fig 713

PICT-7503a

4. Locate the neutral adjusting puck and loosen the Allen head bolt. If it's difficult to loosen, heat the aluminum housing near the bolt with a propane torch (Fig. 714).



Fig 714

PICT-7822

5. Start the engine and run it at full throttle.
6. Rotate the adjusting puck in both directions and watch the axle direction. Adjust the puck so it is set at the midpoint between forward and reverse axle rotation. Make sure the axle is not moving.
7. Once in neutral, hold the puck with an adjustable wrench so it won't move. Tighten the Allen head bolt (Fig. 715).



Fig 715

PICT-7823

# HYDROSTATIC DRIVE SYSTEM

8. Operate the foot control in forward and reverse. Allow the pedal to return to the neutral position to test the adjustment.
9. Slide the wheel assembly onto the wheel hub assembly (Fig. 716).



Fig 716

PICT-7503a

11. Lower the machine to the ground.
12. Tighten the 4 lug nuts (Fig. 718).



Fig 718

PICT-7502a

10. Install 4 lug nuts securing the wheel assembly to the wheel hub assembly (Fig. 717).



Fig 717

PICT-7502a

# HYDROSTATIC DRIVE SYSTEM

## Brake Puck Replacement

### Brake Puck Removal

1. Loosen the 4 lug nuts securing the right rear wheel to the wheel hub assembly (Fig. 719).



Fig 719

PICT-7502a

2. Raise and support the rear of the machine.
3. Remove the 4 lug nuts and remove the wheel assembly from the wheel hub (Fig. 720).



Fig 720

PICT-7503a

4. Loosen the lower bolt securing the brake assembly to the transmission housing (Fig. 721).




Fig 721

PICT-7733

# HYDROSTATIC DRIVE SYSTEM

5. Remove the brake arm spring (Fig. 722).



Fig 722

PICT-7734

7. Remove the upper bolt securing the brake assembly to the transmission housing (Fig. 724).



Fig 724

PICT-7737

6. Remove the lower bolt, washer, and spacer from the brake assembly (Fig. 723).



Fig 723

PICT-7736

8. Remove the brake assembly from the transmission (Fig. 725).



Fig 725

PICT-7738

# HYDROSTATIC DRIVE SYSTEM

9. Remove the brake assembly from the spring (Fig. 726).



Fig 726

PICT-7739

11. Remove the disc brake from the transmission (Fig. 728).



Fig 728

PICT-7742a

10. Remove the puck from the brake assembly (Fig. 727).



Fig 727

PICT-7741a

12. Remove the puck from the transmission housing (Fig. 729).



Fig 729

PICT-7743a

# HYDROSTATIC DRIVE SYSTEM

13. Inspect the disc brake and 2 brake pucks. Replace if damaged or worn (Fig. 730).



Fig 730

PICT-7744a

2. Slide the disc brake onto the transmission shaft (Fig. 732).



Fig 732

PICT-7745

## Brake Puck Installation

1. Install a puck into the transmission housing (Fig. 731).



Fig 731

PICT-7743a

3. Install the puck into the brake assembly (Fig. 733).



Fig 733

PICT-7741a

# HYDROSTATIC DRIVE SYSTEM

- Hook the brake assembly onto the spring (Fig. 734).



Fig 734

PICT-7747

- Install the lower bolt, washer and spacer to secure the brake assembly to the transmission housing (Fig. 736).



Fig 736

PICT-7736

- Position the brake assembly to the transmission and install the top bolt to secure it (Fig. 735).



Fig 735

PICT-7748

- Hook the brake arm spring onto the brake arm (Fig. 737).



Fig 737

PICT-7749

6

# HYDROSTATIC DRIVE SYSTEM

- Hook the brake arm spring onto the lower bolt (Fig. 738).



Fig 738

PICT-7733

- Lower the machine.

- Tighten the 4 lug nuts securing the rear wheel to the wheel hub assembly (Fig. 740).



Fig 740

PICT-7502a

- Adjust the parking brake. See "Parking Brake Adjustment" on page 6-30.

- Slide the wheel onto the wheel hub assembly and install 4 lug nuts (Fig. 739).



Fig 739

PICT-7503a



# HYDROSTATIC DRIVE SYSTEM

## Parking Brake Adjustment

### ! WARNING !

Never attempt to adjust the brakes while the engine is running. Always disengage PTO, stop engine and remove key to prevent unintended starting.

If the tractor does not come to a complete stop when the brake pedal is completely depressed, or if the tractor's rear wheels can roll with the parking brake applied, the brake is in need of adjustment. The brake disc can be found on the right side of the transmission in the rear of the tractor. Adjust if necessary as follows:

**Note: Have a replacement cotter pin on hand before beginning this adjustment.**

Looking at the transmission from the right side of the tractor, locate the brake puck and brake disc (Fig. 741).




Fig 741

fig. 11 3345-977

- A. Brake puck (2)
- B. Cotter pin
- C. Crown nut
- D. Brake disc

1. Remove and discard the cotter pin which secures the crown nut to the assembly (Fig. 741).
2. Loosen, but do NOT remove, the crown nut found on the brake assembly.
3. Insert a feeler gauge set at .011" (.28mm) between the brake disc and the brake puck (Fig. 742).

**Note: If a feeler gauge is unavailable, a typical business card is approximately .011" (.28mm) thick.**



Fig 742

PICT-7751

4. Retighten the crown nut loosened earlier, leaving a .011" (.28mm) gap between the brake disc and each of the brake pucks.
5. Insert a new cotter pin to secure the crown nut in place. Do NOT reuse the old cotter pin.

## 50" Mower Deck Belt Replacement

### 50" Mower Deck Belt Removal

1. Remove the mower deck from the tractor. Refer to "50" Mower Deck Removal" on page 7-6.
2. Remove the 3 screws securing the left hand spindle cover to the mower deck (Fig. 743).



Fig 743

PICT-7946

3. Remove the left hand spindle cover (Fig. 744).



Fig 744

PICT-7949

4. Remove the 4 screws securing the right hand spindle cover to the mower deck (Fig. 000).

**Note:** There is a hook retainer bracket located under one of the screws securing the right spindle cover to the mower deck (Fig. 745).



Fig 745

PICT-7947

5. Remove the right hand spindle cover (Fig. 746).



Fig 746

PICT-7950a

# MOWER DECK

6. Loosen the nut from the bolt securing the pulley to the spring loaded idler assembly (Fig. 747).



Fig 747

PICT-7952

## 50" Mower Deck Belt Installation

1. Route the mower deck belt around the spindles and idlers. Refer to the belt routing decal (Fig. 749):




Fig 749

decal 1 3354-977

7. Tilt the spring loaded idler pulley and remove the mower deck belt from the mower deck (Fig. 748).



Fig 748

PICT-7953a

2. Tilt the spring loaded idler pulley to route the belt around it (Fig. 750).



Fig 750

PICT-7953a

7

# MOWER DECK

3. Tighten the nut onto the bolt securing the pulley to the spring loaded idler assembly (Fig. 751).



Fig 751

PICT-7952

5. Install 4 screws to secure the right hand spindle cover to the mower deck (Fig. 753).

**Note:** There is a hook retainer bracket located under one of the screws securing the spindle cover to the mower deck.



Fig 753

PICT-7947

4. Position the right hand spindle cover onto the mower deck (Fig. 752).



Fig 752

PICT-7950

6. Position the left hand spindle cover onto the mower deck (Fig. 754).



Fig 754

PICT-7949

# MOWER DECK

7. Install 3 screws to secure the left hand spindle cover to the mower deck (Fig. 755).



Fig 755

PICT-7946

8. Install the mower deck onto the tractor. Refer to "50" Mower Deck Installation" on page 7-8.

## 50" Mower Deck Fixed Idler Replacement

The mower deck has been removed from the tractor for photo purposes.

### 50" Mower Deck Fixed Idler Removal

1. Remove the bolt, washer and nut securing the fixed idler pulley to the fixed idler mounting bracket (Fig. 756).



Fig 756

PICT-7982

# MOWER DECK

2. Remove the fixed idler pulley from the mounting bracket (Fig. 757).



Fig 757

PICT-7984

## 50" Mower Deck Fixed Idler Installation

1. Position the fixed idler pulley onto the fixed idler mounting bracket (Fig. 758).



Fig 758

PICT-7984

2. Install a bolt, washer and nut to secure the fixed idler pulley to the fixed idler mounting bracket (Fig. 759).



Fig 759

PICT-7982

# MOWER DECK

## 50" Mower Deck Removal

1. Place the PTO/Blade Engage knob in the disengaged (OFF) position and engage the parking brake.
2. Lower the deck by moving the deck lift lever into the bottom notch on the right fender (Fig. 760).



Fig 760

PICT-7829

3. Using a breaker bar or ratchet, rotate the idler bracket forward and remove the deck belt from around the electric PTO clutch (Fig. 761 and Fig. 762).




Fig 761

fig. 20 3354-975

- |                          |                     |
|--------------------------|---------------------|
| A. Idler bracket         | D. Belt guard       |
| B. Spring                | E. 3/8" Square hole |
| C. Pivoting idler pulley |                     |



Fig 762

PICT-7830

# MOWER DECK

4. From the left side of the tractor, locate the deck support pin on the rear left side of the deck. Pull the deck support pin outward to release the deck from the deck lift arm. Rotate the pin so it rests on the deck hanger bracket (Fig. 763).



Fig 763

PICT-7988

5. Repeat the above step on the tractor's right side.
6. Slide the cutting deck toward the front of the tractor allowing the hooks on the deck to release themselves from the deck stabilizer rod (Fig. 764).



Fig 764

PICT-7987

7. Move the deck lift lever into the top notch to raise the deck lift arms up and out of the way (Fig. 765).



Fig 765

PICT-7839

8. Turn the tractor's front wheels fully left. Slide the cutting deck (from the right side) out from underneath the tractor (Fig. 766).



Fig 766

PICT-7986



# MOWER DECK

## 50" Mower Deck Installation

1. Place the PTO/Blade Engage knob in the disengaged (OFF) position and engage the parking brake.
2. Move the deck lift lever into the top notch to raise the deck lift arms up and out of the way (Fig. 767).



Fig 767

PICT-7839

4. Slide the cutting deck toward the front of the tractor allowing the hooks on the deck to catch on the deck stabilizer rod (Fig. 769).



Fig 769

PICT-7987

3. Turn the tractor's front wheels fully left. Slide the cutting deck (from the right side) underneath the tractor (Fig. 768).



Fig 768

PICT-7986

5. Lower the deck lift arms by moving the deck lift lever into the bottom notch on the right fender (Fig. 770).



Fig 770

PICT-7829

# MOWER DECK

- From the left side of the tractor, locate the deck support pin on the rear left side of the deck. Pull the deck support pin outward. Lift the deck into position and release the deck support pin so that the deck is hanging and supported by the deck support pin (Fig. 771).



Fig 771

PICT-7988

- Repeat the above step on the tractor's right side.
- Using a breaker bar or ratchet, rotate the idler bracket forward and route the mower deck belt around the electric PTO clutch (Fig. 772 and Fig. 773).




Fig 772

Fig. 20 3354-975

- |                          |                     |
|--------------------------|---------------------|
| A. Idler bracket         | D. Belt guard       |
| B. Spring                | E. 3/8" Square hole |
| C. Pivoting idler pulley |                     |



Fig 773

PICT-7990

# MOWER DECK

9. Raise the deck by moving the deck lift lever into the top notch on the right fender (Fig. 774).



Fig 774

PICT-7837

## 50" Mower Deck Spindle Replacement

The following procedure was performed on the center spindle assembly. The process is the same for all three spindle assemblies except where noted.

### 50" Mower Deck Spindle Removal

1. Remove the mower deck from the tractor. Refer to "50" Mower Deck Removal" on page 7-6.
2. If servicing a left or right spindle, remove the deck belt from the mower deck. Refer to "50" Mower Deck Belt Removal" on page 7-1.
3. Turn the mower deck over to access the underside of the mower deck.
4. Block the mower deck blade and remove the nut securing the mower deck blade to the spindle shaft (Fig. 775).



Fig 775

PICT-7976

# MOWER DECK

5. Remove the mower deck blade from the spindle shaft (Fig. 776).



Fig 776

PICT-7978

7. Remove the spindle assembly from the mower deck (Fig. 778).



Fig 778

PICT-012a

6. Remove the 4 screws securing the spindle assembly to the mower deck (Fig 777).



Fig 777

PICT-7980

# MOWER DECK

## 50" Mower Deck Spindle Installation

1. As necessary, apply grease to all three mower deck spindles.
2. Position the spindle assembly onto the top side of the mower deck (pulley side facing up) (Fig. 779).

**Note:** The spindle grease fitting should be positioned so that it is facing toward the front of the mower deck. This will allow for easier greasing of the spindles.



Fig 779

PICT-012a

3. Install 4 screws securing the spindle assembly to the mower deck (Fig 780).

**Note:** The screws are installed from the bottom side of the mower deck.



Fig 780

PICT-7980

4. Slide mower deck blade onto the spindle shaft (Fig. 781). Ensure the center of the blade is seated onto machined star end of the spindle shaft.

**Note:** Make sure the blade sails face the deck.



Fig 781

PICT-7978

5. Block the mower deck blade and install a nut securing the mower deck blade to the spindle shaft (Fig. 782). Torque the blade nut to  $80 \pm 10$  ft-lbs. ( $108 \pm 13.5$  Nm).



Fig 782

PICT-019

6. Install the pulley onto the spindle. Refer to "Mower Deck Pulley Installation" on page 7-50.
7. If applicable, install the mower deck belt onto the mower deck. Refer to "50" Mower Deck Belt Installation" on page 7-2.
8. Install the mower deck onto the tractor. Refer to "50" Mower Deck Installation" on page 7-8.

## 50" Mower Deck Spindle Service

1. Secure the mower deck spindle into a vise.
2. Secure the spindle shaft and remove the nut securing the pulley to the mower deck spindle (Fig. 783).



Fig 783

PICT-8046a

3. Remove the washer (Fig. 784).



Fig 784

PICT-8047a

# MOWER DECK

4. Remove the pulley (Fig. 785).



Fig 785

PICT-8048a

6. Remove the shoulder spacer from the spindle shaft (Fig. 787).



Fig 787

PICT-8050a

5. Remove the spindle shaft/shoulder spacer assembly from the spindle housing (Fig. 786).



Fig 786

PICT-8049a

7. Remove the bearing and 2 spacers from the pulley side of the housing (Fig. 788).



Fig 788

PICT-7742a

7

# MOWER DECK

8. Press the second bearing out of the blade side of the housing (Fig. 789).

**Note:** Since this bearing is staked in place it **WILL** be damaged if removed.



Fig 789

PICT-7745a

9. Inspect the bearings and spacers and replace if worn or damaged.
10. Press the blade side bearing into the housing (Fig. 790).



Fig 790

PICT-7740

11. Secure the housing assembly into a vise and stake the housing to retain the bearing (Fig. 791).



Fig 791

PICT-7748a

12. Insert 2 spacers into the spindle housing (Fig. 792).



Fig 792

PICT-7749a



# MOWER DECK

13. Install a bearing into the pulley side of the spindle housing (Fig. 793).



Fig 793

PICT-7750a

15. Install the spindle shaft and shoulder spacer assembly into the spindle housing (Fig. 795).



Fig 795

PICT-8049a

14. Install a shoulder spacer onto the spindle shaft cupped side down (Fig. 794).



Fig 794

PICT-8050a

16. Place the spindle housing into a vise.

17. Install the pulley (Fig. 796).



Fig 796

PICT-8048a

7

18. Install a washer onto the spindle shaft (Fig. 797).



Fig 797

PICT-8047a

19. Secure the spindle shaft and install a nut to secure the pulley to the mower deck spindle (Fig. 798).



Fig 798

PICT-8046a

20. Remove the mower deck spindle from the vise.

## 50" Mower Deck Spring Loaded Idler Replacement

### 50" Mower Deck Spring Loaded Idler Removal

1. Remove the Mower Deck from the Tractor. Refer to "50" Mower Deck Removal" on page 7-6.
2. Remove the mower deck belt. Refer to "50" Mower Deck Belt Removal" on page 7-1.
3. Remove the bolt, washer and nut securing the pulley to the spring loaded idler (Fig. 799).



Fig 799

PICT-7955

# MOWER DECK

4. Remove the pulley from the idler bracket (Fig. 800).



Fig 800

PICT-7956

6. Using a spring tool (Toro part no. 92-5771), unhook the idler spring from the spring post on the mower deck (Fig. 802).



Fig 802

PICT-7960

5. Remove the spacer from the idler bracket (Fig. 801).



Fig 801

PICT-7957

7. Remove the idler spring from the idler bracket (Fig. 803).



Fig 803

PICT-7962

# MOWER DECK

8. Remove the nut from the shoulder bolt securing the idler bracket to the mower deck (Fig. 804).



Fig 804

PICT-7963

10. Remove the washer from below the idler assembly mounting bracket (Fig. 806).



Fig 806

PICT-7967

9. Remove the idler bracket from the mower deck (Fig. 805).



Fig 805

PICT-7966

11. Remove the spacer from on top of the idler assembly mounting bracket (Fig. 807).



Fig 807

PICT-7969

# MOWER DECK

12. Remove the shoulder bolt from the idler bracket (Fig. 808).



Fig 808

PICT-7972

2. Position the spacer on top of the idler assembly mounting bracket (Fig. 810).



Fig 810

PICT-7969

## 50" Mower Deck Spring Loaded Idler Installation

1. Insert the shoulder bolt into the idler bracket (Fig. 809).



Fig 809

PICT-7972

3. Position a washer on the underside of the idler assembly mounting bracket (Fig. 811).



Fig 811

PICT-7967

7

# MOWER DECK

4. Insert the idler bracket shoulder bolt through the idler assembly mower mounting bracket and washer (Fig. 812).



Fig 812

PICT-7966

6. Hook the idler spring onto the idler bracket (Fig. 814).



Fig 814

PICT-7962

5. Install a nut onto the shoulder bolt securing the idler bracket to the mower deck (Fig. 813).



Fig 813

PICT-7963

7. Using a spring tool (Toro part no. 92-5771), hook the idler spring to the spring post on the mower deck (Fig. 815).



Fig 815

PICT-7960

# MOWER DECK

8. Position a spacer onto the idler bracket (Fig. 816).



Fig 816

PICT-7957

10. Loosely install a bolt, washer and nut to secure the pulley to the spring loaded idler (Fig. 818).



Fig 818

PICT-7955

9. Position the pulley onto the idler bracket (Fig. 817).



Fig 817

PICT-7956

11. Apply grease to the idler assembly shoulder bolt (Fig. 819).

**Note: Check and apply grease to each of the mower deck spindles as needed.**



Fig 819

PICT-7975

12. Install the mower deck belt. Refer to "50" Mower Deck Belt Installation" on page 7-2.

13. Install the Mower Deck onto the Tractor. Refer to "50" Mower Deck Installation" on page 7-8.

# MOWER DECK

## 54" Mower Deck Belt Replacement

The following procedures were done with the mower deck removed from the mower for photo purposes. To replace the mower deck belt the mower deck can remain on the tractor.

### 54" Mower Deck Belt Removal

1. Place the PTO/Blade Engage knob in the disengaged (OFF) position and engage the parking brake.
2. Lower the deck by moving the deck lift lever into the bottom notch on the right fender (Fig. 820).



Fig 820

PICT-7829

3. Using a breaker bar or ratchet, rotate the idler bracket forward and remove the deck belt from around the electric PTO clutch (Fig. 821 and Fig. 822).




Fig 821

fig. 22 3354-977

A. Idler pulley

B. 3/8" Square hole



Fig 822

PICT-7830



# MOWER DECK

4. Remove the 5 screws securing the left hand spindle cover to the mower deck (Fig. 823).



Fig 823

PICT-7845

6. Remove the 5 screws securing the right hand spindle cover to the mower deck (Fig. 824).



Fig 824

PICT-7847

5. Remove the left hand spindle cover (Fig. 823).



Fig 823

PICT-7848

7. Remove the right hand spindle cover (Fig. 825).



Fig 825

PICT-7849

7

# MOWER DECK

8. Remove the mower deck belt from the mower deck (Fig. 826).



Fig 826

PICT-7851

2. Install 5 screws to secure the right hand spindle cover to the mower deck (Fig. 828).



Fig 828

PICT-7847

## 54" Mower Deck Belt Installation

1. Position the right hand spindle cover onto the mower deck (Fig. 827).



Fig 827

PICT-7849

3. Position the left hand spindle cover onto the mower deck (Fig. 829).



Fig 830

PICT-7848

# MOWER DECK

4. Install 5 screws to secure the left hand spindle cover to the mower deck (Fig. 831).



Fig 831

PICT-7845

## 54" Mower Deck Fixed Idler Replacement

### 54" Mower Deck Fixed Idler Removal

1. Remove the mower deck from the tractor. Refer to "54" Mower Deck Removal" on page 7-29.
2. Remove the deck belt from the mower deck. Refer to "54" Mower Deck Belt Removal" on page 7-23.
3. Remove the bolt, washer and nut securing the fixed idler pulley to the fixed idler bracket (Fig. 832).



Fig 832

PICT-7869

# MOWER DECK

4. Remove the fixed idler pulley (Fig. 833).



Fig 833

PICT-7871

6. Remove the 4 screws securing the fixed idler bracket from the bottom side of the mower deck (Fig. 835).



Fig 835

PICT-7875

5. Remove the spacer (Fig. 834).



Fig 834

PICT-7873

7. Remove the fixed idler bracket (Fig. 836).



Fig 836

PICT-7878

# MOWER DECK

## 54" Mower Deck Fixed Idler Installation

1. Position the fixed idler bracket onto the mower deck (Fig. 837).



Fig 837

PICT-7878

3. Position a spacer onto the fixed idler bracket (Fig. 839).



Fig 839

PICT-7873

2. Install 4 screws from the underside of the mower deck to secure the fixed idler bracket (Fig. 838).




Fig 838

PICT-7875

4. Position the fixed idler pulley onto the spacer (Fig. 840).



Fig 840

PICT-7871

7

# MOWER DECK

5. Install a bolt, washer and nut to secure the fixed idler pulley to the fixed idler bracket (Fig. 841).



Fig 841

PICT-7869

6. Install the mower deck belt onto the mower deck. Refer to "54" Mower Deck Belt Installation" on page 7-25.
7. Install the mower deck onto the tractor. Refer to "54" Mower Deck Installation" on page 7-31.

## 54" Mower Deck Removal

1. Place the PTO/Blade Engage knob in the disengaged (OFF) position and engage the parking brake.
2. Lower the deck by moving the deck lift lever into the bottom notch on the right fender (Fig. 842).



Fig 842

PICT-7829

# MOWER DECK

- Using a breaker bar or ratchet, rotate the idler bracket forward and remove the deck belt from around the electric PTO clutch (Fig. 843 and Fig. 844).




Fig 843 fig. 22 3354-977

- A. Idler pulley                      B. 3/8" Square hole

- From the left side of the tractor, locate the deck support pin on the rear left side of the deck. Pull the deck support pin outward to release the deck from the deck lift arm. Rotate the pin so it rests on the deck hanger bracket (Fig. 845).



Fig 845 PICT-7833



Fig 844 PICT-7830

- Repeat the above step on the tractor's right side.
- Gently slide the cutting deck toward the front of the tractor allowing the hooks on the deck to release themselves from the deck stabilizer rod (Fig. 846).



Fig 846 PICT-7836

# MOWER DECK

7. Move the deck lift lever into the top notch to raise the deck lift arms up and out of the way (Fig. 847).



Fig 847

PICT-7839

8. Turn the tractor's wheels fully left. Slide the cutting deck (from the right side) out from underneath the tractor (Fig. 848).



Fig 848

PICT-7842

## 54" Mower Deck Installation

1. Place the PTO/Blade Engage knob in the disengaged (OFF) position and engage the parking brake.
2. Move the deck lift lever into the top notch to raise the deck lift arms up and out of the way (Fig. 849).



Fig 849

PICT-7839

3. Turn the tractor's wheels fully left. Slide the cutting deck (from the right side) underneath the tractor (Fig. 850).



Fig 850

PICT-7842



# MOWER DECK

- Slide the cutting deck toward the front of the tractor allowing the hooks on the deck to catch on the deck stabilizer rod (Fig. 851).



Fig 851

PICT-7836

- From the left side of the tractor, locate the deck support pin on the rear left side of the deck. Pull the deck support pin outward. Lift the deck into position and release the deck support pin so that the deck is hanging and supported by the deck support pin (Fig. 853).



Fig 853

PICT-7833

- Lower the deck lift arms by moving the deck lift lever into the bottom notch on the right fender (Fig. 852).



Fig 852

PICT-7829

- Repeat the above step on the tractor's right side.
- Route the mower deck belt around the spindles and idlers. Refer to the belt routing decal (Fig. 854):




Fig 854

decal 1 3354-977

# MOWER DECK

9. Using a breaker bar or ratchet, rotate the idler bracket forward and route the mower deck belt around the electric PTO clutch (Fig. 855 and Fig. 856).




Fig 855

fig. 22 3354-977

A. Idler pulley

B. 3/8" Square hole

10. Raise the deck by moving the deck lift lever into the top notch on the right fender (Fig. 857).



Fig 857

PICT-7837



Fig 856

PICT-7990

# MOWER DECK

## 54" Mower Deck Roller Replacement

### 54" Mower Deck Roller Removal

1. Raise the deck by moving the deck lift lever into the top notch on the right fender. Raise and support the rear of the tractor to allow clearance for the deck roller to be removed from the mower deck roller brackets (Fig. 858).



Fig 858

PICT-7837

2. Remove the hairpin cotter from the lift bracket pin on both sides of the mower deck (Fig. 859).



Fig 859

PICT-7929

3. Support the lift bracket and remove the lift bracket pin from the lift bracket on both sides of the mower. Gently lower the roller assembly to the ground (Fig. 860).



Fig 860

PICT-7933

4. Slide the roller away from the mower deck and out from under the tractor (Fig. 861).



Fig 861

PICT-7935

# MOWER DECK

5. Remove the cotter pin from end of the roller shaft (Fig. 862).



Fig 862

PICT-7940

7. Remove the spacer from the end of the roller shaft (Fig. 864).



Fig 864

PICT-7944a

6. Remove the height adjuster from the end of the roller shaft (Fig. 863).



Fig 863

PICT-7943a

8. Repeat steps 5 – 7 to remove the height adjuster from the other end of the roller shaft.
9. Remove the 4 deck rollers from the roller shaft (Fig. 865).



Fig 865

PICT-7945

7

# MOWER DECK

## 54" Mower Deck Roller Installation

1. Slide 4 deck rollers onto the roller shaft (Fig. 866).



Fig 866

PICT-7945

3. Slide the height adjuster onto the end of the roller shaft (Fig. 868).



Fig 868

PICT-7943

2. Slide a spacer onto the end of the roller shaft (Fig. 867).



Fig 867

PICT-7944a

4. Install a cotter pin into end of the roller shaft (Fig. 869).



Fig 869

PICT-7940

# MOWER DECK

- Repeat steps 2 – 4 to install the height adjuster onto the other end of the roller shaft.
- Raise the deck by moving the deck lift lever into the top notch on the right fender. Raise and support the rear of the tractor to allow clearance for the deck roller to be installed into the mower deck roller brackets (Fig. 870).



Fig 870

PICT-7837

- Slide the deck roller assembly under the rear end of the mower deck (Fig. 871).



Fig 871

PICT-7935

- Slide the height adjuster into the mower deck roller bracket. Support the lift bracket and install the lift bracket pin into the lift bracket (Fig. 872).



Fig 872

PICT-7933

- Install a hairpin into the lift bracket pin (Fig. 873).



Fig 873

PICT-7929

- Repeat steps 8 and 9 on the other side of the deck roller.

# MOWER DECK

## 54" Mower Deck Roller Adjustment

1. Place the deck lift lever in the lowest position.
2. Remove the clevis pin and hairpin cotter from the deck roller brackets on the left and right sides of the cutting deck (Fig. 874).



Fig 874

PICT-7929

3. Position the deck roller brackets up or down through the slots on the rear of the deck until desired position is reached, then re-attach with the clevis pins and hairpin cotters just removed.

**IMPORTANT:** Be certain that the left roller bracket and the right roller bracket are set in the same position.

## 54" Mower Deck Spindle Replacement

The following procedure was performed on the left hand spindle assembly. The process is the same for all three spindle assemblies.

### 54" Mower Deck Spindle Removal

1. Remove the mower deck from the tractor. Refer to "54" Mower Deck Removal" on page 7-29.
2. Remove the deck belt from the mower deck. Refer to "54" Mower Deck Belt Removal" on page 7-23.
3. Turn the mower deck over to access the underside of the mower deck.
4. Block the mower deck blade and remove the nut securing the mower deck blade to the spindle shaft (Fig. 875).



Fig 875

PICT-7882

# MOWER DECK

5. Remove the mower deck blade from the spindle shaft (Fig. 876).



Fig 876

PICT-7883

7. Remove the spindle assembly from the mower deck (Fig. 878).



Fig 878

PICT-7889

6. Remove the 4 screws securing the spindle assembly to the mower deck (Fig 877).



Fig 877

PICT-7884



# MOWER DECK

## 54" Mower Deck Spindle Installation

1. Check and apply grease to all three mower deck spindles as needed.
2. Position the spindle assembly onto the top side of the mower deck (pulley side facing up) (Fig. 879).

**Note:** The spindle grease fitting should be positioned so that it is facing toward the front of the mower deck. This will allow for easier greasing of the spindles.



Fig 879

PICT-7925

3. Install 4 screws securing the spindle assembly to the mower deck (Fig. 880).

**Note:** The screws are installed from the bottom side of the mower deck.



Fig 880

PICT-7884

# MOWER DECK

- Slide mower deck blade onto the spindle shaft (Fig. 881). Ensure the center of the blade is seated onto machined star end of the spindle shaft.

**Note: Make sure the blade sails face the deck.**



Fig 881

PICT-7926

## 54" Mower Deck Spindle Service

- Secure the spindle assembly in a vice.
- Remove the nut from the spindle shaft (Fig. 882).



Fig 882

PICT-7894

- Block the mower deck blade and install a nut securing the mower deck blade to the spindle shaft (Fig. 000). Torque the blade nut to  $80 \pm 10$  ft-lbs. ( $108 \pm 13.5$  Nm).
- Install the mower deck belt onto the mower deck. Refer to "54" Mower Deck Belt Installation" on page 7-25.
- Install the mower deck onto the tractor. Refer to "54" Mower Deck Installation" on page 7-31.

- Remove the pulley and the spacer from the spindle shaft (Fig. 883).



Fig 883

PICT-7897

# MOWER DECK

4. Remove the spindle assembly from the vise and remove the spindle shaft and spacer from the spindle housing (Fig. 884).



Fig 884

PICT-7901

6. Remove the second bearing from the blade side of the spindle housing (Fig. 886).



Fig 886

PICT-7904

5. Remove the bearing and two spacers from the pulley side of the housing (Fig. 885).



Fig 885

PICT-7903

7. Inspect the bearings and spacers. Replace if worn or damaged.
8. Install a bearing into the blade side of the spindle housing (Fig. 887).



Fig 887

PICT-7906

# MOWER DECK

9. Insert 2 spacers into the pulley side of the spindle housing (Fig. 888).



Fig 888

PICT-7908a

11. Slide the spacer onto the spindle shaft (Fig. 890).



Fig 890

PICT-7912a

10. Install a bearing into the pulley side of the spindle housing (Fig. 889).



Fig 889

PICT-7910a

12. Slide the spindle shaft into the spindle housing by inserting it into the blade side of the housing first (Fig. 891).



Fig 891

PICT-7913a

# MOWER DECK

13. Secure the spindle housing into a vise with the pulley side up.

14. Slide a spacer onto the spindle shaft (Fig. 892).



Fig 892

PICT-7916a

**Note:** Slide the pulley onto the spindle shaft so that the flanged side of the pulley is installed blade side down (Fig. 894).



Fig 894

PICT-7919

15. Slide the pulley onto the spindle shaft. Ensure the center of the pulley is seated onto machined star end of the shaft (Fig. 893).



Fig 893

PICT-7918

16. Install a nut securing the pulley to the spindle assembly (Fig. 895).



Fig 895

PICT-7894

7

17. Apply grease to the spindle until it begins to appear at the weep hole (Fig. 896).



Fig 896

PICT-7923

## 54" Mower Deck Spring Loaded Idler Replacement

### 54" Mower Deck Spring Loaded Idler Removal

1. Remove the mower deck from the tractor. Refer to "54" Mower Deck Removal" on page 7-29.
2. Remove the mower deck belt from the mower deck. Refer to "54" Mower Deck Belt Removal" on page 7-23.
3. Remove the bolt, washer and nut securing the idler pulley to the idler bracket (Fig. 897).



Fig 897

PICT-7853

# MOWER DECK

4. Remove the idler pulley from the idler bracket (Fig. 898).



Fig 898

PICT-7854

6. Using a spring removal tool (Toro part no. 92-5771), remove the idler spring from the idler bracket and mower deck (Fig. 900).



Fig 900

PICT-7859

5. Remove the spacer from the idler bracket (Fig. 899).



Fig 899

PICT-7856

7. Remove the nut and lock washer from the shoulder bolt securing the idler bracket to the mower deck (Fig. 901).



Fig 901

PICT-7863

7

# MOWER DECK

8. Remove the shoulder bolt, idler bracket and stabilizer bracket from the mower deck (Fig. 902).



Fig 902

PICT-7868

2. Install a lock washer and nut onto the shoulder bolt to secure the idler bracket to the mower deck (Fig. 904).



Fig 904

PICT-7863

## 54" Mower Deck Spring Loaded Idler Installation

1. Position the stabilizer bracket and idler bracket to the mower deck. Insert a shoulder bolt through the idler and stabilizer brackets and then through the mower deck (Fig. 903).



Fig 903

PICT-7868

3. Hook the idler spring to the idler bracket and using a spring removal tool (Toro part no. 92-5771), hook the idler spring to the spring post on the mower deck (Fig. 905).



Fig 905

PICT-7859



# MOWER DECK

4. Position a spacer onto the idler bracket (Fig. 906).



Fig 906

PICT-7856

6. Insert a bolt and washer through the idler pulley, spacer and idler bracket. Install a nut to secure the pulley to the idler bracket (Fig. 908).



Fig 908

PICT-7853

5. Place the idler pulley onto the spacer (Fig. 907).



Fig 907

PICT-7854

7. Install the deck belt. Refer to "54" Mower Deck Belt Installation" on page 7-25.
8. Install the mower deck onto the tractor. Refer to "54" Mower Deck Installation" on page 7-31.

7

## Mower Deck Pulley Replacement (50" & 54" Mower Decks)

The following procedure was performed on the left hand spindle pulley. The process is the same for all spindle pulley replacement. Depending on which pulley is being replaced, the spindle covers and mower deck belt may have to be removed:

Remove the mower deck from the tractor. Refer to:

- 50" Mower Deck Removal on page 7-6
- 54" Mower Deck Removal on page 7-29

Remove the mower deck belt from the mower deck. Refer to:

- 50" Mower Deck Belt Removal on page 7-1
- 54" Mower Deck Belt Removal on page 7-23

2. Remove the pulley and the spacer from the spindle shaft (54" mower spindle shown) (Fig. 910).



Fig 910

PICT-7880

## Mower Deck Pulley Removal

1. Block the blade and remove the nut from the spindle shaft (Fig. 909).



Fig 909

PICT-7879

# MOWER DECK

## Mower Deck Pulley Installation

1. Slide the pulley and the spacer onto the spindle shaft (54" mower spindle shown) (Fig. 911).



Fig 911

PICT-7880

If the mower deck, spindle covers and mower deck belt have to been removed:

Install the mower deck belt onto the mower deck. Refer to:

- 50" Mower Deck Belt Installation on page 7-2
- 54" Mower Deck Belt Installation on page 7-25

Install the mower deck onto the tractor. Refer to:

- 50" Mower Deck Installation on page 7-8
- 54" Mower Deck Installation on page 7-31

2. Block the blade and install a nut onto the spindle shaft (Fig. 912).



Fig 912

PICT-7879

## Electrical System

The GT2000 Series tractor electrical components and electrical troubleshooting topics can be found in the 2006 LX Series Lawn Tractors / GT2000 Series Garden Tractors Demystification Guide (Form No. 492-9161) along with complete wiring diagrams to help diagnose electrical problems. Electrical Troubleshooting DVD, Part No. 492-9193, also contains wiring diagrams and component troubleshooting information for GT2000 Series tractors.

# ELECTRICAL

## GT2100, GT2200, GT2300 Wiring Diagram




Fig 913

GT wiring diag 1

## GT2100, GT2200, GT2300 Wiring Diagram cont.




Fig 914

GT wiring diag 2

**THIS PAGE INTENTIONALLY LEFT BLANK.**







Garden Tractor  
GT Series  
Service Manual