



Count on it.

Parts Catalog

Multi Pro® WM Turf Sprayer

Model No. 41240—Serial No. 315000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Frame, Stand and Boom Mount Assembly	4
Fresh Water Tank Assembly No. 117-7901	5
Control Console Assembly	6
Pump Mount Assembly	7
Pump Assembly No. 117-0713	8
Spray Tank Assembly	9
Tank Assembly No. 121-6518	10
Spray Tank Lid Assembly No. 119-9380.....	11
Suction Filter Assembly No. 125-8006	12
Spray Valve Assembly	13
Agitation Valve Assmebly	14
Regulating Valve Body Assembly No. 127-9804.....	15
On/Off Manifold Valve Kit No. 131-0248.....	16
Actuator Regulating Kit No. 131-3724	17
Pressure Filter Assembly No. 127-9847.....	18
Manifold Valve Kit No. 131-0253	19
2 Way Valve On/Off Assembly No. 131-0250	20
Manifold Valve Kit No. 131-7256	21
Flow Meter Assembly No. 106-1038.....	22
Section Valve Manifold Assembly	23
On/Off Manifold Valve Kit No. 127-9803.....	24
Actuator On/Off Kit No. 131-3723	25
Bypass Valve Assembly No. 127-9805.....	26
Hose A thru J Assembly	27
Boom Lift Assembly	29
Hydraulic Cylinder Assembly No. 117-0701.....	30
On-Off Boom Lift Valve No. 117-0702.....	31
Electrical Assembly	32
Center Boom Mount Assembly.....	33
LH Single Turret Body Assembly No. 108-3725	34
Double Turret Body Assembly No. 108-3727	35
RH Single Body Turret Assembly No. 108-3726	36
Boom Mounting Assembly	37
Left and Right Hand Boom Assembly	38
Attachments and Accessories	39




Frame, Stand and Boom Mount Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	127-3984	1	Skid ASM	25	283-83	4	Pin-Clevis
1:2	127-3936	2	Decal-Danger	26	283-55	2	Pin-Clevis
2	131-5791-03	1	Tube	27	49-2040	4	Screw-HWHTF
3	131-3338-03	1	Mount-Fresh Water Bottle	29	3231-2	4	Bolt-CARR
5	117-7901	1	Fresh Water Tank ASM	30	125-4049-03	1	Bracket-Mount, Valve Drain
8	125-0798	2	Cover-Access	31	3234-14	8	Screw-HHF
9	125-8108-03	1	Jack Stand-Rear, RH	32	104-8300	8	Nut-HF, NI
10	125-8138-03	1	Guard-Relay	33	125-8094	16	Pad-Tank
11	100-9880	2	Bolt-Shoulder	34	127-3985	1	Skid Cover ASM
12	104-8301	4	Nut-HF, NI	34:2	127-3937	1	Decal-Warning, Engine Cover
13	93-9719	4	Block-Wear	35	106-6777	2	Handle-Latch, Swell
14	321-4	4	Screw-HH	36	106-6778	2	Bushing-Latch, Swell
15	3296-42	4	Nut-Lock, NI	37	1-804254	2	Nut-Lock, HH
16	100-5569	2	Pin-Clevis	38	92-1233	2	Pin-Clevis
17	3290-343	8	Pin-Hair	39	92-1298	4	Pin-Lynch
18	125-0809	2	Bracket-Mount, Front	45	322-5	1	Screw-HH
19	100-6116	2	Screw-HHF	46	3218-2	1	Nut-Jam
20	99-5107	2	Nut-Lock	47	3256-23	2	Washer-Plain
21	240-2	1	Grommet-Rubber	48	322-11	2	Screw-HH
22	92-2667-03	2	Bracket-Mount	49	95-9648	2	Knob
23	125-0840-03	1	Jack Stand-Rear				
24	125-0841-03	2	Stand-Front				




Fresh Water Tank Assembly No. 117-7901

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-3983	1	Tank-Water, Fresh
1:2	120-0616	2	Decal-Water, Fresh
2	117-7998	1	Bulkhead
3	119-0524	1	Elbow
4	106-4925	1	Spigot-90 DEG
5	119-0526	1	Bulkhead-Washer
6	119-0525	1	Bulkhead-Nut
7	99-0613	1	Cap-Tank




Control Console Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-5795-03	1	Bracket-Console	15	99-7420	3	Plug-Hole
2	131-9618	1	Control-Console	16	125-8137	1	Fitting-Elbow-90
2:2	131-9607-03	1	Plate-Switch	17	100-8674	1	Coupler-Tube
2:3	3290-409	2	Rivet	18	119-5329	1	Plug-Hole
2:4	131-5808	1	Decal-Switch	19	93-6083	4	Screw-HWH
3	115-1900	1	Controller	20	3290-495	1	Pin-Klik
4	120-6310	1	LCD Display ASM	21	120-0834	3	Screw-HSBH
4:1	120-4630	1	Nut-Display	22	104-7201	3	Nut-HF
4:2	120-6311	1	Decal-Display	23	3234-5	2	Screw-HHF
5	120-8546	1	Gauge-Pressure	24	104-8300	5	Nut-HF, NI
6	100-8490	1	Switch-Rocker, On-None-On	25	3256-71	6	Washer-Flat
7	100-1535	1	Switch	26	322-43	6	Screw-HH
8	125-0899	2	Switch-Rocker	27	130-8294	1	Decal-Console
9	125-7996	1	Switch-Pb, Momentary	28	125-4052	1	Decal-Console, Upper
11	109-8054	2	Bushing-Flange	29	125-4054	1	Pin
12	125-4021-03	1	Bracket-Pivot, Console	30	3234-17	3	Screw-HHF
13	125-4020-03	1	Panel-Control	32	125-8139	1	Decal-Master Boom Switch
14	95-9648	1	Knob	33	95-8999	3	Switch



Pump Mount Assembly


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-0713	1	Pump ASM
3	125-8053-03	1	Mount-Pump
5	3234-11	4	Screw-HHF
6	3290-357	4	Nut-HHF, Whiz
7	3234-6	6	Screw-HHF
8	32128-49	6	Nut-HHF
12	2412-147	1	Clamp-R
13	3234-42	1	Screw-HHF
14	104-8301	1	Nut-HF, NI



Pump Assembly No. 117-0713


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	120-0773	18	Bolt-Hex	18	120-0788	2	Bearing-Ball
2	120-0774	6	Bolt-Hex	19	99-0873	1	Fitting-Grease
3	120-0775	1	Bracket-Pump	20	120-0789	1	Shaft-Crank
4	120-0776	6	Cover-Valve	21	120-0790	2	Spacer-Metal
5	120-0777	6	Bolt-Hex	22	120-0791	2	Bearing-Ball
6	120-0778	6	Disc-Diaphragm	23	120-0792	1	Spacer
7	120-0779	6	Diaphragm	24	120-0793	2	Valve W/Hole
8	120-0780	6	Disc-Backing, Diaphragm	25	120-0794	3	Bolt-Hex
9	120-0781	6	Rod-Connecting	26	120-0795	1	Casting-Pump
10	99-0861	10	Valve-Pump	27	120-0796	1	Pump Kit ●
11	100-6651	12	O-Ring	27:1	120-0777	6	Bolt-Hex
12	120-0782	1	Casting-Pump	27:2	99-0861	10	Valve-Pump
13	120-0783	2	Seal-Oil	27:3	120-0793	2	Valve W/Hole
14	120-0784	4	Bolt-Hex	27:4	100-6651	12	O-Ring
15	120-0785	2	Plug	27:5	120-0778	6	Disc-Diaphragm
16	120-0786	2	Seal	27:6	120-0779	6	Diaphragm
17	120-0787	1	Foot-Pump				

● Not illustrated




Spray Tank Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	121-6518	1	200 Gallon Tank ASM	17	125-4081-03	4	Band-Tank
2	100-8642	1	Screen-Suction	18	3256-24	4	Washer-Flat
3	125-8006	1	Suction Filter ASM	19	323-58	2	Bolt-TAP, HH
4	100-8641	1	Vane-Screen	20	104-8301	4	Nut-HF, NI
5	117-7928	1	Adapter ASM	22	127-3920-03	1	Bracket-Storage
5:2	100-6989	1	O-Ring	23	3290-343	4	Pin-Hair
6	110-5082-03	1	Bracket-Anti Siphon	24	41316	1	Adapter-Quick
7	41140	1	Elbow	25	100-6714	1	Foot-Tube, Suction
8	110-5090	1	Grommet	26	108-3270	1	Screw-TAP
9	110-5088	1	Hose-Fill	27	125-8128	1	Tube-Suction
10	100-6779	1	Coupling-Female	28	100-8649	1	Hose-Suction
11	108-0069	1	Valve-Ball	29	2412-130	2	Clamp-Hose
12	110-5224	1	Fitting-Barbed, Straight	30	3234-7	2	Screw-HHF
13	2412-34	2	Clamp-Hose	31	3231-21	2	Screw-CARR
14	100-8635	6	Fork	32	3234-5	1	Screw-HHF
15	117-7996	1	Fork	33	127-9716	1	Shield-Hose, Drain
16	119-9419	1	Basket-Filter	34	127-9795	2	Tie-Cable, High Temp




Tank Assembly No. 121-6518

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	108-3358	6	Fitting-Bulkhead	8	107-8635	8	Screw-PFH
2:1	107-2864	1	Gasket-Bulkhead	9	125-8064	2	Decal-Tank
3	106-4933	2	Hosebarb ASM	10	120-0622	1	Decal-Warning
3:1	100-8637	1	O-Ring	11	100-8635	2	Fork
4	117-7851	1	Bulkhead ASM	12	127-3967	1	Shield-Sump, Bottom
4:2	100-8646	1	Gasket-Bulkhead	13	127-3960	1	Shield-Sump, Center
4:3	100-8647	1	Nut-Bulkhead	14	127-3962	1	Shield-Sump, Rear
5	100-7051	6	Nut-Bulkhead	15	127-3961	1	Shield-Sump, Front
6	119-9378	1	Gasket-Lid, Tank	16	127-3988	1	Shield-Sump, Side
7	119-9380	1	Spray Tank Lid ASM				




Spray Tank Lid Assembly No. 119-9380

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-9381	1	Ring-Lid
2	119-9382	1	Arm-Lid
3	119-9383	1	Vent-Lid
4	119-9384	1	Cover-Lid
5	119-9385	1	Pin-Pivot
6	106-5004	1	Seal-Lid
7	119-9386	2	O-Ring
8	119-9387	1	Cap-Lid



Suction Filter Assembly No. 125-8006

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	100-8643	1	Housing-Filter
2	106-4942	1	Hosebarb-Straight
2:1	100-6989	1	O-Ring
3	100-8636	1	Fork-Special
4	100-8647	1	Nut-Bulkhead
5	100-8644	2	Pin-Expansion
6	100-8646	1	Gasket-Bulkhead




Spray Valve Assembly

Ref.	Part Number	Qty.	Description
1	131-3704	1	Bracket-Fitting, Tee
2		1	Agitation Manifold ASM ●
4	107-8704	1	Hosebarb
5	106-1038	1	Flow Meter ASM
6	117-7996	1	Fork
7		1	Section Valve Manifold ASM ●
9	104-9090	2	Gasket
10	104-9089	2	Clamp-Screw, Worm
11	100-6704	3	Tee
12	117-7874	1	Relief Valve ASM
13	106-4947	2	Connector
13:1	100-8637	2	O-Ring


Ref.	Part Number	Qty.	Description
14	2412-129	3	Clamp-Hose
18	117-7859	1	Fitting-Pump
19	117-7858	1	Fitting-Pump
21	3234-47	2	Screw-HHF
22	3256-61	2	Washer-Flat
23	32144-32	2	Screw
24	2412-34	6	Clamp-Hose
25	100-8635	12	Fork
26	3290-379	1	Tie-Cable
27	3234-42	6	Screw-HHF
28	104-8301	6	Nut-HF, NI
29	131-3782	1	Hose-Master

● Not serviced separately



Agitation Valve Assmebly


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-3722	1	Mount-Valve	17	127-9815	2	Fitting-Cap
2	127-9804	1	Regulating Valve Body ASM	18	131-0250	1	2-Way Valve On/Off Kit
3	131-0248	1	On/Off Manifold Valve Kit	19	131-0265	1	Agitation Regulating Handle Kit
4	131-3724	1	Actuator Regulating Kit	19:1	131-0263	1	Screw-Handle
5	131-3723	2	Actuator On/Off Kit	20	131-0264	1	Agitation Throttling Handle Kit
6	127-9829	12	Clamp/Gasket Kit	20:1	131-0263	1	Screw-Handle
7	127-9806	1	Fitting Kit	21	131-0266	1	Master Regulating Handle Kit
7:1	127-1175	1	Fork	21:1	131-0263	1	Screw-Handle
8	127-9811	3	Fitting-Cap, Female	25	104-7201	6	Nut-HF
8:1	127-1175	1	Fork	26	3234-4	6	Screw-HHF
9	127-9847	1	Pressure Filter ASM	27	322-19	2	Screw-HH
10	131-0241	1	Fitting-Elbow, Sweep	28	104-8300	2	Nut-HF, NI
11	127-9814	1	Fitting-Adapter	29	131-7256	1	Manifold Valve Kit
13	131-0213	2	90 DEG Barb Fitting Kit				
13:1	127-1175	1	Fork				
15	131-0253	2	Manifold Valve Kit				
16	127-1142	1	Fitting-Barb				



Regulating Valve Body Assembly No. 127-9804

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-8248	1	Valve Stem Kit	6:4	127-1187	1	O-Ring, Endcap
1:1	127-1197	2	O-Ring-Stem	99	130-7304	1	Valve Repair Kit ●
2	127-1196	1	Washer-Stem, Valve	99:1	127-1197	2	O-Ring-Stem
3	127-1195	1	Seat-Stem, Valve	99:2	127-1196	2	Washer-Stem, Valve
4	127-1190	1	Fork-Stem, Valve	99:3	127-1195	1	Seat-Stem, Valve
5	127-1113	1	Ball-V	99:4	127-1190	1	Fork-Stem, Valve
6	130-7317	2	Endcap Kit	99:5	127-1192	2	Seat-Ball
6:1	127-1192	1	Seat-Ball	99:6	127-1188	2	O-Ring, Seat (Ball)
6:2	127-1188	1	O-Ring, Seat (Ball)	99:7	127-1187	2	O-Ring, Endcap
6:3	127-1189	1	O-Ring, Endcap	99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Item 99:7 not used on this kit.

On/Off Manifold Valve Kit No. 131-0248


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	130-8248	1	Valve Stem Kit	99	130-7304	1	Valve Repair Kit ●
1:1	127-1197	2	O-Ring-Stem	99:1	127-1197	2	O-Ring-Stem
2	127-1194	1	Ball-Valve, 3Way	99:2	127-1196	2	Washer-Stem, Valve
3	130-8249	2	Endcap Kit	99:3	127-1195	1	Seat-Stem, Valve
3:1	127-1192	1	Seat-Ball	99:4	127-1190	1	Fork-Stem, Valve
3:2	127-1188	1	O-Ring, Seat (Ball)	99:5	127-1192	2	Seat-Ball
3:3	127-1189	1	O-Ring, Endcap	99:6	127-1188	2	O-Ring, Seat (Ball)
4	127-1196	1	Washer-Stem, Valve	99:7	127-1187	2	O-Ring, Endcap
5	127-1195	1	Seat-Stem, Valve	99:8	127-1189	2	O-Ring, Endcap
6	127-1190	1	Fork-Stem, Valve				

● Not illustrated




Actuator Regulating Kit No. 131-3724

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-9802	1	Actuator-Regulating
2	127-6984	1	Decal-Valve, Regulating
3	130-7301	1	Hairpin-Actuator



Pressure Filter Assembly No. 127-9847


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-0206	1	Head-Filter,
2	131-0203	1	Cup-Filter
3	131-0207	1	Oring-Filter, Cup
4	131-0212	1	Screen-Filter, 16 Mesh
4	131-0211	1	Screen-Filter, 30 Mesh
4	131-0210	1	Screen-Filter, 50 Mesh
4	131-0208	1	Screen-Filter, 100 Mesh
4	131-0209	1	Screen-Filter, 80 Mesh
5	131-0204	1	Plug-Filter
6	131-0205	1	Oring-Filter, Plug



Manifold Valve Kit No. 131-0253


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-8248	1	Valve Stem Kit	5	127-1196	1	Washer-Stem, Valve
1:1	127-1197	2	O-Ring-Stem	6	127-1195	1	Seat-Stem, Valve
2	127-1113	1	Ball-V	7	127-1190	1	Fork-Stem, Valve
3	130-7317	1	Endcap Kit	99	130-7304	1	Valve Repair Kit ●
3:1	127-1192	1	Seat-Ball	99:1	127-1197	2	O-Ring-Stem
3:2	127-1188	1	O-Ring, Seat (Ball)	99:2	127-1196	2	Washer-Stem, Valve
3:3	127-1189	1	O-Ring, Endcap	99:3	127-1195	1	Seat-Stem, Valve
3:4	127-1187	1	O-Ring, Endcap	99:4	127-1190	1	Fork-Stem, Valve
4	130-8249	1	Endcap Kit	99:5	127-1192	2	Seat-Ball
4:1	127-1192	1	Seat-Ball	99:6	127-1188	2	O-Ring, Seat (Ball)
4:2	127-1188	1	O-Ring, Seat (Ball)	99:7	127-1187	2	O-Ring, Endcap
4:3	127-1189	1	O-Ring, Endcap	99:8	127-1189	2	O-Ring, Endcap

● Not illustrated



2 Way Valve On/Off Assembly No. 131-0250

Ref.	Part Number	Qty.	Description
1	130-8248	1	Vavle Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	131-0252	1	Ball-2-Way
3	130-8249	1	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
4	130-7317	1	Endcap Kit
4:1	127-1192	1	Seat-Ball
4:2	127-1188	1	O-Ring, Seat (Ball)
4:3	127-1189	1	O-Ring, Endcap
4:4	127-1187	1	O-Ring, Endcap
5	127-1196	1	Washer-Stem, Valve
6	127-1195	1	Seat-Stem, Valve
7	127-1190	1	Fork-Stem, Valve




Item 99:7 not used on this kit.

Manifold Valve Kit No. 131-7256

Ref.	Part Number	Qty.	Description
1	130-8248	1	Valve Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1194	1	Ball-Valve, 3Way
3	130-8249	1	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
4	127-1196	1	Washer-Stem, Valve
5	127-1195	1	Seat-Stem, Valve
6	127-1190	1	Fork-Stem, Valve
7	130-7317	1	Endcap Kit
7:1	127-1192	1	Seat-Ball


Ref.	Part Number	Qty.	Description
7:2	127-1188	1	O-Ring, Seat (Ball)
7:3	127-1189	1	O-Ring, Endcap
7:4	127-1187	1	O-Ring, Endcap
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Flow Meter Assembly No. 106-1038

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	106-1042	1	Body-Meter, Flow
2	104-9059	1	Rotor / Magnet ASM
3	104-9060	1	Upstream Hub And Bearing ASM
4	104-9061	1	Downstream Hub ASM
5	104-9062	2	Ring-Retaining, Internal
6	42480	1	Stud-Turbine (W / Bearing)
7	104-9065	1	External Sensor ASM
8	104-9063	1	Clamp-Cable
9	104-9064	1	Screw-HWHTF



Section Valve Manifold Assembly


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-0258	1	Mount-Valves, Boom	8	127-9810	1	Male Cap Fitting Kit
2	127-9803	3	On/Off Manifold Valve Kit	8:2	127-1187	1	O-Ring, Endcap
3	131-3723	3	Actuator On/Off Kit	9	131-0213	1	90 DEG Barb Fitting Kit
4	127-9807	3	Straight Fitting Kit	9:1	127-1175	1	Fork
4:1	127-1175	1	Fork	10	127-1144	1	Fitting-Adapter
5	127-9829	4	Clamp/Gasket Kit	11	3234-4	4	Screw-HHF
6	127-1185	1	Fitting-Cap, Port	12	104-7201	4	Nut-HF
7	127-9805	3	Bypass Valve ASM	13	131-3709	1	Coupler



On/Off Manifold Valve Kit No. 127-9803


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	130-8248	1	Valve Stem Kit	6	127-1190	1	Fork-Stem, Valve
1:1	127-1197	2	O-Ring-Stem	99	130-7304	1	Valve Repair Kit ●
2	127-1194	1	Ball-Valve, 3Way	99:1	127-1197	2	O-Ring-Stem
3	130-7317	2	Endcap Kit	99:2	127-1196	2	Washer-Stem, Valve
3:1	127-1192	1	Seat-Ball	99:3	127-1195	1	Seat-Stem, Valve
3:2	127-1188	1	O-Ring, Seat (Ball)	99:4	127-1190	1	Fork-Stem, Valve
3:3	127-1189	1	O-Ring, Endcap	99:5	127-1192	2	Seat-Ball
3:4	127-1187	1	O-Ring, Endcap	99:6	127-1188	2	O-Ring, Seat (Ball)
4	127-1196	1	Washer-Stem, Valve	99:7	127-1187	2	O-Ring, Endcap
5	127-1195	1	Seat-Stem, Valve	99:8	127-1189	2	O-Ring, Endcap

● Not illustrated




Actuator On/Off Kit No. 131-3723

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-9801	1	Actuator-On/Off
2	127-6979	1	Decal-Valve, Agitation
2	127-6981	1	Decal-Valve, On/Off
2	127-6982	1	Decal-Valve, Master Boom
3	127-6976	1	Decal-Valve, Bypass Adjust
4	130-7301	1	Hairpin-Actuator




Bypass Valve Assembly No. 127-9805

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-0298	1	Bypass Needle Kit
1:1	127-1182	1	Needle-Bypass
1:2	127-1181	2	Oring-Bypass Needle
2	127-1180	1	Knob-Bypass
3	127-1179	1	Fork-Bypass Knob
4	127-1187	1	O-Ring, Endcap
5	127-1175	2	Fork




Hose A thru J Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	131-3729	1	Agitation Hose ASM	5:3	2412-34	1	Clamp-Hose
1:1	131-3731	4	Agitation Nozzle ASM	6	131-3765	1	Hose ASM
1:1:1	131-3732	1	Fitting-Barb	6:2	106-4933	1	Hosebarb ASM
1:1:2	120-8579	1	Nozzle-Agitation	6:2:1	100-8637	1	O-Ring
1:1:3	121-4996	1	O-Ring	6:3	2412-3	1	Clamp-Hose
1:3	117-7867	1	Elbow-Hosebarb	8	125-0639	1	Regulating Hose ASM
1:5	117-7866	3	Tee-Hosebarb	8:1	106-4933	2	Hosebarb ASM
1:7	2412-3	15	Clamp-Hose	8:1:1	100-8637	1	O-Ring
2	125-0645	1	Upper Suction Hose ASM	8:3	2412-34	2	Clamp-Hose
2:1	110-5156	1	Suction Elbow ASM	9	131-3784	1	Hose-Bypass
2:1:1	100-8637	1	O-Ring	9:2	106-4933	1	Hosebarb ASM
2:2	106-4952	1	Hosebarb-90 DEG	9:2:1	100-8637	1	O-Ring
2:2:1	100-6989	1	O-Ring	9:3	2412-34	1	Clamp-Hose
2:4	41327	2	Clamp-Hose	10	125-0643	1	Lower Suction Hose ASM
3	125-0647	1	Drain Hose ASM	10:1	117-7965	1	Hosebarb ASM
3:1	106-4933	1	Hosebarb ASM	10:2	117-7982	1	Hosebarb ASM
3:1:1	100-8637	1	O-Ring	10:1:1	100-6989	1	O-Ring
3:3	2412-34	1	Clamp-Hose	10:2:2	100-8637	1	O-Ring
5	131-3764	1	Hose ASM	10:4	41327	2	Clamp-Hose
5:2	106-4932	1	Hosebarb-Straight	11	131-3767	1	Hose ASM
5:2:1	100-8637	1	O-Ring	11:2	106-4932	1	Hosebarb-Straight




Hose A thru J Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
11:2:1	100-8637	1	O-Ring
11:3	2412-34	1	Clamp-Hose



Boom Lift Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-4856-03	1	Plate-Mount, Cylinders	11:1	237-42	1	O-Ring
2	117-0701	2	Hydraulic Cylinder ASM	12	354-79	1	Cap-Dust
3	104-8300	4	Nut-HF, NI	13	322-14	2	Screw-HH
4	131-0297-03	1	Plate-Stiffener, Boom	14	32128-26	2	Nut-Flange
5	112-7884	2	Pin-Pivot	15	110-5067	2	Screw-CARR
6	110-5053	2	Screw-HHF	16	3296-23	2	Nut-Lock, NI
7	3234-29	2	Screw-HHF	17	119-4859	4	Hose ASM
8	130-8201-03	1	Mount-Valve	17:3	237-78	1	O-Ring
9	117-0702	1	On-Off Boom Lift Valve ASM	18	106-7968	1	Coupler-Quick, Female
10	340-2	2	Fitting-Straight	19	106-7969	1	Coupler-Quick, Male
10:1	237-22	1	O-Ring	20	127-9717	2	Hose ASM
10:2	237-42	1	O-Ring	20:1	237-42	1	O-Ring
11	59-7410	1	Fitting-Diagnostic				





Hydraulic Cylinder Assembly No. 117-0701

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-8026	1	Seal Kit ●
1:1		1	O-Ring ■
1:2		1	Ring-Backup ■
1:3		1	Bp Seal ■
1:4		1	Bs Seal ■
1:5		1	Dust Seal ■
1:6		1	O-Ring ■
2	119-8027	1	Rod End
3	3220-6	1	Nut-Jam

● Not illustrated


■ Not serviced separately



On-Off Boom Lift Valve No. 117-0702


Ref.	Part Number	Qty.	Description
3	120-2588	2	Valve-Check
3:1	120-0886	1	Seal Kit ●
4	107-7517	1	Valve-Solenoid
4:1	105-9156	1	Seal Kit ●
4:2	107-7812	1	Nut-Solenoid
5	120-2587	2	Valve-Solenoid
5:1	112-6520	1	Seal Kit ●
6	119-8036	5	Coil
7	120-2586	2	Spacer-Coil
8	120-2585	4	Orifice, .035
9	340-92	4	Fitting-Straight
9:1	237-78	1	O-Ring
9:2	237-21	1	O-Ring

● Not illustrated




Electrical Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0433	1	Harness-Wire	4:2	32180-108	2	Nut-Battery Clamp
1:13	94-6710	1	Fuse-2 Amp	5	106-1429	3	Clamp-J
1:15	114241	3	Fuse-Blade, 7.5 Amp	6	99-7435	1	Relay-Power
1:16	218-578	1	Fuse-Blade, 10 Amp	7	99-7430	1	Relay
1:17	109355	1	Fuse-Blade, 15 Amp	8	125-8067	1	Plug-Plastic
1:18	32180-043	2	Resistor-120 Ohm	9	104-0395	1	Plug-Plastic
1:24	109103	1	Fuse-Blade, 30 Amp	10	3234-13	1	Screw-HHF
2	127-3966	1	Decal-Fuse Block	11	104-7201	1	Nut-HF
3	108-9455	1	Harness-Wire, Fusible Link	12	32180-110	1	Insulator-Lead Cast, Red
4	112-9921	2	Bolt ASM				
4:1	32180-107	1	Bolt-Battery Clamp-Double Ended Stud				




Center Boom Mount Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	131-3752	2	Boom-Outside	19	108-3495	2	Cover-Slide
1:2	120-0617	2	Decal-Warning, Pinch, Crush	20	108-3743	2	Washer
2	107-8775-03	3	Bracket-Nozzle Mount	21	108-3744	2	Screw-Shoulder
3	108-3725	1	LH Single Body Turret ASM	22	114-9566	2	Clamp-R
4	108-3727	1	Double Turret Body ASM	23	95-9186	3	Cap
5	108-3726	1	RH Single Body Turret ASM	23:1	40998	1	Seat-Gasket
6	3269-18	6	Rivet-Blind	24	95-9187	6	Cap-Blank
7	104-8300	7	Nut-HF, NI	24:1	40998	1	Seat-Gasket
8	108-3717	1	Hose-Boom	25	108-3735	1	Hose-Boom, Center (LH)
9	108-3439	1	Tee	26	108-3718	1	Hose-Boom, Center (RH)
10	2412-129	7	Clamp-Hose	27	3256-68	2	Washer-Flat
11	130-8238-03	2	Lower Cradle ASM	28	110-5070	2	Bumper
12	3290-378	2	Tie-Cable	29	127-3923RT02	1	Conduit
13	104-8301	14	Nut-HF, NI	30	127-9770	1	Hose-Shutoff
14	108-3476-03	2	Cradle-Upper	31	127-8955-03	1	Mount-Boom
15	108-3457	2	Spacer	32	127-8956-03	1	Mount-Boom
16	108-3742	2	Screw-HHF	33	110-5057	4	Capscrew-HHF
17	108-3489	4	Cap-Tube	34	108-3745	4	Nut-HHF, Whiz
18	110-5052	6	Screw-HHF	35	110-5050	4	Screw-HHF
				36	3234-42	2	Screw-HHF



LH Single Turret Body Assembly No. 108-3725


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	95-9200	1	Plug	9	95-9193	1	Cap-Diaphragm
2	95-9198	1	O-Ring	10	95-9192	1	Body-Split Eyelet
3	95-9197	1	E-Clip	11	95-9191	1	O-Ring
4	95-9199	2	O-Ring	12	99-0811	1	Screw-Clamp
5	108-3264	1	Seal-Viton	13	99-0812	1	Clamp-Upper
6	108-3265	1	O-Ring-Viton	14	99-0814	1	Pin-Pivot
7	95-9196	1	Turret	15	95-9201	1	Shank-Hose
8	41003	1	Diaphragm	16	322-3	1	Screw-HH



Double Turret Body Assembly No. 108-3727

Ref.	Part Number	Qty.	Description
1	95-9200	1	Plug
2	95-9198	1	O-Ring
3	95-9197	1	E-Clip
4	95-9199	2	O-Ring
5	108-3264	1	Seal-Viton
6	108-3265	1	O-Ring-Viton
7	95-9196	1	Turret
8	41003	1	Diaphragm


Ref.	Part Number	Qty.	Description
9	95-9193	1	Cap-Diaphragm
10	95-9192	1	Body-Split Eyelet
11	95-9191	1	O-Ring
12	99-0811	1	Screw-Clamp
13	99-0812	1	Clamp-Upper
14	99-0814	1	Pin-Pivot
15	95-9202	1	Shank-Hose
16	322-3	1	Screw-HH



RH Single Body Turret Assembly No. 108-3726


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	95-9200	1	Plug
2	95-9198	1	O-Ring
3	95-9197	1	E-Clip
4	95-9199	2	O-Ring
5	108-3264	1	Seal-Viton
6	108-3265	1	O-Ring-Viton
7	95-9196	1	Turret
8	41003	1	Diaphragm

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
9	95-9193	1	Cap-Diaphragm
10	95-9192	1	Body-Split Eyelet
11	95-9191	1	O-Ring
12	99-0811	1	Screw-Clamp
13	99-0812	1	Clamp-Upper
14	99-0814	1	Pin-Pivot
15	95-9201	1	Shank-Hose
16	322-3	1	Screw-HH



Boom Mounting Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	119-4993-03	2	Bracket-Pivot	11	110-5050	16	Screw-HHF
2	108-3471-03	4	Hinge	12	104-8301	16	Nut-HF, NI
3	100-8541	4	Bushing-A Arm	13	108-3748	2	Screw-HHF
4	108-3436	2	Pin-Clevis	14	108-3444	4	Retainer-Spring
5	3290-468	2	Pin-Cotter	15	104-8300	2	Nut-HF, NI
6	110-5054	4	Washer-Flat	16	108-3440	4	Spring-Breakaway, Boom
7	108-3738	4	Screw-HH	17	302-5	8	Fitting-Grease
8	3296-15	4	Nut-Lock, NI	18	108-3459	4	Boot-Hinge
9	108-3419	2	Pivot Pin ASM	19	120-8541	4	Dampener-Hinge
10	108-3605	8	Plate-Backing				



Left and Right Hand Boom Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	108-3524-03	1	Boom-RH	13	240-3	4	Grommet-Rubber
2	108-3525-03	1	Boom-LH	14	108-3721	2	Hose-Boom
3	119-9368	4	Block Slide	15	95-9186	8	Cap
4	108-3725	2	LH Single Body Turret ASM	15:1	40998	1	Seat-Gasket
5	108-3727	4	Double Turret Body ASM	16	95-9187	16	Cap-Blank
6	108-3726	2	RH Single Body Turret ASM	16:1	40998	1	Seat-Gasket
7	104-8300	8	Nut-HF, NI	17	107-8650	2	Conduit-Convolutd
8	108-3728	2	Hose-Boom	18	3290-378	6	Tie-Cable
9	40506	4	Hose-Jumper	19	131-3790	1	Hose-Boom
10	2412-129	18	Clamp-Hose	20	127-9769	1	Hose-Supply
11	119-9369	8	Screw-HHF	22	104-8904	2	Decal-Grasp Boom Here
12	108-3439	2	Tee	99	119-9434	1	Decal-Magnetic

Attachments and Accessories

For 41240 Multi Pro WM Turf Sprayer

Product Name	Model/Part
Premium ATF (Drum).....	108-1185
Premium ATF (Pail)	108-1186
Premium All Purpose Grease (Tube)	108-1190
License Plate Kit.....	120-8506
Covered Boom Spring Upgrade Kit.....	120-8508
Premium Engine Oil 10w30 (55 Gal).....	121-6392
Premium Engine Oil 10w30 (5 Gallon Pail)	121-6393
Foam Marker Finishing Kit.....	125-8121
Fan Kit (EFI, Gas Engine Only).....	127-9719
Lance Suction Assembly	127-9826
Sonic Boom Finish Kit.....	130-8228
Multi Pro WM Turf Sprayer Finishing Kit (Automatic).....	131-3301
Multi Pro WM Turf Sprayer Finishing Kit (Manual).....	131-3302
Finishing Kit, Foam Marker for Multi Pro WM Turf Sprayer.....	136-0459
Rear Work Light Kit.....	41010
Single Nozzle Kit.....	41023
Hand Spray Wand Kit	41118
Pro Foam Concentrate (4 x 1 Gallon)	41157
EU Compliance Kit.....	41200
Jackstand Kit	41216
Ultra Sonic Boom Leveling Kit	41219
Tank Clean Rinse Kit	41241
Chemical Pre-Mix Kit, Multi Pro WM Turf Sprayer.....	41244
Electric Hose Reel Kit	41245
Foam Marker Kit, Serial number 400000000 and After Multi Pro 1750, 5800, and WM Turf Sprayer.....	41249
Drift Reduction Boom Shroud Kit	41602
Pro-Foam.....	41607



Count on it.