

EU Declaration of Conformity

The Toro Company®, 8111 Lyndale Ave. South, Bloomington, MN, USA, declares that the following unit(s):

| Model No. | Serial No. | Product Description | Invoice Description |
|-----------|------------------|---------------------|-------------------------------|
| 23511 | 400000000 and Up | 18in Turf Seeder | 18IN MECHANICAL OVERSEEDER |

Conform(s) to the following directives:

2006/42/EC (Machinery Safety), 2014/30/EU (EMC)

This declaration has been issued under the sole responsibility of the manufacturer.

The object of the declaration is in conformity with relevant Union harmonization legislation.

Certified:



Joe Hager
Sr. Engineering Manager
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
December 18, 2017

Authorized Representative:

Marcel Dutrieux
Manager European Product Integrity
Toro Europe NV
Nijverheidsstraat 5
2260 Oevel
Belgium

Tel. +32 16 386 659



EU Specifications

Machine Power, Mass, and Vibration Data

| Model | Nominal Power (kW) | Machine Mass [‡] (kg) | Hand/Arm Vibration (m/s ²) [*] | | Uncertainty |
|-------|--------------------|--------------------------------|---|------------------|-------------|
| | | | Left Hand Level | Right Hand Level | |
| 23511 | 3.6 | 78 | 4.4 | 3.5 | 2.2 |

[‡] With empty tanks in the normal operating configuration

^{*} Determined in accordance with EN ISO 5349-1:2001

Machine Sound Data

| Model | Sound Pressure (dBA) ¹ | | Sound Power (dBA) ² | |
|-------|-----------------------------------|-------------|--------------------------------|-------------|
| | Level | Uncertainty | Level | Uncertainty |
| 23511 | 90 | 1 | 100 | 1 |

¹ A-weighted levels, as measured at the operator position, determined in accordance with ISO 11201: 2010

² Determined in accordance with ISO 3744: 1995



BG: За да получите копие от този документ на вашия език, отидете на www.toro.com/en-us/pages/manuals/default.aspx.

CS: Kopii tohoto dokumentu ve svém jazyce získáte na adrese www.toro.com/en-us/pages/manuals/default.aspx.

DA: For at indhente en kopi af dette dokument på dit sprog skal du besøge www.toro.com/en-us/pages/manuals/default.aspx.

DE: Ein Exemplar dieses Dokuments in Ihrer Sprache erhalten Sie unter www.toro.com/en-us/pages/manuals/default.aspx.

EL: Για να λάβετε αντίγραφο του εγγράφου αυτού στη γλώσσα σας μεταβείτε στη διεύθυνση www.toro.com/en-us/pages/manuals/default.aspx.

EN: To obtain a copy of this document in your language, go to www.toro.com/en-us/pages/manuals/default.aspx.

ES: Puede obtener una copia de este documento en su idioma en www.toro.com/en-us/pages/manuals/default.aspx.

ET: Dokumendist enda keeles koopia saamiseks külastage veebilehte www.toro.com/en-us/pages/manuals/default.aspx.

FI: Tästä asiakirjasta saa omakielisen version osoitteesta www.toro.com/en-us/pages/manuals/default.aspx.

FR: Pour vous procurer une copie de ce document dans votre langue, rendez-vous sur www.toro.com/en-us/pages/manuals/default.aspx.

HU: Ha szüksége van a dokumentum egy példányára a saját nyelvén, letöltheti azt a www.toro.com/en-us/pages/manuals/default.aspx oldalról.

IT: La copia del presente documento nella vostra lingua è disponibile su www.toro.com/en-us/pages/manuals/default.aspx.

LT: Norėdami gauti šio dokumento kopiją savo kalba, apsilankykite www.toro.com/en-us/pages/manuals/default.aspx.

LV: Lai iegūtu šī dokumenta kopiju savā valodā, lūdzu, dodieties uz www.toro.com/en-us/pages/manuals/default.aspx.

NL: Voor een exemplaar van dit document in uw eigen taal, gaat u naar: www.toro.com/en-us/pages/manuals/default.aspx.

NO: For å få en kopi av dette dokumentet på ditt språk, gå til www.toro.com/en-us/pages/manuals/default.aspx.

PL: Aby uzyskać kopię dokumentu dla swojego języka, należy przejść na stronę www.toro.com/en-us/pages/manuals/default.aspx.

PT: Para obter uma cópia deste documento no seu idioma, vá a www.toro.com/en-us/pages/manuals/default.aspx.

RO: Pentru a obține un exemplar al prezentului document în limba dumneavoastră, vizitați www.toro.com/en-us/pages/manuals/default.aspx.

SK: Ak chcete získať kópiu tohto dokumentu vo svojom jazyku, prejdite na adresu www.toro.com/en-us/pages/manuals/default.aspx.

SL: Za izvod tega dokumenta v vašem jeziku obiščite spletno stran www.toro.com/en-us/pages/manuals/default.aspx.

SV: Gå in på www.toro.com/en-us/pages/manuals/default.aspx om du vill ha ett exemplar av det här dokumentet på ditt språk.