

Count on it.

Parts Catalog

27-inch Rear Roller Brush Kit Reelmaster® 3100-D and 7000-D Edge Series Cutting Unit

Model No. 03243



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

rive Assembly	4
oller Brush Assembly	5
late Assembly	6



Drive Assembly

Ref.	Part Number	Qty.	Description
1	112-6967	1	O-Ring
2	108-4203	1	Housing-Bearing, Drive
3	240-7	1	Grommet-Rubber
4	3274-7	2	Screw-HSH
6	125-2788	1	Shaft-Drive, LH
7	125-2787	1	Shaft-Drive, RH
8	104-1843	1	Fitting-Grease, 90 DEG



Roller Brush Assembly

				•			
Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	127-7134	1	Non Driven Bearing Housing	4:5	3296-2	2	Nut-Lock, NI
			ASM	4:6	137-0844	1	Brush-Roller, Rear (HD) ●
1:2	95-0707	1	Bearing-Aligning, Self	5	104-8300	4	Nut-HF, NI
1:3	106-8530	1	Seal-Grease	6	108-4480	2	Bracket-Mounting
1:4	302-5	1	Fitting-Grease	7	108-4172	2	Seal-Excluder
2	127-7138	1	Driven Bearing Housing	8	94-6936	4	Washer-Hardened
			ASM	9	322-16	4	Screw-HH
2:2	95-0707	1	Bearing-Aligning, Self	10	127-7139	1	Spacer-Pulley, Driven
2:3	106-8530	2	Seal-Grease	11	112-6957	2	Washer-Hardened
2:4	302-5	1	Fitting-Grease	12	115-0821	1	Pulley-Driven, RRB (5-Rib)
3	107-8844	1	O-Ring	13	104-8301	1	Nut-HF, NI
4	133-8231	1	Roller Brush ASM	99	131-3233	1	Groomer/RRB Seal Kit ●
4:2	115-0813	1	Brush-Roller	99:1	95-0707	2	Bearing-Aligning, Self
4:3	115-0838	1	Brush-Roller (High HOC) ●	99:2	106-8530	3	Seal-Grease
4:4	105-9632	2	Bolt-J	99:3	108-4172	2	Seal-Excluder

Optional Equipment




Plate Assembly

Ref.	Part Number	Qtv	Description	Ref.	Part Number	Otv	Description
1	3230-23	2	•	12	114-9397	41	<u> </u>
Į.			Screw-CARR	· -		!	Idler Pulley ASM
2	112-6950	3	Screw-CARR	12:2	110-1701	1	Bearing
3	115-0814-03	1	Plate-Brush, 7 Inch	12:3	32151-60	1	Ring-Snap
4	322-1	2	Screw-HH	13	115-0830	1	Brush Cover ASM
5	3256-45	4	Washer-Flat	13:2	108-0989	2	Screw-Set
6	3296-47	6	Nut-Lock, NI	14	104-8300	2	Nut-HF, NI
7	115-0834	1	Idler Arm ASM	15	27-0411	1	Screw-Shoulder
7:2	125-8775	1	Bushing-Flange	16	66-9302	1	Screw-HHF, Whiz
8	115-0826	1	Spacer-Idler	17	115-0820	1	Pulley-Driver, 5-Rib, 7-Inch
9	115-0839	1	Spring-Idler				RRB
10	5-4460	1	Washer-Pivot	18	108-4477	1	Spacer
11	115-0828	1	Belt-Brush, 7-Inch	99	114-5446	1	Tool-Alignment ●



