



**Count on it.**

**Parts Catalog**

**Auxiliary Hydraulic Kit  
Groundsmaster® 3200 or 3300 Series  
Traction Unit**

Model No. 31966



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Auxiliary Hydraulic Kit Assembly ..... 4  
Auxiliary Manifold Assembly No. 140-3061 ..... 6  
Auxiliary Hydraulic Wire Harness Assembly No. 122-1774 ..... 8


# Auxiliary Hydraulic Kit Assembly



## Auxiliary Hydraulic Kit Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-3099-03	1	Support-Manifold	8	3230-2	2	Bolt-CARR
2	3234-5	3	Screw-HHF	10	109-9376	1	Receptacle-12V
3	140-3061	1	Auxiliary Manifold ASM	11	122-1774	1	Harness-Wire, Aux HYD
4	131-6057	1	Fitting-Quick Coupling	12	100-1535	2	Switch-Rocker, (On)-Off-(On)
5	131-6058	1	Fitting-Quick Coupling	13	3290-378	2	Tie-Cable
6	140-3098	1	Hydraulic Tube ASM				
7	104-8300	2	Nut-HF, NI				

# Auxiliary Manifold Assembly No. 140-3061




# Auxiliary Manifold Assembly No. 140-3061 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Manifold Block ●	7	95-3209	2	Fitting-Thread, Straight
3	HYD13974	1	Valve,3 Position,4 Way,Open Center	7:1	237-79	2	O-Ring
4	119-4619	2	Coil-Solenoid	8	340-2	2	Fitting-Straight
5	117-8316	1	Spacer-E Coil	8:1	237-22	1	O-Ring
6	110-2634	1	Nut-Coil	8:2	237-42	1	O-Ring

● Not serviced separately

# Auxiliary Hydraulic Wire Harness Assembly No. 122-1774



# Auxiliary Hydraulic Wire Harness Assembly No. 122-1774 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	218-578	1	Fuse-Blade, 10 Amp
8	99-7431	1	Fuse-Thermal, 15 Amp
9	32180-019	1	Cover-Fuse, Single

**Notes:**

**Notes:**



**Count on it.**