



# Customer Bulletin

Commercial Products

May 28, 2020

## Maximum Fuel Tank Level

Greensmaster 1000 Series

**Bulletin Type** Information Only

**Status** Final Release

**Affected Units**

Model Number(s)	Serial Number(s)
04820	400000000 through 999999999
04830	
04840	
04850	
04860	

**Situation** Important Information

Exceeding the maximum fuel level in the fuel tank could cause the following to occur:

- Failure of the evaporative-emission-control (EEC) system (i.e., the charcoal canister in the tank cap)
- Fuel leaking from the cap vent when the machine is tipped

**Corrective Action** When filling the fuel tank, do not add fuel beyond the full-tank level; refer to [Service Instructions \(Page 2\)](#).

**Safety Awareness** Follow reasonable and customary safety precautions.

**References** Download the latest versions of the *Operator's Manual*, *Parts Catalog*, *Service Manual*, *Electrical Schematic*, and *Hydraulic Schematic* by visiting [www.Toro.com](http://www.Toro.com) and searching for your machine from the Manuals link on the home page.


Resource	Search Term
<i>Operator's Manual</i>	Model and serial number for the machine.

# Service Instructions

- Preparing the Machine**
1. Park the machine on a level surface.
  2. Engage the parking brake.
  3. Shut off the engine.

- Filling the Fuel Tank**
1. Clean around the fuel-tank cap and remove the cap from the tank.
  2. Add the recommended fuel to the full level (i.e., to the bottom of the fuel gauge) in the fuel tank.

**Important: Do not fill the tank above this level.**



**Figure 2**

1. Fuel gauge
2. Full-tank level
3. Install the fuel-tank cap and wipe up any spilled fuel.



[Filling the Fuel Tank Animation](#)