



Count on it.

Parts Catalog

3WD Kit

Greensmaster® 3360 or 3370 eTriFlex Traction Unit

Model No. 04504—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

3 Wheel Drive Assembly 4

Hub Kit Assembly No. 147-3131 5


3 Wheel Drive Gearbox Assembly 6

Direct Drive REM/INV Assembly No. 144-6662 7

REM Direct Drive Assembly No. 161-0342 8

Inverter Direct Drive Assembly No. 161-0343 9

Inverter Controller Assembly 10




3 Wheel Drive Assembly

Ref.	Part Number	Qty.	Description
1	92-9250	1	Seal-Grease
2	147-3131	1	Hub Assembly, 3Wd
3	302-40	1	Fitting-Grease, 90 DEG
4	3255-7	1	Washer-Lock/EXT
5	133-5848	1	O-Ring
6	33096-00	4	Washer-Flat
7	139-8302	2	Bearing-Thrust, 35 X 52 X 2
8	32151-10	1	Ring-Retaining
9	139-8300	1	Washer-Wave, Spring 2.125
10	121-9228	1	Plug-Dust Cap
11	132-9999	1	Fitting-Straight


Ref.	Part Number	Qty.	Description
11:1	237-79	1	O-Ring
12	133-0000	1	Hose-Vent, Formed
13	106-8829	1	R Clamp-Double
14	3234-17	1	Screw-HHF
15	140-5024	1	Screw-HHF
16	104-8300	1	Nut-HF, NI
17	33116-035	4	Screw-HH
18		1	Gearbox ASM 3Wd ●
19	139-8303	4	Washer-Thrust
99	122-0255	1	Fuse-Maxi, 35 Amp-58V
99	3290-378	1	Tie-Cable

● Not serviced separately



Hub Kit Assembly No. 147-3131


Ref.	Part Number	Qty.	Description
1	92-9250	1	Seal-Grease
2	139-8330	1	Hub ASM
2:1	121-9231-03	1	Hub ASM, Welded
2:2	85-6540	4	Stud-Drive
2:3	92-9167	3	Clutch-Roller
3	302-40	1	Fitting-Grease, 90 DEG
4	3255-7	1	Washer-Lock/EXT
5	139-8302	2	Bearing-Thrust, 35 X 52 X 2
6	139-8300	1	Washer-Wave, Spring 2.125
7	139-8303	4	Washer-Thrust
8	32151-10	1	Ring-Retaining
9	133-5848	1	O-Ring
10	121-9228	1	Plug-Dust Cap



3 Wheel Drive Gearbox Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1		1	Housing ASM ●	13	137-8073	1	Washer-Wave, Spring 47MM
1:2	139-8572	1	Bearing-Ball	15	105-2409	17	Screw-HSH
2	139-8327	1	Axle Shaft ASM	16	144-6662	1	Rem/Inv Assy, Dir Drv
2:1	137-8065	1	Shaft-Axle	17	103-5895	1	O-Ring
2:2	139-8572	1	Bearing-Ball	18	137-7851	1	Key
2:3	139-8322	1	Washer-Flat	21	137-8061	1	Gear-Spur, 23T, Crowned
2:4	137-8064	1	Gear-Spur, 133T	22	3245-20	1	Screw-Set
2:5	137-8184	1	Key-Square	23	48-7850	1	Screw- HSH
3	145-0087	1	Spacer	25	353-988	1	Plug-Hex
4	145-0089	1	Spacer-Seal	25:1	237-79	1	O-Ring
6	32151-102	1	Ring-Retaining, External	26	137-8077	1	Washer-Wave, Spring 80MM
7	133-4885	1	Ring-Retaining, Snap, Int	27	137-8181	1	Electric Motor Gasket
8	137-8187	1	Seal-Shaft	28	137-8182	1	Housing Gasket
9	139-8329	1	Spur Gear ASM	29	353-989	2	Plug-Hex, Hollow
9:1	137-8063	1	Gear-Spur, 22T	29:1	237-42	1	O-Ring
9:2	137-8066	2	Ball Bearing	32	136-2667	1	Pin-Dowel
9:3	137-8062	1	Gear-Spur, 137T				
9:4	137-8185	1	Key-Square				
12	87-1910	2	Pin-Dowel				


● Not serviced separately



Direct Drive REM/INV Assembly No. 144-6662

Ref.	Part Number	Qty.	Description
3	144-6692	6	Screw-Tph
4	144-6738	1	O-Ring-Formed, Controller
5	145-5053	1	Oil-Super Lube,Dielectric,1Qt ●
6	139-8597	1	Seal-Oil
8	161-0342	1	Rem-Direct Drive
9	161-0343	1	Inverter-Direct Drive

● Not illustrated




REM Direct Drive Assembly No. 161-0342

Ref.	Part Number	Qty.	Description
1		1	Motor-W/O Cntrlr ■
2		1	Service Kit-Controller & Motor ■
2:1	144-6738	1	O-Ring-Formed, Controller
2:2	144-6723	1	Desiccant-Silica Gel, 1/2 Gram
2:3	144-6692	6	Screw-Tph
2:4	161-0309	1	Grease-Dielectric ●

● Not illustrated

■ Not serviced separately




Inverter Direct Drive Assembly No. 161-0343

Ref.	Part Number	Qty.	Description
1		1	Inverter/Cntrlr ASM ■
2		1	Service Kit-Controller & Motor ■
2:1	144-6738	1	O-Ring-Formed, Controller
2:2	144-6723	1	Desiccant-Silica Gel, 1/2 Gram
2:3	144-6692	6	Screw-Tph
2:4	161-0309	1	Grease-Dielectric ●

● Not illustrated

■ Not serviced separately



Inverter Controller Assembly

Ref.	Part Number	Qty.	Description
9	32160-698	1	Connector-Deutsch, Dtp, 2M
10	32160-315	1	Connector
11	144-6691	1	Ferrule-Wire Seal
12	119-7477	1	Nut-Fitting, Ferrule -8
13	119-7497	1	Backshell-90 Degree
14	32180-083	1	Wedge
15	32180-084	1	Wedge
16	3290-378	1	Tie-Cable
17	138-8962	1	Tubing-Convolutd Slit

Notes:



Count on it.