Installation Instructions

Installation

Loose Parts

Use the chart below to verify that all parts have been shipped.

Description	Qty.	Use
No parts required	_	Prepare the machine.
Floormat Plastic plug	1 8	Install the floormat.

Preparing the Machine

Gas Models Only

- Park the machine on a level surface.
- 2. Disengage the blade-control switch.
- 3. Move the motion-control levers outward to the NEUTRAL-LOCK position.
- 4. Shut off the engine and remove the key.
- 5. Wait for all moving parts to stop.
- Allow machine components to cool.

Electric Models Only

- 1. Park the machine on a level surface.
- 2. Disengage the blade-control switch.
- 3. Move the motion-control levers outward to the NEUTRAL position.
- 4. Engage the parking brake.
- Shut off the machine and remove the key.
- 6. Wait for all moving parts to stop.
- 7. Allow machine components to cool.
- 8. Remove the battery packs from the machine.

Installing the Floormat

Secure the floormat to the platform using the plastic plugs.




Figure 1

g467787




Figure 2

g467788