




Brush Cutter
Walk Behind

Model No. 23521—Serial No. 40000000 and Up
Model No. 33521—Serial No. 40000000 and Up

Electrical Schematic

23521 and 33521
122-0924 Rev B
1 of 1



g467407