

Count on it.

Parts Catalog

Flex-Force Power System™ 60V MAX Leaf Blower

Model No. 51827T—Serial No. 324000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Flex-Force Power System 60V MAX Leaf Blower Assembly	. 4
Attachments and Accessories	6

Flex-Force Power System 60V MAX Leaf Blower Assembly



Flex-Force Power System 60V MAX Leaf Blower Assembly (continued)

R	ef. Part Numbe	r Qty.	Description	Ref.	Part Number	Qty.	Description
	3 147-6578	1	60V Axial Blower Blow Tube	17	163-2812	1	60V Blower Fan Service
4	4 147-6579	1	60V Axial Blower Reducer				ASM
			Nozzle	18	147-6599	1	60V Axial Blower Battery
(9 163-2814	1	Blowtube Release Service				Latch
			Kit	31	163-2816	1	60V Axial Blower Hardware
1	6 163-2815	6	60V Axial Blower Isolator Kit				Kit

3467-109A

Attachments and Accessories

For 51827T Flex-Force Power System 60V MAX Leaf Blower

Product Name	Model/Part
Charger-Battery 60V 1.0AMP	88901
Charger-Battery 60V 2.0AMP	88902
Charger-Battery 60V 5.4AMP	88905
60V Six Pod Battery Charger 12 AMP	66550
Battery-LI-ION, 60V 2.0AH, 108WH	88920
Battery-LI-ION, 60V 2.5AH, 135WH	88925
Battery-LI-ION, 60V 4.0AH, 216WH	88941
Battery-LI-ION, 60V 5.0AH, 270WH	88950
Battery-LI-ION, 60V 6.0AH, 324WH	88960
Battery-LI-ION, 60V 7.5AH, 405WH	88975
Battery-LI-ION, 60V 8.0AH, 432WH	88980
Battery -LI-ION, 60V 10 AH, 540WH	66910
Battery -LI-ION, 60V 12 AH, 648WH	66912



