



**Count on it.**

**Parts Catalog**

**GrandStand® Mower**

**With 60in TURBO FORCE® Cutting Unit**

Model No. 72509—Serial No. 416500000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                       |    |
|---------------------------------------|----|
| 60 Inch Deck Assembly                 | 4  |
| Deck Decal Assembly No. 139-8101      | 6  |
| Spindle Assembly No. 137-9780         | 8  |
| Deflector Assembly No. 120-2451       | 10 |
| Ground Drive Assembly                 | 12 |
| LH Transmission Assembly No. 138-5838 | 14 |
| RH Transmission Assembly No. 138-5839 | 16 |
| Overflow Hose Assembly                | 18 |
| Motion Control Assembly               | 20 |
| Control Handle Assembly No. 132-5157  | 22 |
| Control Handle Assembly No. 132-5158  | 24 |
| Parking Brake Assembly                | 26 |
| Deck Lift Assembly                    | 28 |
| HOC Lever Assembly No. 161-6735       | 30 |
| HOC Link Assembly No. 130-6615        | 32 |
| Frame Assembly                        | 34 |
| Wheel and Bearing Assembly            | 36 |
| Platform Assembly                     | 38 |
| Engine Assembly                       | 40 |
| Fuel Tank Assembly                    | 42 |
| Electrical Assembly                   | 44 |
| Attachments and Accessories           | 46 |


# 60 Inch Deck Assembly



## 60 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 139-8101           | 1           | 60 Deck ASM                | 26          | 104-8300           | 2           | Nut-HF, NI              |
| 2           | 137-9780           | 3           | Spindle ASM                | 27          | 108-4052           | 1           | Spring-Torsion          |
| 3           | 138-6059           | 3           | Sheave-Drive, Blade        | 28          | 98-7912            | 2           | Tube-Spanner            |
| 4           | 109-6982           | 4           | Wireform-Cover             | 29          | 104-0892           | 2           | Spacer-Axle, Rear       |
| 5           | 109-6936           | 2           | Cover-Belt, LH             | 30          | 98-5967            | 1           | Spacer-Wheel            |
| 6           | 114-5204-01        | 1           | Bracket-Wheel, LH          | 31          | 323-23             | 2           | Screw-HH                |
| 7           | 114-5208-01        | 1           | Bracket-Wheel, Center      | 32          | 145-3450           | 1           | Gs Torsion Idler ASM li |
| 8           | 114-5213-01        | 1           | Bracket-Wheel, RH          | 33          | 127-1971           | 1           | Pulley-Idler            |
| 9           | 1-603299           | 4           | Roller-Scalp, Anti         | 34          | 323-20             | 1           | Screw-HH                |
| 10          | 117-5758-03        | 3           | Bracket-Cover              | 35          | 114-1908-01        | 1           | Skid                    |
| 11          | 117-9701-01        | 1           | Baffle ASM                 | 36          | 130-6647-01        | 1           | Bracket-Skid            |
| 12          | 139-8106-01        | 1           | Plate-Baffle, Formed [red] | 37          | 109-2872           | 1           | Spacer-Pulley           |
| 13          | 130-6594-01        | 1           | Baffle-Discharge           | 38          | 3231-44            | 1           | Screw-CARR              |
| 14          | 3231-2             | 8           | Bolt-CARR                  | 39          | 136-5404           | 1           | Pulley-Idler, Flat      |
| 15          | 104-8301           | 47          | Nut-HF, NI                 | 40          | 132-5153           | 1           | Shield-Dust             |
| 16          | 120-2451           | 1           | Deflector ASM              | 41          | 3231-25            | 1           | Bolt-CARR               |
| 17          | 140-1240           | 3           | Blade                      | 42          | 100-4852           | 1           | Washer-Hardened         |
| 18          | 131-1123           | 1           | Belt-V                     | 43          | 94-7582            | 1           | Bolt-Shoulder           |
| 19          | 32144-70           | 3           | Screw-HWHTF                | 44          | 137-9784           | 3           | Guard-Bottom            |
| 20          | 92-1624            | 6           | Screw-HWH Thd Form         | 45          | 103-1330           | 3           | Guard-Bearing, Top      |
| 21          | 109-6658           | 1           | Nut-Flange, NI             | 46          | 138-6045           | 3           | Shaft-Spindle           |
| 22          | 137-9787           | 3           | Bushing-Hex                | 47          | 103-2802           | 3           | Washer                  |
| 23          | 109-9220           | 3           | Screw-Sems                 | 48          | 116-7306           | 3           | Nut-Hex                 |
| 24          | 105-4622           | 1           | Spacer                     | 49          | 109-1092           | 1           | Knob                    |
| 25          | 322-50             | 2           | Screw-HH                   |             |                    |             |                         |

# Deck Decal Assembly No. 139-8101



## Deck Decal Assembly No. 139-8101 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------|
| 2           | 133-4604           | 2           | Decal-Danger       | 5           | 131-3507           | 1           | Decal-Belt, Tension (CE)  |
| 3           | 107-1619           | 1           | Decal              | 6           | 138-1147           | 1           | Decal - Baffle Adjustment |
| 4           | 116-8283           | 1           | Decal-Torque, Bolt | 7           | 112-3858           | 1           | Decal-Scalp, Anti         |

# Spindle Assembly No. 137-9780





## Spindle Assembly No. 137-9780 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 116-0720           | 2           | Bearing-Ball       |
| 3           | 138-6042           | 1           | Spacer-Bearing     |

# Deflector Assembly No. 120-2451



## Deflector Assembly No. 120-2451 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         | 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 2           | 106-3246-01        | 1           | Deflector          | 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 3           | 106-3248-03        | 1           | Strap-Discharge    | 7           | 104-8301           | 4           | Nut-HF, NI         |
| 4           | 110-0759           | 1           | Deflector-Rubber   |             |                    |             |                    |

# Ground Drive Assembly




## Ground Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 138-5838           | 1           | LH Transmission ASM        | 20          | 3229-25            | 3           | Screw-CARR             |
| 2           | 138-5839           | 1           | RH Transmission ASM        | 21          | 104-7201           | 3           | Nut-HF, NI             |
| 3           | 131-1131-03        | 1           | Support-Transaxle          | 22          |                    | 1           | Gs Overflow Hose ASM ■ |
| 4           | 93-2569            | 4           | Screw-HHF                  | 23          | 109-0309           | 1           | Hose-Fuel              |
| 5           | 116-4701           | 16          | Screw-HHF                  | 24          | 92-2379            | 1           | Clamp-Hose             |
| 6           | 104-8301           | 18          | Nut-HF, NI                 | 25          | 131-7469           | 1           | Rod-Bypass, RH         |
| 7           | 138-1108-03        | 1           | Plate-Skid                 | 26          | 131-7470           | 1           | Rod-Bypass, LH         |
| 9           | 117-5351           | 1           | Spacer                     | 27          | 108-2992           | 2           | Pin-Hair               |
| 10          | 1-413088           | 1           | Bushing-Lever, Lift        | 28          | 32180-030          | 1           | Clip-Tie               |
| 11          | 131-1175           | 1           | Arm-Idler                  | 29          | 140-1886           | 2           | Wheel And Tire ASM     |
| 12          | 114-0463           | 2           | Washer-Friction, Composite | 29:1        | 140-1887           | 1           | Rim-8 Inch Black       |
| 13          | 110-9981           | 1           | Washer-Plain               | 29:2        | 120-6466           | 1           | Tire                   |
| 14          | 3234-39            | 1           | Screw-HHF                  | 29:3        | 232-27             | 1           | Stem-Valve             |
| 15          | 93-1622            | 1           | Pulley-Idler               | 30          | 242-50             | 8           | Nut-Lug                |
| 16          | 3231-4             | 1           | Screw-CARR                 | 31          | 132-7584           | 2           | Spacer-Hex             |
| 17          | 138-1104           | 1           | Spring-Extension           | 32          | 104-8300           | 2           | Nut-HF, NI             |
| 18          | 131-1124           | 1           | Belt-V                     | 33          | 3290-250           | 2           | Pin-Cotter             |
| 19          | 132-1135           | 1           | Tank-HYD                   | 34          | 2412-129           | 2           | Clamp-Hose             |
| 19:2        | 133-8677           | 1           | Cap-Vented                 | 35          | 3290-378           | 1           | Tie-Cable              |
| 19:5        | 140-9463           | 1           | Strainer-Neck, Removable ● |             |                    |             |                        |

● Not illustrated

■ Not serviced separately

# LH Transmission Assembly No. 138-5838



# LH Transmission Assembly No. 138-5838 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 132-4737           | 1           | Nut-Lock           | 15          | 132-4743           | 1           | Hydro Filter Kit                |
| 2           | 132-4738           | 1           | Fan                | 15:1        | 136-5409           | 2           | Filter                          |
| 3           | 132-4739           | 1           | Pulley             | 15:2        | 136-5410           | 2           | O-Ring                          |
| 5           | 104-3265           | 1           | Pin                | 16          | 137-4109           | 1           | Spring-Torsion                  |
| 6           | 132-4700           | 1           | Lever-Bypass       | 17          | 137-9509           | 4           | Stud-Wheel                      |
| 8           | 133-1468           | 1           | Brake Kit,Left     | 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 8:1         |                    | 1           | O-Ring ●           | 21          | 137-9509           | 1           | Stud-Wheel                      |
| 8:2         |                    | 1           | Arm-Brake ●        | 23          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 8:3         |                    | 1           | Pin-Roll ●         | 24          | 139-5588           | 1           | Axle                            |
| 8:4         |                    | 1           | Shaft-Brake ●      | 25          | 139-5589           | 2           | Drain Bolt                      |
| 8:5         |                    | 1           | Actuator-Brake ●   | 26          | 139-5590           | 1           | Expansion Fitting               |
| 8:6         |                    | 1           | Disc-Brake ●       | 27          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 8:7         |                    | 1           | Shoe-Brake ●       |             |                    |             |                                 |
| 8:8         |                    | 1           | Shim Kit ●         | 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 9           | 132-4735           | 1           | Cap-Oil            | 28:3        |                    | 1           | M8*20 Flange Bolt ●             |
| 11          | 136-5401           | 1           | Lever-Control, RH  |             |                    |             |                                 |

● Not serviced separately

# RH Transmission Assembly No. 138-5839





# RH Transmission Assembly No. 138-5839 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 132-4737           | 1           | Nut-Lock           | 11          | 136-5401           | 1           | Lever-Control, RH               |
| 2           | 132-4738           | 1           | Fan                | 15          | 132-4743           | 1           | Hydro Filter Kit                |
| 3           | 132-4739           | 1           | Pulley             | 15:1        | 136-5409           | 2           | Filter                          |
| 5           | 104-3265           | 1           | Pin                | 15:2        | 136-5410           | 2           | O-Ring                          |
| 6           | 132-4700           | 1           | Lever-Bypass       | 16          | 137-4109           | 1           | Spring-Torsion                  |
| 8           | 133-1462           | 1           | RH Brake Kit       | 17          | 137-9509           | 4           | Stud-Wheel                      |
| 8:1         |                    | 1           | O-Ring ●           | 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 8:2         |                    | 1           | Arm-Brake ●        | 19          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 8:3         |                    | 1           | Pin-Roll ●         | 20          | 139-5588           | 1           | Axle                            |
| 8:4         |                    | 1           | Shaft-Brake ●      | 21          | 139-5589           | 2           | Drain Bolt                      |
| 8:5         |                    | 1           | Actuator-Brake ●   | 22          | 139-5590           | 1           | Expansion Fitting               |
| 8:6         |                    | 1           | Disc-Brake ●       | 23          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 8:7         |                    | 1           | Shoe-Brake ●       | 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 8:8         |                    | 1           | Shim Kit ●         | 28:3        |                    | 1           | M8*20 Flange Bolt ●             |
| 9           | 132-4735           | 1           | Cap-Oil            |             |                    |             |                                 |

● Not serviced separately

# Overflow Hose Assembly



## Overflow Hose Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 145-3444           | 1           | Hose-Hydraulic     | 4           | 147-0201           | 1           | R-Clamp            |
| 2           | 139-4055           | 1           | Fitting Tee        | 5           | 147-0204           | 1           | Hydraulic Hose     |
| 3           | 147-0202           | 1           | Hydraulic Hose     | 6           | 145-3599           | 4           | Hose Clamp         |

# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 132-5157           | 1           | LH Control Handle ASM | 9:5         | 1-603807           | 1           | Spring-Return, Neutral    |
| 2           | 132-5158           | 1           | RH Control Handle ASM | 10          | 138-4620           | 1           | RH Control Rod ASM        |
| 3           | 119-0222           | 2           | Grip                  | 10:1        | 138-4647           | 1           | Ball Joint-LH             |
| 4           | 103-9928           | 2           | Bearing               | 10:2        | 138-4648           | 1           | Ball Joint-RH             |
| 5           | 120-3288           | 1           | Tab-Pivot, LH         | 10:4        | 3219-3             | 1           | Nut-Hex                   |
| 6           | 3229-1             | 4           | Screw-CARR            | 11          | 3231-28            | 2           | Screw-CARR                |
| 7           | 104-7201           | 6           | Nut-HF, NI            | 12          | 104-8301           | 4           | Nut-HF, NI                |
| 8           | 120-3287           | 1           | Tab-Pivot, RH         | 13          | 3256-24            | 2           | Washer-Plain              |
| 9           | 138-4619           | 1           | LH Control Rod ASM    | 14          | 132-7538           | 1           | Bracket-Adjustment, Speed |
| 9:1         | 138-4647           | 1           | Ball Joint-LH         | 15          | 126-1499           | 2           | Cam                       |
| 9:2         | 138-4648           | 1           | Ball Joint-RH         | 16          | 323-7              | 2           | Screw-HH                  |
| 9:4         | 3219-3             | 1           | Nut-Hex               |             |                    |             |                           |

# Control Handle Assembly No. 132-5157



## Control Handle Assembly No. 132-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 131-3562           | 1           | Bearing-Sleeve     |
| 4           | 323-10             | 1           | Screw-HH           |
| 5           | 104-8301           | 1           | Nut-HF, NI         |
| 6           | 110-7191           | 2           | Washer-Thrust      |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 116-2670           | 1           | Screw-Shoulder     |
| 8           | 104-8300           | 1           | Nut-HF, NI         |
| 9           | 132-5146           | 1           | Spring-Extension   |

# Control Handle Assembly No. 132-5158





## Control Handle Assembly No. 132-5158 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 3           | 104-8301           | 1           | Nut-HF, NI         | 7           | 104-8300           | 1           | Nut-HF, NI         |
| 4           | 323-10             | 1           | Screw-HH           | 8           | 131-3562           | 1           | Bearing-Sleeve     |
| 5           | 110-7191           | 2           | Washer-Thrust      | 9           | 132-5146           | 1           | Spring-Extension   |
| 6           | 116-2670           | 1           | Screw-Shoulder     |             |                    |             |                    |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5170           | 1           | Brake Handle ASM     | 7           | 32144-4            | 2           | Screw-HWH          |
| 2           | 3230-23            | 5           | Bolt-CARR            | 8           | 132-1187           | 1           | Clamp-Cable        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 9           | 132-7582           | 1           | Mount-Cable, Brake |
| 4           | 132-5168           | 1           | RH Brake Caliper ASM | 10          | 1-633268           | 1           | Grip-Lever         |
| 5           | 132-5169           | 1           | LH Brake Caliper ASM | 11          | 131-1195           | 2           | Cable-Brake        |
| 6           | 104-8301           | 2           | Nut-HF, NI           |             |                    |             |                    |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 120-8405-01        | 1           | Shaft-Cross, Front                   | 25          | 3231-7             | 4           | Screw-CARR              |
| 2           | 109-9409           | 2           | Support-Bearing, Cross Shaft (Front) | 26          | 104-8301           | 7           | Nut-HF, NI              |
| 3           | 109-9410           | 2           | Bearing-Cross Shaft, Front           | 27          | 32128-19           | 4           | Nut-HF Lock, Large Flg  |
| 4           | 116-1700           | 4           | Bolt-CARR                            | 28          | 109-9066           | 4           | Yoke-Adjust, Deck       |
| 5           | 99-5107            | 8           | Nut-Lock                             | 29          | 322-47             | 4           | Screw-HH                |
| 6           | 127-0369           | 6           | Bushing                              | 30          | 3218-2             | 8           | Nut-Hex Jam             |
| 7           | 10-8110            | 3           | Washer-Thrust                        | 31          | 130-6589           | 2           | Link-Lift               |
| 8           | 3256-62            | 3           | Washer-Flat                          | 32          | 109-9840           | 2           | Screw-Shoulder, HHF     |
| 9           | 120-8411-01        | 1           | Arm-Lift, RH                         | 33          | 109-9065           | 2           | Screw-HH                |
| 10          | 32151-29           | 3           | Ring-Retaining                       | 34          | 116-2428           | 2           | Bushing-Flanged         |
| 11          | 120-8410-01        | 1           | Arm-Lift, LH                         | 35          | 3256-4             | 2           | Washer-Flat             |
| 12          | 161-6735           | 1           | HOC Lever ASM                        | 36          | 3296-48            | 4           | Nut-Hex                 |
| 13          | 119-6223           | 2           | Washer                               | 37          | 95-6448            | 2           | Spacer                  |
| 14          | 138-4932           | 3           | Nut-Hex Flg                          | 38          | 138-1111           | 1           | Spacer                  |
| 15          | 138-4931           | 3           | Screw-Lock                           | 39          | 132-7581           | 1           | HOC Plate And Decal ASM |
| 16          | 130-6615           | 1           | HOC Link ASM                         | 40          | 138-4887           | 1           | Plate-HOC, Inner        |
| 17          | 3218-6             | 1           | Nut-Jam                              | 41          | 116-4701           | 3           | Screw-HHF               |
| 18          | 98-5975            | 1           | Washer-Belleville                    | 42          | 121-1760           | 2           | Spacer                  |
| 19          | 323-58             | 1           | Bolt-TAP, HH                         | 43          | 116-5584           | 1           | Pin-HOC                 |
| 20          | 116-0886           | 1           | Spring-Extension                     | 44          | 116-0756           | 2           | Deck Lift Chain ASM     |
| 21          | 116-0780           | 4           | Screw-Shoulder, HHF                  | 44:1        | 1-633447           | 1           | Chain-Lift, Deck        |
| 22          | 3256-28            | 4           | Washer-Flat                          | 44:2        | 109-9065           | 1           | Screw-HH                |
| 23          | 127-1948-03        | 2           | Link-Lift                            | 44:3        | 32128-37           | 1           | Nut-HF                  |
| 24          | 137-4129           | 1           | Deck Strut ASM                       | 45          | 130-0742           | 2           | Bolt-Shoulder           |
| 24:2        | 137-4108           | 4           | Bushing-Rubber                       | 46          | 43-0940            | 2           | Spacer                  |
| 24:3        | 108-6544           | 4           | Spacer                               | 47          | 133-1431           | 1           | Spacer-Split            |


# HOC Lever Assembly No. 161-6735



## HOC Lever Assembly No. 161-6735 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 161-6736-01        | 1           | Lift Lever ASM [red] | 8           | 103-1363           | 4           | Rivet               |
| 2           | 136-0530           | 1           | Rod-Latch, Release   | 9           | 614672             | 1           | Screw-Shoulder, HWH |
| 3           | 114-8187           | 1           | Spring-Compression   | 10          | 110-8982           | 1           | Washer-Spring       |
| 4           | 114-1207           | 1           | Washer-Special       | 11          | 104-7201           | 1           | Nut-HF, NI          |
| 5           | 115-2750           | 1           | Knob                 | 12          | 104-8301           | 1           | Nut-HF, NI          |
| 6           | 115-3592           | 1           | Grip                 | 13          | 138-4888           | 1           | Latch-HOC           |
| 7           | 119-2309           | 1           | Bolt-Shoulder        | 14          | 138-4863           | 1           | Plug-Wear           |

# HOC Link Assembly No. 130-6615






## HOC Link Assembly No. 130-6615 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 1-633029           | 1           | Balljoint-Spherical | 4           | 117-5293           | 1           | Nut-Jam            |
| 2           | 117-5291           | 1           | Balljoint-Spherical | 5           | 130-6614           | 1           | Link-Height Of Cut |
| 3           | 3220-6             | 1           | Nut-Jam             |             |                    |             |                    |

# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 131-7431-01        | 1           | Frame                     | 23          | 114-1926           | 4           | Bumper-Rubber                |
| 8           | 140-4283           | 1           | Tower Decal ASM           | 24          | 147-6343-01        | 2           | Caster Fork ASM [red]        |
| 8:2         | 147-7921           | 1           | Decal-Oil Level           | 25          | 1-811010           | 2           | Plug                         |
| 8:4         | 116-8775           | 1           | Decal-Fill, Fuel          | 26          | 1-543509           | 4           | Bearing-Roller, Tapered      |
| 8:5         | 139-2878           | 1           | Decal-Warning             | 27          | 116-5647           | 2           | Seal-Grease                  |
| 8:6         | 131-3526           | 1           | Decal-Controls            | 28          | 1-633508           | 6           | Washer-Bellville             |
| 8:7         | 147-0212           | 1           | Decal - Fuse              | 29          | 103-4882           | 2           | Cap-Grease                   |
| 9           | 3234-42            | 4           | Screw-HHF                 | 30          | 161-3586           | 1           | Engine Guard ASM<br>W/Decals |
| 10          | 104-8301           | 8           | Nut-HF, NI                | 30:2        | 105-8278           | 1           | Decal                        |
| 11          | 131-7455           | 1           | Plate-Striker             | 30:3        | 133-4641           | 2           | Decal-Warning, No Riders     |
| 12          | 3229-11            | 1           | Screw-CARR                | 31          | 1-513658           | 4           | Bumper                       |
| 13          | 104-7201           | 1           | Nut-HF, NI                | 33          | 3230-10            | 2           | Bolt-CARR                    |
| 14          | 105-4886           | 4           | Nut-Tinnerman             | 34          | 3296-51            | 2           | Nut-Lock, NI                 |
| 15          | 3230-5             | 3           | Bolt-CARR                 | 35          | 3290-271           | 2           | Rivet-Pop                    |
| 16          | 104-8300           | 9           | Nut-HF, NI                | 38          | 140-4258           | 1           | Decal-Panel, Control         |
| 17          | 107-3844           | 3           | Washer                    | 48          | 107-3002           | 2           | Washer-Nylon                 |
| 18          | 140-5485           | 2           | Mf Wheel Tire Bearing ASM | 52          | 132-7578-01        | 1           | Guard-Fan, RH                |
| 18:2        | 103-2768           | 2           | Guard-Seal                | 53          | 132-7598-01        | 1           | Guard-Fan, LH                |
| 18:3        | 3296-45            | 1           | Nut-Hex                   | 64          | 119-4061           | 8           | Screw-HHF                    |
| 18:4        | 325-20             | 1           | Screw-HH                  | 77          | 131-3529           | 1           | Decal-Service Aid            |
| 19          | 132-5161-01        | 1           | Tube-Mount, Fuel Tank     | 80          | 133-8062           | 1           | Decal-Spark Arrestor         |
| 20          | 132-1145-03        | 1           | Bracket-Cross             | 86          | 145-3595           | 3           | Dome Panel Plug              |
| 21          | 117-3591           | 2           | Decal-Commercial          |             |                    |             |                              |


# Wheel and Bearing Assembly



## Wheel and Bearing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 1-633585           | 2           | Bearing-Cone, Taper | 4           | 126-5359           | 1           | Caster Axle ASM       |
| 2           | 103-0063           | 2           | Seal-Caster         | 5           | 140-5483           | 1           | Mf Wheel And Tire ASM |
| 3           | 103-3051           | 1           | Spacer-Nut          |             |                    |             |                       |


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8499-03        | 1           | Hinge-Pad                  | 14          | 3231-2             | 2           | Bolt-CARR          |
| 2           | 117-9739           | 1           | Pad-Cushion                | 15          | 3231-27            | 2           | Screw-CARR         |
| 3           | 3256-23            | 4           | Washer-Plain               | 16          | 161-6796-01        | 1           | Platform ASM [red] |
| 4           | 121-7999           | 4           | Screw-HH                   | 17          | 126-7157           | 1           | Mat-Platform       |
| 5           | 114-0463           | 4           | Washer-Friction, Composite | 18          | 3345-771           | 1           | Shield Clamp Kit   |
| 6           | 133-1426           | 2           | Knob                       | 19          | 32144-70           | 2           | Screw-HWHTF        |
| 7           | 116-2886           | 2           | Slide-Bushing              | 20          | 119-8650           | 1           | Pin-Latch          |
| 8           | 3253-4             | 2           | Washer-Lock                | 21          | 114-5348           | 1           | Spring             |
| 9           | 137-4808           | 2           | Nut-Acorn                  | 22          | 1-603175           | 1           | Knob-Ball          |
| 10          | 111044             | 4           | Spacer                     | 23          | 132-7583           | 2           | Bushing-Flanged    |
| 11          | 114-1915-01        | 2           | Link-Pad                   | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3256-4             | 6           | Washer-Flat                | 25          | 323-45             | 2           | Screw-HH           |
| 13          | 3296-59            | 4           | Nut-Lock, NI               |             |                    |             |                    |

# Engine Assembly





## Engine Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           |                    | 1           | Engine-Kawasaki, Fx730V<br>■▲ | 18          | 1-603610           | 1           | Washer-Spring           |
| 1:1         | 1-653313           | 2           | Gasket-Exhaust                | 19          | 94-2413            | 4           | Nut-U                   |
| 1:2         | 114-3549           | 4           | Nut                           | 20          | 131-3550           | 1           | Muffler Guard ASM       |
| 1:5         | 119-5945           | 1           | Element-Filter, Air (Inner) ● | 20:2        | 106-5517           | 1           | Decal-Warning           |
| 1:6         | 119-5944           | 1           | Element-Filter, Air (Outer) ● | 21          | 131-3530-03        | 1           | Bracket-Mounting, Guard |
| 1:7         | 95-9853            | 1           | Bolt (5X18) ●                 | 22          | 106-9758           | 1           | Screw-CARR              |
| 3           | 132-1173           | 1           | Bracket-Muffler, Front        | 24          | 3290-456           | 4           | Washer-Belleville       |
| 4           | 132-1174           | 1           | Bracket-Muffler, Rear         | 25          | 3234-29            | 4           | Screw-HHF               |
| 5           | 33104-025          | 4           | Screw-HHF                     | 28          | 94-2579            | 1           | Decal                   |
| 6           | 133-4633           | 1           | Muffler                       | 29          | 3230-23            | 4           | Bolt-CARR               |
| 8           | 133-4659           | 1           | Hose ASM                      | 30          | 32128-25           | 5           | Nut-HF                  |
| 8:2         | 353-508            | 1           | Plug-HH                       | 31          | 147-1664           | 1           | Throttle ASM            |
| 8:2:1       | 237-42             | 1           | O-Ring                        | 31:1        | 145-6187           | 1           | Lever-Control           |
| 9           | 98-5975            | 4           | Washer-Belleville             | 31:2        | 147-1674           | 1           | Cable-Throttle          |
| 10          | 126-0983           | 4           | Screw-BHTF                    | 32          | 1-603175           | 1           | Knob-Ball               |
| 11          | 131-3586-03        | 1           | Stop-Clutch                   | 33          | 1-807533           | 2           | Bolt-CARR               |
| 12          | 32144-70           | 2           | Screw-HWHTF                   | 34          | 32128-17           | 2           | Nut-Lock, Flange        |
| 13          | 120-8498           | 1           | Pulley                        | 35          | 132-5140           | 1           | Cable-Choke             |
| 14          | 139-7910           | 1           | Clutch-200Cms                 | 36          | 3290-378           | 1           | Tie-Cable               |
| 15          | 1-807259           | 1           | Key                           | 37          | 81-1690            | 1           | Clamp-Cable             |
| 16          | 3212-6             | 1           | Screw-HH                      | 39          | 121-4570           | 1           | Filter-Fuel ●           |
| 17          | 107-4136           | 1           | Washer                        | 40          | 119-5852           | 1           | Filter-Oil ●            |

● Not illustrated

▲ Obtain parts from [www.kawpower.com](http://www.kawpower.com)

■ Not serviced separately


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-7560           | 1           | Fuel Tank ASM         | 2           | 110-8255           | 1           | Hose-Fuel          |
| 1:2         | 46-6560            | 2           | Bushing               | 3           | 98-2952            | 1           | Fitting-Straight   |
| 1:3         | 137-4127           | 1           | Cap-Fuel              | 4           | 132-7576           | 1           | Hose-Fuel          |
| 1:4         | 104-5228           | 1           | Fitting-Elbow, 90 DEG | 5           | 132-7546           | 1           | Fuel Line ASM      |
| 1:5         | 145-6195           | 1           | ASM, Tube-Fuel        |             |                    |             |                    |

# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 145-5228           | 1           | Harness-Wire, Grandstand   | 10          | 322-3              | 2           | Screw-HH                   |
| 1:4         | 109101             | 1           | Fuse-Blade, 20 Amp         | 11          | 115-3864           | 1           | Cable-Battery, Positive    |
| 1:8         | 109355             | 2           | Fuse-Blade, 15 Amp         | 12          | 109-5715           | 2           | Nut-HHF, Smooth            |
| 1:9         | 218-578            | 1           | Fuse-Blade, 10 Amp         | 13          | 139-6367           | 1           | Switch-Rocker, (On)-On-Off |
| 1:10        | 116-0053           | 2           | Cap-Plug                   | 14          | 137-4101           | 1           | Switch-Ignition            |
| 1:11        | 110928             | 1           | Fuse-Blade, 5 Amp          | 15          | 63-8360            | 1           | Key-Ignition               |
| 1:12        | 109103             | 1           | Fuse-Blade, 30 Amp         | 16          | 3253-3             | 1           | Washer-Lock                |
| 2           | 82-2190            | 3           | Switch-Bail                | 17          | 3217-5             | 1           | Nut-Hex                    |
| 3           | 104-8162           | 1           | Battery                    | 18          | 3290-500           | 1           | Screw-PPH                  |
| 4           | 130-6635-01        | 1           | Bracket-Hold Down, Battery | 19          | 3256-14            | 1           | Washer-Flat                |
| 5           | 104-7201           | 2           | Nut-HF, NI                 | 20          | 3296-2             | 1           | Nut-Lock, NI               |
| 6           | 1-633651           | 2           | Bolt-Holddown              | 21          | 1-643275           | 1           | Relay                      |
| 7           | 112-7063           | 1           | Cable-Battery, Black       | 22          | 67-1300            | 1           | Decal                      |
| 8           | 140-1884           | 1           | Module-Meter, Hour         | 30          | 3290-378           | 2           | Tie-Cable                  |
| 9           | 3256-23            | 2           | Washer-Plain               |             |                    |             |                            |

# Attachments and Accessories

## For 72509 GrandStand Mower With 60in TURBO FORCE Cutting Unit

| <b>Product Name</b>                          | <b>Model/Part</b> |
|--|-------------------|
| Speed Setting Tool.....                      | 132-7595          |
| Light Kit.....                               | 133-1437          |
| Electric Accessory Port.....                 | 133-1438          |
| Hydraulic Cap Lock Kit.....                  | 136-5420          |
| Twin Bagger Kit.....                         | 78524             |
| Oil Filter .....                             | 119-5852          |
| Trash Bag Assembly.....                      | 133-1435          |
| HOC Set Blocks.....                          | 133-1439          |
| Strobe Light Kit.....                        | 133-1495          |
| Harness Wire Splitter.....                   | 121-5988          |
| Trimmer Rack .....                           | 133-1441          |
| 5 Gallon Bucket .....                        | 133-2533          |
| Stand-On Weight Kit.....                     | 133-1428          |
| Chute Gate Kit W/ Bag.....                   | 133-1434          |
| Pneumatic Castor Wheel Kit.....              | 140-4311          |
| Blower Drive 60-in .....                     | 78527             |
| Roller Striper Kit.....                      | 133-1436          |
| 18x8.5n10 X-Tweel Turf.....                  | 139-7890          |
| Soft Bag (3 Bushel).....                     | 30104             |
| Spark Plug .....                             | 92-2153           |
| Element-Filter, Air (Outer).....             | 119-5944          |
| Bagger Enhancement Kit.....                  | 139-1529          |
| Recycler Kit .....                           | 139-6655          |
| Element-Filter, Air (Inner).....             | 119-5945          |
| Fuel Filter.....                             | 120-2235          |
| Blade-20.5 High Flow .....                   | 140-1240          |
| Blade-20.50 Medium Flow .....                | 140-4853          |
| Blade-20.50, Low Flow .....                  | 140-4854          |
| Blade-20.50 Atomic .....                     | 140-1241          |
| Blade-20.50 Recycler .....                   | 140-4855          |
| 6 Pack-Blade, 20.5 High Flow.....            | 140-4877          |
| 6 Pack-Blade, 20.5 Med Flow .....            | 140-4878          |
| 6 Pack-Blade, 20.5 Low Flow .....            | 140-4879          |
| 6 Pack-Blade, 20.5 Atomic.....               | 140-4880          |
| 6 Pack-Blade, 20.5 Recycler.....             | 140-4881          |
| Hypr-Oil 500 (quart).....                    | 114-4713          |
| Hypr-Oil 500 (gallon).....                   | 114-4714          |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715          |
| Blade-20.50 High Flow .....                  | 147-6252          |
| 6 Pack-Blade, 20.50 High Flow.....           | 147-6256          |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572          |
| Hydro Oil Change Kit .....                   | 133-1457          |
| 2 Transmission Filter Kit .....              | 144-3842          |
| 10W30 4-Cycle Engine Oil (32oz Bottle).....  | 38280             |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....  | 38903             |
| Spark Arrestor .....                         | 98-9099           |

**Notes:**



**Count on it.**