

Center Spindle Assembly Replacement Kit

36in and 52in Mid-Size Mower

Part No. 106-0802

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form \mathbf{nX} \mathbf{y} . The \mathbf{n} represents the quantity of the part, the \mathbf{X} is the multiplication symbol, and the \mathbf{y} represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.



Sheet No.:0

Center Spindle Assembly

г				
	Ref. No.	Part No.	Qty.	Description
	1 2 3 4 5 6 7 8	3219-7 7-4150 104-1117 106-0873 104-6325 106-0819 106-0795 106-0781	1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Nut-Hex Washer Pulley And Hub ASM Shield-Bearing Bearing Housing-Spindle Spacer-Bearing Shaft-Spindle

Ref. No.	Part No.	Qty.	Description
		<u> </u>	