



Snow Canopy

TX 1000 Compact Tool Carrier

Model No. 22584

Installation Instructions

▲ WARNING

CALIFORNIA Proposition 65 Warning

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Safety

▲ WARNING

This canopy does not protect you from falling objects or during rollovers.

Do not use the canopy as a falling object or rollover protection system.

Installation

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	–	Prepare the machine.
2	Front receiver tube Left, rear receiver tube Right, rear receiver tube Windshield bracket Hose guard Bolt (1/4 x 1-1/2 inches) Bolt (5/16 x 1 inch) Bolt (5/16 x 1-1/4 inches) Bolt (1/4 x 2 inches) Locknut (1/4 inch)	2 1 1 1 2 2 2 2 2 4	Install the receiver tubes.



Procedure	Description	Qty.	Use
3	Center brace	1	Assemble the frame.
	Front frame tube	1	
	Rear frame tube	1	
	Side frame tube	2	
	Front post	2	
	Rear post	2	
	Bolt (1/4 x 3/4 inch)	4	
	Bolt (1/4 x 1 inch)	6	
	Bolt (1/4 x 1-1/4 inches)	2	
	Acorn nut (1/4 inch)	2	
	Locknut (1/4 inch)	10	
Fender washer	4		
4	Left panel	1	Install the canopy.
	Right panel	1	
	Windshield	1	
	Top cover	1	
	Bolt (5/16 x 1-1/4 inches)	2	

1

Preparing the Machine

No Parts Required

Procedure

1. Park the machine on a level surface.
2. Lower the loader arms.
3. Engage the parking brake.
4. Shut off the engine and remove the key.

2

Installing the Receiver Tubes

Parts needed for this procedure:

2	Front receiver tube
1	Left, rear receiver tube
1	Right, rear receiver tube
1	Windshield bracket
2	Hose guard
2	Bolt (1/4 x 1-1/2 inches)
2	Bolt (5/16 x 1 inch)
2	Bolt (5/16 x 1-1/4 inches)
2	Bolt (1/4 x 2 inches)
4	Locknut (1/4 inch)

Procedure

1. Remove the 2 bolts and locknuts from the fuel tank lock plate to the machine (Figure 1). Retain the locknuts.




Figure 1

1. Bolt (5/16 x 7/8 inch)
2. Locknut (5/16 inch)

2. Install a front receiver tube to the right side of the machine using a bolt (1/4 x 1-1/2 inches) and locknut (1/4 inch) as shown in Figure 2.




Figure 2

1. Right, rear receiver tube
2. Bolt (5/16 x 1 inch) and retained locknut (5/16 inch)
3. Bolt (5/16 x 1-1/4 inches) and retained locknut (5/16 inch)
4. Hose guard
5. Bolt (1/4 x 1-1/2 inches) and locknut (1/4 inch)
6. Front receiver tube

3. Install the right, rear receiver tube using a bolt (5/16 x 1) and a retained locknut (5/16 inch) as shown in Figure 2.
4. Install the hose guard to the bracket of the rear receiver tube using a bolt (5/16 x 1-1/4 inch) and a retained locknut (5/16 inch) as shown in Figure 2.
5. Repeat steps 2 through 4 for the other side of the machine.
6. Install the windshield bracket, using the 2 bolts (1/4 x 2 inches) and 2 locknuts (1/4 inch) to also secure the front receiver tubes and the hose guards to the frame (Figure 3 and Figure 4).

3

Assembling the Frame

Parts needed for this procedure:

1	Center brace
1	Front frame tube
1	Rear frame tube
2	Side frame tube
2	Front post
2	Rear post
4	Bolt (1/4 x 3/4 inch)
6	Bolt (1/4 x 1 inch)
2	Bolt (1/4 x 1-1/4 inches)
2	Acorn nut (1/4 inch)
10	Locknut (1/4 inch)
4	Fender washer




Figure 3

g341665

1. Hose guard
2. Bolt (1/4 x 2 inches)
3. Receiver tube
4. Locknut (1/4 inch)
5. Windshield bracket




Figure 4

g341664

1. Bolt (1/4 x 2 inches)
2. Locknut (1/4 inch)
3. Windshield bracket

Procedure

1. Install the center brace to the front frame tube and rear frame tube using a bolt (1/4 x 1 inch) and acorn nut on each end (Figure 5).




Figure 5

View from rear

g323641

1. Center brace
2. Side frame tube
3. Hole for rear post
4. Bolt—1/4 x 1 inch (2)
5. Acorn nut (2)
6. Rear frame tube
7. Front frame tube

- Install the 2 side frame tubes to the rear frame tube (Figure 5 and Figure 6).

Note: Install the side frame tubes so that they bend outward and the holes for the rear posts are closer to the rear frame tube, as shown in Figure 5; ensure that the heads of the bolts face outward.




Figure 6

View from rear; left side shown

- | | |
|--------------------------|-----------------------|
| 1. Bolt (1/4 x 3/4 inch) | 4. Side frame tube |
| 2. Fender washer | 5. Locknut (1/4 inch) |
| 3. Rear frame tube | |

- Secure the 2 side frame tubes and 2 front posts to the front frame tube (Figure 7).

Note: The front posts are shorter than the rear posts; ensure that the heads of the bolts face outward.




Figure 7

- | | |
|-------------------------|----------------------------|
| 1. Post | 3. Bolt—1/4 x 3/4 inch (2) |
| 2. Locknut—1/4 inch (2) | 4. Side frame tube |

- Install the 2 rear posts to the side frame tubes (Figure 8).

Note: Ensure that the heads of the bolts face outward.




Figure 8

- | | |
|-------------------------|--------------------------------|
| 1. Locknut—1/4 inch (2) | 3. Bolt—1/4 x 1-1/4 inches (2) |
| 2. Post | |

- Install 4 bolts (1/4 x 1 inch) and 4 locknuts (1/4 inch) onto the posts so that the bolt heads face outward. (Figure 9).




Figure 9

- | | |
|--------------------------|-------------------------|
| 1. Bolt—1/4 x 1 inch (4) | 2. Locknut—1/4 inch (4) |
|--------------------------|-------------------------|

- With the assistance of another person, install the posts into the receiver tubes, using the bolts in the posts as stops (Figure 9).

4

Installing the Canopy

Parts needed for this procedure:

1	Left panel
1	Right panel
1	Windshield
1	Top cover
2	Bolt (5/16 x 1-1/4 inches)

Procedure

1. Install the left and right panels, using the hook and loop fasteners to secure them to the frame, as shown in [Figure 10](#) and [Figure 11](#).




Figure 10

g341667

1. Left panel
2. Hook and loop fastener




Figure 11

g323638

1. Right panel
2. Windshield

2. Install the windshield, using the hook and loop fasteners to secure it to the panels, front frame tube, and the windshield bracket ([Figure 11](#)).

Note: Secure the windshield to the front frame tube before securing it to the windshield bracket.

3. Install the top cover, using the hook and loop fasteners to secure it to the panels and windshield ([Figure 12](#)).





Figure 12

g323639

1. Top cover

4. On both sides of the machine, remove the existing bolt and install a bolt (5/16 x 1-1/4 inches) as shown in [Figure 13](#).



g323732

Figure 13

1. Spring 2. Bolt (5/16 x 1-1/4 inches)

-
5. Hook the springs from the panels on the bolt.

Operation

Transporting the Machine

Before transporting the machine, unhook the springs and lift the canopy frame out of the receiver tubes.

Important: Do not transport the machine with the canopy installed.

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



WARNING: Cancer and Reproductive Harm—www.p65Warnings.ca.gov.

What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to <https://oag.ca.gov/prop65/faqs-view-all>.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.