



MODEL NO. 41355

INSTRUCTION SHEET

HOSE REEL for the MULTI-PRO® 1200 and 1250 with COVERED BOOM

NOTICE:

Use this Instruction Sheet to mount the Hose Reel, Model 41134, on the Multi-Pro® 1200 & 1250 with a Covered Boom.

Additional parts required are as follows and should be ordered from an Authorized Toro Service Dealer.

Part #	Description	Qty
104-9026	Hose Reel Mount. Bracket	1
42257	1" Spacer Tube	4
3234-27	1/2 x 2/0 Flg. Head Bolt	4
32128-49	1/2 Flg. Nut	5
3234-17	5/16 x 1.0 Flg. Head Bolt	5
32128-44	5/16 Flg. Nut	5

The Hose Reel Mounting Bracket(104-9026) takes the place of 104-8716 (right) and 104-8717 (left) Hose Reel Mounts, as well as 104-8723 Cross Bars.

FRAME ASSEMBLY:

Use this procedure in place of Steps 1-8 of the Set-up instructions, Form No. 104-8731 REV-B.

1. Disconnect negative battery terminal from the Battery.
2. Loosen the two (2) 1/2" x 18 screws securing the Boom Mounting Assembly to the Vehicle Frame. Slide the Boom Mount Assembly out 2" to allow installation of the Hose Reel Mounting Bracket.
3. Drill holes on the left and right Boom Uprights as shown in FIG. 1.
4. Install the Hose Reel Mounting Bracket to the Boom Uprights using the 1" spacers and 1/2 x 2" Bolts with Flange Nuts. See FIG. 2.




FIG. 1

Boom Upright (Left shown)




FIG. 2

- | | |
|-------------------------------|-----------------|
| 1. Hose Reel Mounting Bracket | 2. 1/2" Bolt |
| 3. 1" Spacer | 4. Boom Upright |




FIG. 3

- 1. Hose Reel ASM
- 2. Hose Reel Mounting Bracket

5. Slide Boom Assembly into Vehicle Frame leaving 1-1/2" clearance from the Frame Tube for the Hoses and the right side of Boom. Tighten Bolts; there will be 1" clearance after Bolts have been completely tightened.

6. Remove the upper right Bolt securing the Motor Mounting Plate to the Hose Reel Frame. Use a 5/16 x 1.0" Flange Head Bolt and Flange Nut to secure the electrical box assembly at this location. See FIG. 3.

7. Mount the Hose Reel Assembly onto the Hose Reel Mounting Bracket using the four (4) 5/16 x 1.0" Flange Head Bolts and Flange Nuts. See FIG. 3.

8. Continue with Step 9 in the Hose Reel Set-Up instructions, Form No. 104-8731 REV-B, page 3.

NOTES: